FUJIFILM

DIGITAL CAMERA

X-T30 III

FF250003

Owner's Manual

BL00005411-200 EN

Introduction

Thank you for your purchase of this product. Be sure that you have read this manual and understood its contents before using the camera. Keep the manual where it will be read by all who use the product.

For the Latest Information

The latest versions of the manuals are available from:

https://fujifilm-dsc.com/en/manual/

The website can be accessed not only from your computer but also from smartphones and tablets. It also contains information on the software license.

For information on firmware updates, visit:
https://fujifilm-x.com/support/download/firmware/cameras/

Chapter Index

Menu List iv

1 Before You Begin 1

2 First Steps 35

3 Basic Photography and Playback 51

4 Movie Recording and Playback 59

5 Taking Photographs 67

6 The Shooting Menus 125

7 Playback and the Playback Menu 225

8 Network/USB Features and Settings 253

9 The Setup Menus 289

10 Shortcuts 329

11 Peripherals and Optional Accessories 349

12 Technical Notes 367

Menu List

Camera menu options are listed below.

Shooting Menus

Adjust settings when shooting photos or movies.

See page 125 for details.

Photo Menus

Items marked with both 📷 and 🎥 icons are available in both the still photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

	IQ IMAGE QUALITY SETTING	📖
1/4	IMAGE SIZE	126
	IMAGE QUALITY	127
	RAW RECORDING	128
	SELECT JPEG/HEIF	129
	FILM SIMULATION DIAL SETTING	130
	FILM SIMULATION	131
	MONOCHROMATIC COLOR	133
	GRAIN EFFECT	133
2/4	COLOR CHROME EFFECT	134
	COLOR CHROME FX BLUE	134
	WHITE BALANCE	135
	DYNAMIC RANGE	139
	D RANGE PRIORITY	140
	TONE CURVE	141
	COLOR	141
	SHARPNESS	141

	IQ IMAGE QUALITY SETTING	📖
3/4	HIGH ISO NR	142
	PORTRAIT ENHANCER LV	142
	CLARITY	142
	LONG EXPOSURE NR	143
	LENS MODULATION OPTIMIZER	143
	COLOR SPACE	143
	PIXEL MAPPING	144
	📷 SELECT CUSTOM SETTING	144
4/4	📷 EDIT/SAVE CUSTOM SETTING	145
	AUTO UPDATE CUSTOM SETTING	150
	📷 🎥 MOUNT ADAPTOR SETTING	150

AF/MF SETTING		
1/3	FOCUS AREA	153
	AF MODE	153
	ZONE CUSTOM SETTING	153
	AF MODE ALL SETTING	153
	AF-C CUSTOM SETTINGS	154
	STORE AF MODE BY ORIENTATION	158
	AF POINT DISPLAY	158
	WRAP FOCUS POINT	159
2/3	NUMBER OF FOCUS POINTS	159
	PRE-AF	160
	AF ILLUMINATOR	160
	FACE/EYE DETECTION SETTING	161
	SUBJECT DETECTION SETTING	163
	AF+MF	165
	MF ASSIST	166
	INTERLOCK MF ASSIST & FOCUS RING	167
3/3	FOCUS CHECK	167
	INTERLOCK SPOT AE & FOCUS AREA	168
	INSTANT AF SETTING	168
	DEPTH-OF-FIELD SCALE	169
	RELEASE/FOCUS PRIORITY	169
	AF RANGE LIMITER	170
	TOUCH SCREEN MODE	171

SHOOTING SETTING		
1/3	AUTO MODE SETTING	173
	SPORTS FINDER MODE	173
	PRE-SHOT ES	174
	SELF-TIMER	175
	SAVE SELF-TIMER SETTING	175
	SELF-TIMER LAMP	176
	AE BKT SETTING	176
	FILM SIMULATION BKT	177

SHOOTING SETTING		
2/3	FOCUS BKT SETTING	177
	PHOTOMETRY	177
	SHUTTER TYPE	178
	INTERVAL TIMER SHOOTING	179
	INTERVAL TIMER SHOOTING EXPOSURE SMOOTHING	181
	INTERVAL PRIORITY MODE	181
	FLICKER REDUCTION	182
	FLICKERLESS S.S. SETTING	182
3/3	IS MODE	183
	ISO	183

FLASH SETTING	
FLASH FUNCTION SETTING	184
RED EYE REMOVAL	184
TTL-LOCK MODE	185
LED LIGHT SETTING	185
COMMANDER SETTING	186
CH SETTING	186

MOVIE SETTING	
MOVIE MODE	187
HIGH SPEED REC	187
MEDIA REC SETTING	187
IS MODE	187
IS MODE BOOST	187
AUDIO SETTING	188
MIC/REMOTE RELEASE	190
REC FRAME INDICATOR	190

Movie Menus

Items marked with both 📷 and 🎥 icons are available in both the still photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

	MOVIE SETTING	📖
1/3	MOVIE SETTING LIST	191
	MOVIE MODE	192
	HIGH SPEED REC	193
	9:16 SHORT MOVIE MODE	194
	🎥 SELF-TIMER	194
	MEDIA REC SETTING	194
	HDMI OUTPUT SETTING	197
	FIX MOVIE CROP MAGNIFICATION	198
2/3	F-Log/HLG RECORDING	199
	DATA LEVEL SETTING	200
	🎥 PHOTOMETRY	200
	🎥 FLICKERLESS S.S. SETTING	200
	🎥 IS MODE	201
	🎥 IS MODE BOOST	201
	🎥 ISO	202
	ZEBRA SETTING	202
3/3	ZEBRA LEVEL	202
	MOVIE OPTIMIZED CONTROL	203
	🎥 REC FRAME INDICATOR	203
	TALLY LIGHT	204
	🎥 SELECT CUSTOM SETTING	205
	🎥 EDIT/SAVE CUSTOM SETTING	205
	🎥 AUTO UPDATE CUSTOM SETTING	205

	IMAGE QUALITY SETTING	📖
1/2	🎥 FILM SIMULATION DIAL SETTING	206
	🎥 FILM SIMULATION	206
	🎥 MONOCHROMATIC COLOR	206
	🎥 WHITE BALANCE	206
	🎥 DYNAMIC RANGE	207
	🎥 TONE CURVE	207
	🎥 COLOR	207
	🎥 SHARPNESS	208
2/2	🎥 HIGH ISO NR	208
	🎥 PORTRAIT ENHANCER LV	208
	INTERFRAME NR	208
	🎥 PERIPHERAL LIGHT CORRECTION	209
	📷 🎥 MOUNT ADAPTOR SETTING	209

AF/MF SETTING	
FOCUS AREA	210
AF MODE	210
AF-C CUSTOM SETTING	211
WRAP FOCUS POINT	211
FACE/EYE DETECTION SETTING	212
SUBJECT DETECTION SETTING	212
AF+MF	213
MF ASSIST	213
INTERLOCK MF ASSIST & FOCUS RING	213
FOCUS CHECK	214
INSTANT AF SETTING	214
DEPTH-OF-FIELD SCALE	214
AF RANGE LIMITER	214
TOUCH SCREEN MODE	215
FOCUS CHECK LOCK	217

AUDIO SETTING	
INTERNAL MIC LEVEL ADJUSTMENT	218
EXTERNAL MIC LEVEL ADJUSTMENT	218
MIC LEVEL LIMITER	219
MIC JACK SETTING	219
WIND FILTER	219
LOW CUT FILTER	220
HEADPHONES VOLUME	220
MIC/REMOTE RELEASE	220

TIME CODE SETTING	
TIME CODE DISPLAY	221
START TIME SETTING	221
COUNT UP SETTING	221
DROP FRAME	222
HDMI TIME CODE OUTPUT	222
TIME CODE SYNC. SETTING	223

The Playback Menu

Adjust playback settings.

See page 232 for details.

	PLAY BACK MENU	
1/2	RAW CONVERSION	232
	HEIF TO JPEG/TIFF CONVERSION	236
	ERASE	236
	CROP	238
	RESIZE	239
	PROTECT	240
	IMAGE ROTATE	241
	VOICE MEMO SETTING	242

	PLAY BACK MENU	
2/2	RATING	243
	TRANSFER IMAGE TO SMARTPHONE	244
	SLIDE SHOW	246
	PHOTOBOOK ASSIST	247
	PRINT ORDER (DPOF)	249
	instax PRINTER PRINT	250
	instax IMAGE QUALITY MODE	250
	DISP ASPECT	251

Setup Menus

Adjust basic camera settings.

See page 289 for details.

	USER SETTING	
1½	FORMAT	290
	AREA SETTING	291
	DATE/TIME	291
	TIME DIFFERENCE	292
	言語/LANG.	293
	MY MENU SETTING	293
	MY MENU SETTING	293
	SENSOR CLEANING	294
2½	SOUND & FLASH	294
	FIRMWARE UPDATE	294
	RESET	295
	SUPPORT WEBSITE	295
	REGULATORY	295

	SOUND SETTING	
1½	AF BEEP VOL.	296
	SELF-TIMER BEEP VOL.	296
	OPERATION VOL.	297
	REC START/STOP VOLUME	297
	MS EF ELECTRONIC SHUTTER VOLUME	297
	MS EF ELECTRONIC SHUTTER SOUND	298
	ES ELECTRONIC SHUTTER VOLUME	298
	ES ELECTRONIC SHUTTER SOUND	298
2½	PLAYBACK VOLUME	299

SCREEN SETTING		
1/4	VIEW MODE SETTING	300
	EVF BRIGHTNESS	300
	EVF COLOR	300
	EVF COLOR ADJUSTMENT	301
	LCD BRIGHTNESS	301
	LCD COLOR	301
	LCD COLOR ADJUSTMENT	301
	IMAGE DISP.	302
2/4	AUTOROTATE DISPLAYS	302
	PREVIEW EXP./WB IN MANUAL MODE	303
	NATURAL LIVE VIEW	303
	F-Log VIEW ASSIST	304
	ELECTRONIC LEVEL SETTING	304
	FRAMING GUIDELINE	304
	AUTOROTATE PB	305
	FOCUS SCALE UNITS	305
3/4	APERTURE UNIT FOR CINEMA LENS	305
	DISP. CUSTOM SETTING	306
	LARGE INDICATORS MODE(EVF)	306
	LARGE INDICATORS MODE(LCD)	307
	LARGE INDICATORS DISP. SETTING	308
	INFORMATION CONTRAST ADJ.	308
	LOCATION INFO	309
	Q MENU BACKGROUND	309
4/4	Q MENU BACKGROUND	309

BUTTON/DIAL SETTING		
1/3	FOCUS LEVER SETTING	310
	EDIT/SAVE QUICK MENU	311
	EDIT/SAVE QUICK MENU	311
	FUNCTION (Fn) SETTING	311
	POWER ZOOM LENS FUNCTION (Fn) SETTING	311
	COMMAND DIAL SETTING	312
	S.S. OPERATION	313
	COMMAND DIAL DIRECTION	313
2/3	SHUTTER AF	314
	SHUTTER AE	314
	SHOOT WITHOUT LENS	315
	SHOOT WITHOUT CARD	315
	LENS ZOOM/FOCUS SETTING	316
	AE/AF-LOCK MODE	319
	AWB-LOCK MODE	319
	APERTURE RING SETTING (A)	319
3/3	APERTURE SETTING	320
	Fn BUTTON SETTING	320
	TOUCH SCREEN SETTING	321
	LOCK	323

POWER MANAGEMENT	
AUTO POWER OFF	324
PERFORMANCE	324
EVF/LCD BOOST SETTING	325
AUTO POWER OFF TEMP.	325

SAVE DATA SETTING	
FRAME NO.	326
EDIT FILE NAME	327
SELECT FOLDER	327
COPYRIGHT INFO	328
GEOTAGGING	328

The Network/USB Settings Menu

Adjust camera network and USB settings.

See page 279 for details.

	NETWORK/USB SETTING	
	Bluetooth/SMARTPHONE SETTING	279
	AIRPLANE MODE	283
	NETWORK SETTING	283
	instax IMAGE QUALITY MODE	283
1½	Frame.io Camera to Cloud	284
	CONNECTION MODE	287
	USB POWER SUPPLY/ COMM SETTING	288
	INFORMATION	288
2½	RESET NETWORK/USB SETTING	288

Table of Contents

Introduction ii
For the Latest Information ii
Menu List iv
Shooting Menus iv
The Playback Menu viii
Setup Menus ix
The Network/USB Settings Menu xii
Supplied Accessories xxvii
About This Manual xxviii
Symbols and Conventions xxviii
Terminology xxviii

1 Before You Begin **1**

Parts of the Camera 2
The Serial Number Plate 4
The Focus Stick (Focus Lever) 4
The Shutter Speed Dial 4
Film Simulation Dial 5
The DRIVE Button 7
The Exposure Compensation Dial 7
The Auto Mode Selector Lever 8
The Command Dials 9
The Indicator Lamp 12
The LCD Monitor 13
Focusing the Viewfinder 13
Camera Displays 14
The Electronic Viewfinder 14
The LCD Monitor 16
Choosing a Display Mode 18
Adjusting Display Brightness 20
Display Rotation 20
The DISP/BACK Button 21
Customizing Display Indicators 23
Virtual Horizon 25

Using the Menus 26
The Menus 26
Selecting a Menu Tab 27
Touch Screen Mode 28
Shooting Touch Controls 28
Playback Touch Controls 33

2 First Steps **35**
Attaching the Strap 36
Attaching a Lens 37
Inserting the Battery and a Memory Card 39
Compatible Memory Cards 41
Charging the Battery 42
Turning the Camera On and Off 46
Checking the Battery Level 47
Basic Setup 48
Choosing a Different Language 50
Changing the Time and Date 50

3 Basic Photography and Playback **51**
Taking Photographs 52
Viewing Pictures 54
HDMI Output 55
Deleting Pictures 57

4 Movie Recording and Playback **59**
Recording Movies 60
Adjusting Movie Settings 63
Viewing Movies 64

5 Taking Photographs **67**
Choosing a Shooting Mode 68
AUTO (AUTO) 68
Mode P: Program AE 71
Mode S: Shutter-Priority AE 73
Mode A: Aperture-Priority AE 76
Mode M: Manual Exposure 78

Autofocus **82**
Focus Mode 83
Autofocus Options (AF Mode) 85
Focus-Point Selection 87
Manual Focus **91**
Checking Focus 93
Sensitivity **96**
AUTO 97
Metering **98**
Exposure Compensation **99**
C (Custom) 100
Focus/Exposure Lock **101**
Other Controls 102
Bracketing **103**
ISO ISO BKT 104
WB WHITE BALANCE BKT 104
BKT Bracketing 105
Continuous Shooting (Burst Mode) **108**
HDR **110**
Multiple Exposures **112**
Panoramas **115**
Filters **118**
Filter Options 119
Flash Photography **120**
Flash Settings 122

6 The Shooting Menus **125**
IMAGE QUALITY SETTING (Still Photography) **126**
IMAGE SIZE 126
IMAGE QUALITY 127
RAW RECORDING 128
SELECT JPEG/HEIF 129
FILM SIMULATION DIAL SETTING 130
FILM SIMULATION 131
MONOCHROMATIC COLOR 133
GRAIN EFFECT 133

COLOR CHROME EFFECT 134
COLOR CHROME FX BLUE 134
WHITE BALANCE 135
DYNAMIC RANGE 139
D RANGE PRIORITY 140
TONE CURVE 141
COLOR 141
SHARPNESS 141
HIGH ISO NR 142
PORTRAIT ENHANCER LV 142
CLARITY 142
LONG EXPOSURE NR 143
LENS MODULATION OPTIMIZER 143
COLOR SPACE 143
PIXEL MAPPING 144
SELECT CUSTOM SETTING 144
EDIT/SAVE CUSTOM SETTING 145
AUTO UPDATE CUSTOM SETTING 150
MOUNT ADAPTOR SETTING 150
AF/MF SETTING (Still Photography) 153
FOCUS AREA 153
AF MODE 153
ZONE CUSTOM SETTING 153
AF MODE ALL SETTING 153
AF-C CUSTOM SETTINGS 154
STORE AF MODE BY ORIENTATION 158
AF POINT DISPLAY 158
WRAP FOCUS POINT 159
NUMBER OF FOCUS POINTS 159
PRE-AF 160
AF ILLUMINATOR 160
FACE/EYE DETECTION SETTING 161
SUBJECT DETECTION SETTING 163
AF+MF 165
MF ASSIST 166
INTERLOCK MF ASSIST & FOCUS RING 167

FOCUS CHECK 167
INTERLOCK SPOT AE & FOCUS AREA 168
INSTANT AF SETTING 168
DEPTH-OF-FIELD SCALE 169
RELEASE/FOCUS PRIORITY 169
AF RANGE LIMITER 170
TOUCH SCREEN MODE 171
SHOOTING SETTING (Still Photography) 173
AUTO MODE SETTING 173
SPORTS FINDER MODE 173
PRE-SHOT ES 174
SELF-TIMER 175
SAVE SELF-TIMER SETTING 175
SELF-TIMER LAMP 176
AE BKT SETTING 176
FILM SIMULATION BKT 177
FOCUS BKT SETTING 177
PHOTOMETRY 177
SHUTTER TYPE 178
INTERVAL TIMER SHOOTING 179
INTERVAL TIMER SHOOTING EXPOSURE SMOOTHING 181
INTERVAL PRIORITY MODE 181
FLICKER REDUCTION 182
FLICKERLESS S.S. SETTING 182
IS MODE 183
ISO 183
FLASH SETTING (Still Photography) 184
FLASH FUNCTION SETTING 184
RED EYE REMOVAL 184
TTL-LOCK MODE 185
LED LIGHT SETTING 185
COMMANDER SETTING 186
CH SETTING 186

MOVIE SETTING (Still Photography) 187
MOVIE MODE 187
HIGH SPEED REC 187
MEDIA REC SETTING 187
IS MODE 187
IS MODE BOOST 187
AUDIO SETTING 188
MIC/REMOTE RELEASE 190
REC FRAME INDICATOR 190
MOVIE SETTING (Movie Recording) 191
MOVIE SETTING LIST 191
MOVIE MODE 192
HIGH SPEED REC 193
9:16 SHORT MOVIE MODE 194
SELF-TIMER 194
MEDIA REC SETTING 194
HDMI OUTPUT SETTING 197
FIX MOVIE CROP MAGNIFICATION 198
F-Log/HLG RECORDING 199
DATA LEVEL SETTING 200
PHOTOMETRY 200
FLICKERLESS S.S. SETTING 200
IS MODE 201
IS MODE BOOST 201
ISO 202
ZEBRA SETTING 202
ZEBRA LEVEL 202
MOVIE OPTIMIZED CONTROL 203
REC FRAME INDICATOR 203
TALLY LIGHT 204
SELECT CUSTOM SETTING 205
EDIT/SAVE CUSTOM SETTING 205
AUTO UPDATE CUSTOM SETTING 205
IMAGE QUALITY SETTING (Movie Recording) 206
FILM SIMULATION DIAL SETTING 206
FILM SIMULATION 206

MONOCHROMATIC COLOR 206
WHITE BALANCE 206
DYNAMIC RANGE 207
TONE CURVE 207
COLOR 207
SHARPNESS 208
HIGH ISO NR 208
PORTRAIT ENHANCER LV 208
INTERFRAME NR 208
PERIPHERAL LIGHT CORRECTION 209
MOUNT ADAPTOR SETTING 209
AF/MF SETTING (Movie Recording) 210
FOCUS AREA 210
AF MODE 210
AF-C CUSTOM SETTING 211
WRAP FOCUS POINT 211
FACE/EYE DETECTION SETTING 212
SUBJECT DETECTION SETTING 212
AF+MF 213
MF ASSIST 213
INTERLOCK MF ASSIST & FOCUS RING 213
FOCUS CHECK 214
INSTANT AF SETTING 214
DEPTH-OF-FIELD SCALE 214
AF RANGE LIMITER 214
TOUCH SCREEN MODE 215
FOCUS CHECK LOCK 217
AUDIO SETTING (Movie Recording) 218
INTERNAL MIC LEVEL ADJUSTMENT 218
EXTERNAL MIC LEVEL ADJUSTMENT 218
MIC LEVEL LIMITER 219
MIC JACK SETTING 219
WIND FILTER 219
LOW CUT FILTER 220
HEADPHONES VOLUME 220
MIC/REMOTE RELEASE 220

TIME CODE SETTING (Movie Recording) 221
TIME CODE DISPLAY 221
START TIME SETTING 221
COUNT UP SETTING 221
DROP FRAME 222
HDMI TIME CODE OUTPUT 222
TIME CODE SYNC. SETTING 223

7 Playback and the Playback Menu 225

The Playback Display 226
The DISP/BACK Button 228
Viewing Pictures 230
Playback Zoom 231
Multi-Frame Playback 231
The Playback Menu 232
RAW CONVERSION 232
HEIF TO JPEG/TIFF CONVERSION 236
ERASE 236
CROP 238
RESIZE 239
PROTECT 240
IMAGE ROTATE 241
VOICE MEMO SETTING 242
RATING 243
TRANSFER IMAGE TO SMARTPHONE 244
SLIDE SHOW 246
PHOTOBOOK ASSIST 247
PRINT ORDER (DPOF) 249
instax PRINTER PRINT 250
instax IMAGE QUALITY MODE 250
DISP ASPECT 251

8 Network/USB Features and Settings 253
Overview 254
Supported Features 254
Connecting to Smartphones (Bluetooth) 256
Installing Smartphone Apps 256
Connecting to a Smartphone 256
Using the Smartphone App 258
Connecting to Smartphones (USB) 260
Copying Pictures to a Smartphone 260
Connecting the Camera and Computer 261
Using the Camera as a Webcam 263
instax Printers 264
Establishing a Connection 264
Printing Pictures 265
Uploading Files to Frame.io 267
Connecting via Wireless LAN 267
Uploading Items to Frame.io 271
RAW Processing 274
Saving and Loading Settings 275
Saving and Loading Settings Using a Computer 275
Connecting via a USB Cable 276
Connecting to a Smartphone 276
Connecting to a Computer 278
Network/USB Setting Menus 279
Bluetooth/SMARTPHONE SETTING 279
AIRPLANE MODE 283
NETWORK SETTING 283
instax IMAGE QUALITY MODE 283
Frame.io Camera to Cloud 284
CONNECTION MODE 287
USB POWER SUPPLY/COMM SETTING 288
INFORMATION 288
RESET NETWORK/USB SETTING 288

9 The Setup Menus **289**

USER SETTING 290
FORMAT 290
AREA SETTING 291
DATE/TIME 291
TIME DIFFERENCE 292
言語/LANG. 293
MY MENU SETTING 293
MY MENU SETTING 293
SENSOR CLEANING 294
SOUND & FLASH 294
FIRMWARE UPDATE 294
RESET 295
SUPPORT WEBSITE 295
REGULATORY 295
SOUND SETTING 296
AF BEEP VOL. 296
SELF-TIMER BEEP VOL. 296
OPERATION VOL. 297
REC START/STOP VOLUME 297
MS EF ELECTRONIC SHUTTER VOLUME 297
MS EF ELECTRONIC SHUTTER SOUND 298
ES ELECTRONIC SHUTTER VOLUME 298
ES ELECTRONIC SHUTTER SOUND 298
PLAYBACK VOLUME 299
SCREEN SETTING 300
VIEW MODE SETTING 300
EVF BRIGHTNESS 300
EVF COLOR 300
EVF COLOR ADJUSTMENT 301
LCD BRIGHTNESS 301
LCD COLOR 301
LCD COLOR ADJUSTMENT 301
IMAGE DISP. 302
AUTOROTATE DISPLAYS 302
PREVIEW EXP./WB IN MANUAL MODE 303

NATURAL LIVE VIEW 303
F-Log VIEW ASSIST 304
ELECTRONIC LEVEL SETTING 304
FRAMING GUIDELINE 304
AUTOROTATE PB 305
FOCUS SCALE UNITS 305
APERTURE UNIT FOR CINEMA LENS 305
DISP. CUSTOM SETTING 306
LARGE INDICATORS MODE(EVF) 306
LARGE INDICATORS MODE(LCD) 307
LARGE INDICATORS DISP. SETTING 308
INFORMATION CONTRAST ADJ. 308
LOCATION INFO. 309
Q MENU BACKGROUND 309
Q MENU BACKGROUND 309
BUTTON/DIAL SETTING 310
FOCUS LEVER SETTING 310
EDIT/SAVE QUICK MENU 311
EDIT/SAVE QUICK MENU 311
FUNCTION (Fn) SETTING 311
POWER ZOOM LENS FUNCTION (Fn) SETTING 311
COMMAND DIAL SETTING 312
S.S. OPERATION 313
COMMAND DIAL DIRECTION 313
SHUTTER AF 314
SHUTTER AE 314
SHOOT WITHOUT LENS 315
SHOOT WITHOUT CARD 315
LENS ZOOM/FOCUS SETTING 316
AE/AF-LOCK MODE 319
AWB-LOCK MODE 319
APERTURE RING SETTING (A) 319
APERTURE SETTING 320
Fn BUTTON SETTING 320
TOUCH SCREEN SETTING 321
LOCK 323

POWER MANAGEMENT 324
AUTO POWER OFF 324
PERFORMANCE 324
EVF/LCD BOOST SETTING 325
AUTO POWER OFF TEMP. 325
SAVE DATA SETTING 326
FRAME NO. 326
EDIT FILE NAME 327
SELECT FOLDER 327
COPYRIGHT INFO 328
GEOTAGGING 328

10 Shortcuts 329
Shortcut Options 330
MY MENU 331
MY MENU SETTING 331
The Quick Menu 333
The Quick Menu Display 333
Viewing and Changing Settings 335
Editing the Quick Menu 336
Function Controls 339
The Function Buttons 339
Touch-Function Gestures 343
Lens Function Buttons 345

11 Peripherals and Optional Accessories 349
Lenses....350
Lens Parts....350
Lens Care....351
Removing Lens Caps....351
Attaching Lens Hoods....352
Lenses with Aperture Rings....353
Lenses with No Aperture Rings....354
Lenses with O.I.S. Switches....354
Manual Focus Lenses....355
Power Zoom Lenses....356
External Flash Units....357
Using an External Flash....358
SYNC TERMINAL....359
SHOE MOUNT FLASH....360
COMMANDER(OPTICAL)....363

12 Technical Notes 367
Accessories from Fujifilm....368
Software and Services for Use with Your Camera....371
Smartphone Apps....371
RAW FILE CONVERTER EX powered by SILKYPIX....371
FUJIFILM RAW Converter....372
Capture One....372
FUJIFILM TETHER APP....372
FUJIFILM X RAW STUDIO....373
Frame.io Camera to Cloud....373
For Your Safety....374
Product Care....388
Cleaning the Image Sensor....389
Firmware Updates....390
Downloading Firmware....390
Updating Firmware....390

Troubleshooting **393**
Power and Battery 393
Menus and Displays 395
Shooting 396
Playback 401
During Connection 402
Wireless Transfer 404
Miscellaneous 405
Warning Messages and Displays **406**
Memory Card Capacity **411**
Specifications **412**

Supplied Accessories

The following are included with the camera:

- NP-W126S rechargeable battery
- Body cap (comes attached to camera)
- Shoulder strap
- Headphone adapter

The battery is not charged at shipment. Charge the battery before use (📖 42).

- If you purchased a lens kit, check that a lens is included.
- The headphone adapter converts the USB Type-C connector to a ⌀3.5 mm headphone jack.
- For information on compatible computer software, see "Software and Services for Use with Your Camera" (📖 371).

About This Manual

This manual contains instructions for your FUJIFILM X-T30 III digital camera. Be sure you have read and understood its contents before proceeding.

Symbols and Conventions

The following symbols are used in this manual:

- Information that should be read to prevent damage to the product.
- Additional information that may be helpful when using the product.
- Pages on which related information may be found.

Menus and other text in the displays are shown in **bold**. Illustrations are for explanatory purposes only; drawings may be simplified, while photographs are not necessarily taken with the model of camera described in this manual.

Terminology

The optional SD, SDHC, and SDXC memory cards the camera uses to store pictures are referred to as "memory cards". The electronic viewfinder may be referred to as the "EVF" and the LCD monitor as the "LCD". Smartphones and tablets are referred to as "smartphones".

1 Before You Begin

Parts of the Camera



1. **Fn** *button* *339*
2. *Exposure compensation dial* *7, 99*
3. **ON/OFF** *switch* *46*
4. *Shutter button* *53*
5. *Auto mode selector lever* *8*
6. *Shutter speed dial* *4, 71, 73, 76, 78*
7. *Hot shoe* *358*
8. *Film simulation dial* *5*
9. ϟ *(flash pop-up) lever* *120*
10. *Strap clip* *36*
11. *Connector cover*
12. *Focus mode selector* *83*
13. *Lens signal contacts*
14. *Lens release button* *37*
15. *Microphone* *60, 218*
16. *AF-assist illuminator* *160*
    Self-timer lamp *175*
    Tally light *204*
17. *Front command dial* *9, 312*
18. *Flash* *120*
19. *Body cap* *37*
20. *Microphone/remote release connector (⌀2.5mm)* *62, 81, 220*
21. *USB connector (Type-C)* *42, 260*
22. *HDMI Micro connector (Type D)* *55*



(23) **DRIVE** *button* 7
🗑 *(delete) button* 57
(24) ▶ *(playback) button* 54
(25) *Diopter adjustment control* 13
(26) *Electronic viewfinder (EVF)* 14, 18, 20, 28
(27) **VIEW MODE** *button* 18
(28) **AE-L** *(exposure lock) button* 102, 339
(29) *Rear command dial* 9, 230, 312
(30) **AF-L** *(focus lock) button* 102, 339
(31) **Q** *(quick menu) button* 333
(32) *Indicator lamp* 12, 204
Tally light 204
(33) *Focus stick (focus lever)* 4, 88, 310
(34) **MENU/OK** *button* 26
(35) **DISP** *(display)*/**BACK** *button* 21, 228
(36) *Cable channel cover for DC coupler*
(37) *Battery-chamber cover* 39
(38) *Battery-chamber cover latch* 39
(39) *Serial number plate* 4
(40) *Tripod mount*
(41) *Speaker* 64, 299
(42) *LCD monitor* 13, 16, 18
Touch screen 28, 171, 215
(43) *Eye sensor* 19
(44) *Battery latch* 40
(45) *Battery chamber* 39
(46) *Memory card slot* 39

The Serial Number Plate

Do not remove the serial number plate, which provides the serial number and other important information.



Serial number plate

The Focus Stick (Focus Lever)

Tilt or press the focus stick to select the focus area. The focus stick can also be used to navigate the menus.



- To choose the role played by the focus stick, press and hold the center of the stick or use **BUTTON/DIAL SETTING** > **FOCUS LEVER SETTING**.
- Use **AF/MF SETTING** > **WRAP FOCUS POINT** to choose whether focus-area selection is bounded by the borders of the display or "wraps around" from one edge of the display to another.

The Shutter Speed Dial

The shutter speed dial is used to choose the shutter speed.



Film Simulation Dial

Rotate the film simulation dial and set the icon to the indicator to configure the film simulation.



Film Simulation Dial	Description
PROVIA/STANDARD **Velvia/VIVID** **ASTIA/SOFT** **CLASSIC CHROME** **REALA ACE** **ACROS**	Shoot with each film simulation. When shooting with **ACROS**, use **IMAGE QUALITY SETTING** > **FILM SIMULATION DIAL SETTING** to set the filter.
FS1 **FS2** **FS3**	Shoot with a film simulation set in **IMAGE QUALITY SETTING** > **FILM SIMULATION DIAL SETTING**. Separate settings are available for still photography and movie recording.
C (Custom)	Shoot with a film simulation set in **IMAGE QUALITY SETTING** > **FILM SIMULATION** or in **FILM SIMULATION** without setting a film simulation with the film simulation dial. The film simulation setting can be changed with the command dial (📖 312).

- Select **ON** for **FS RECIPE** in **IMAGE QUALITY SETTING** > **FILM SIMULATION DIAL SETTING** or **FILM SIMULATION DIAL SETTING** to save the image quality setting for **FS1**, **FS2**, and **FS3**.
- The following settings are valid only when the film simulation dial is set to **C**.
  - Settings of **IMAGE QUALITY SETTING** > **FILM SIMULATION** or **FILM SIMULATION**
  - Settings of the film simulation in the **Q** menu
  - Settings by the function buttons to which a film simulation has been assigned
  - Settings of **FILM SIMULATION** saved in **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** or in **MOVIE SETTING** > **EDIT/SAVE CUSTOM SETTING**

The DRIVE Button

Pressing the **DRIVE** button displays drive-mode menu, where you can choose from the following the drive modes.



Mode		📖
	Single frame	68
	High-speed burst	108
	Low-speed burst	108
ISO	ISO BKT	104
WB	WHITE BALANCE BKT	104
BKT	Bracketing	105

Mode		📖
HDR	HDR	110
	Multiple exposure	112
Adv.	Adv. MODE	115 118
	Movie	60

The Exposure Compensation Dial

Rotate the dial to choose an exposure compensation amount.



The Auto Mode Selector Lever

Switch between auto and manual modes.



Position	Mode	📖
	Select from **P** (program AE), **S** (shutter-priority AE), **A** (aperture-priority AE), and **M** (manual) modes. Adjust shutter speed and aperture using program shift (mode **P**) or set shutter speed and/or aperture manually (modes **S**, **A**, and **M**).	71, 73, 76, 78
	Auto mode. The camera adjusts settings automatically according to the option selected by rotating the front command dial. Choose from modes suited to specific subject types, or select **AUTO** to let the camera automatically match the mode to the subject. Scene selection is not available in drive modes ISO, WB, **BKT**, and HDR.	68

Restrictions may apply to camera settings depending on the mode and shooting conditions.

The Command Dials

Rotate or press the command dials to:

	Front command dial	Rear command dial
		
Rotate	• Select menu tabs or page through menus • Adjust aperture • Choose a scene (auto mode) • Choose a film simulation • Adjust exposure compensation • Adjust sensitivity • View other pictures during playback	• Highlight menu items • Choose the desired combination of shutter speed and aperture (program shift) • Choose a shutter speed • Adjust exposure compensation • Adjust settings in the quick menu • Choose the size of the focus frame • Zoom in or out in full frame playback • Zoom in or out in multi-frame playback
Press	• Choose the roles played by the front command dial (📖 10). • Press and hold to choose the option selected for **F BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING** in the **F** (setup) menu	• Zoom in on the active focus point* • Press and hold to choose the manual focus mode focus display* • Zoom in on the active focus point during playback

* Available only if **FOCUS CHECK** is assigned to a function button.

The rotation direction for the command dials can be selected using **F BUTTON/DIAL SETTING** > **COMMAND DIAL DIRECTION**.

Choosing a Function for the Front Command Dial

Press the center of the front command dial during shooting to choose a function assigned in **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.



The following functions can be assigned.

Function	Description
S.S. (PROGRAM SHIFT)	Select a shutter speed. Program shift is possible in mode **P**.
APERTURE	Adjust aperture when the aperture setting is **A** (auto) and **BUTTON/DIAL SETTING** > **APERTURE RING SETTING (A)** is **COMMAND** or when the lens is not equipped with an aperture ring.
EXPOSURE COMPENSATION	Adjust exposure compensation when the exposure compensation dial is set to **C**.
ISO	Adjust sensitivity.
FILM SIMULATION	Choose a film simulation when the film simulation dial is set to **C**.

- Choose between **FILM SIMULATION** and **AUTO MODE SETTING** when the auto mode selector lever is set to **AUTO** (📖 70).
- Depending on the shooting mode or drive mode, some functions cannot be assigned or may be disabled even if they have been assigned.

Choosing a Function for the Rear Command Dial

Values of the functions assigned by **REAR COMMAND DIAL** in **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING** can be adjusted by the rear command dial during shooting. The following functions can be assigned to the dial.

Function	Description
S.S. (PROGRAM SHIFT)	Select a shutter speed. Program shift is possible in mode **P**.
APERTURE	Adjust aperture when the aperture setting is **A** (auto) and **BUTTON/DIAL SETTING** > **APERTURE RING SETTING (A)** is **COMMAND** or when the lens is not equipped with an aperture ring.
EXPOSURE COMPENSATION	Adjust exposure compensation when the exposure compensation dial is set to **C**.
ISO	Adjust sensitivity.
FILM SIMULATION	Choose a film simulation when the film simulation dial is set to **C**.

- The function is automatically switched to **EXP. COMPENSATION** when the auto mode selector lever is set to **AUTO**.
- Depending on the shooting mode or drive mode, some functions cannot be assigned or may be disabled even if they have been assigned.

The Indicator Lamp

Camera status is shown by the indicator lamp.



Indicator lamp	Camera status
Glows green	Focus locked.
Blinks green	Focus or slow shutter speed warning. Pictures can be taken.
Blinks green and orange	• **Camera on**: Recording pictures, or picture displayed for confirmation after being taken with option other than **OFF** selected for **SCREEN SETTING** > **IMAGE DISP.** (additional pictures can be taken). • **Camera off**: Uploading pictures to a smartphone or tablet.*
Glows orange	Recording pictures. No additional pictures can be taken at this time.
Blinks orange	Flash charging; flash will not fire when picture is taken.
Blinks red	Lens or memory error.

* Displayed only if pictures are selected for upload.

- Warnings may also appear in the display.
- The indicator lamp remains off while your eye is to the viewfinder.
- The **MOVIE SETTING** > **TALLY LIGHT** option can be used to choose the lamp (indicator or AF-assist) that lights during movie recording and whether the lamp blinks or remains steady.
- The indicator lamp blinks green whenever the displays are off during interval-timer photography.

The LCD Monitor

The LCD monitor can be tilted for easier viewing, but be careful not to touch the wires or trap fingers or other objects behind the monitor. Touching the wires could cause camera malfunction.



The LCD monitor also functions as a touch screen that can be used for:

- EVF (📖 28)
- LCD Monitor (📖 29)
- MOVIE OPTIMIZED CONTROL (📖 30)
- Touch Function (📖 31)
- Playback Touch Controls (📖 33)

Focusing the Viewfinder

If the indicators displayed in the viewfinder are blurred, put your eye to the viewfinder and rotate the diopter adjustment control until the display is in sharp focus.



Camera Displays

This section lists the indicators that may be displayed during shooting.

For illustrative purposes, displays are shown with all indicators lit.

The Electronic Viewfinder



① Crop factor 198
② IS mode[2] 183
③ Movie compression 195
④ Focus check 94, 167
⑤ Depth-of-field preview 77, 93
⑥ Flash (TTL) mode 360
⑦ Flash compensation 360
⑧ Self-timer indicator 175, 194
⑨ Continuous mode 108
⑩ Shutter type 178
⑪ AF+MF indicator[2] 165
⑫ Bluetooth ON/OFF
⑬ Wireless connection
⑭ White balance 135
⑮ AWB lock 319
⑯ Film simulation 131
⑰ F-Log/HLG recording 199
⑱ Dynamic range 139
⑲ D-range priority 140
⑳ Bluetooth host 256
㉑ AirGlu BT connection 223
㉒ Movie mode 60, 192
㉓ High-speed recording indicator 193
㉔ Recording time available/ elapsed recording time 60
㉕ Destination for movie recording 194
㉖ Number of available frames[1] 411
㉗ Image size 126
㉘ File format 195
㉙ Image quality 127
㉚ HEIF format 129
㉛ Date and time 48, 50, 291
㉜ Touch screen mode 28, 171
㉝ Temperature warning 40, 410
㉞ Control lock[3] 323
㉟ Boost mode 324
㊱ Power supply 44
㊲ Histogram 24
㊳ Battery level 47
㊴ Sensitivity 96
㊵ Exposure compensation 99
㊶ Aperture 72, 76, 78
㊷ Distance indicator[2] 93
㊸ Shutter speed 72, 73, 78
㊹ TTL lock 185, 342
㊺ AE lock 102, 319
㊻ Metering 98
㊼ Shooting mode 68
㊽ Focus mode[2] 83
㊾ Focus indicator[2] 84
㊿ Manual focus indicator[2] 83, 91
(51) AF lock 102, 319
(52) Time code 221
(53) Microphone input channel
(54) Recording level[2] 218
(55) Exposure indicator 78, 99
(56) Virtual horizon 25
(57) Focus frame 87, 101
(58) Location data download status 256, 328
(59) Frame.io connection status 270
(60) Image transfer status 256, 279
(61) Frame.io upload progress 267

1 Shows "9999" if there is space for over 9999 frames.

2 Not displayed when **ON** is selected for **SCREEN SET-UP** > **LARGE INDICATORS MODE(EVF)**.

3 Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.

The LCD Monitor



(1) *Wireless connection*
(2) *Bluetooth ON/OFF*
(3) *Crop factor* 198
(4) *Image transfer status* 256, 279
(5) *Frame.io upload progress* 267
(6) *Movie compression* 195
(7) *Focus check* 94, 167
(8) *Depth-of-field preview* 77, 93
(9) *Bluetooth host* 256
(10) *AirGlu BT connection* 223
(11) *Location data download status* 256, 328
(12) *Movie mode* 60, 192
(13) *High-speed recording indicator* 193
(14) *Focus frame* 87, 101
(15) *Recording time available/ elapsed recording time* 60
(16) *Date and time* 48, 50, 291
(17) *Destination for movie recording* 194
(18) *Number of available frames*[1] 411
(19) *Image size* 126
(20) *File format* 195
(21) *Image quality* 127
(22) *HEIF format* 129
(23) *Touch screen mode*[3] 28, 171
(24) *AWB lock* 319
(25) *White balance* 135
(26) *Film simulation* 131
(27) *F-Log/HLG recording* 199
(28) *Dynamic range* 139
(29) *D-range priority* 140
(30) *Movie optimized control*[3] 30
(31) *Virtual horizon* 25
(32) *Boost mode* 324
(33) *Touch zoom*[3] 32
(34) *Temperature warning* 40, 410
(35) *Control lock*[4] 323
(36) *Battery level* 47
(37) *Power supply* 44
(38) *Sensitivity* 96
(39) *Histogram* 24
(40) *Exposure compensation* 99
(41) *Distance indicator*[2] 93
(42) *Aperture* 72, 76, 78
(43) *Time code* 221
(44) *Shutter speed* 72, 73, 78
(45) *TTL lock* 185, 342
(46) *AE lock* 102, 319
(47) *Metering* 98
(48) *Shooting mode* 68
(49) *Focus mode*[2] 83
(50) *Focus indicator*[2] 84
(51) *Manual focus indicator*[2] 83, 91
(52) *AF lock* 102, 319
(53) *Microphone input channel*
(54) *AF+MF indicator*[2] 165
(55) *Shutter type* 178
(56) *Recording level*[2] 218
(57) *Continuous mode* 108
(58) *Self-timer indicator* 175, 194
(59) *Exposure indicator* 78, 99
(60) *Frame.io connection status* 270
(61) *Flash (TTL) mode* 360
(62) *Flash compensation* 360
(63) *IS mode*[2] 183

1 Shows "9999" if there is space for over 9999 frames.

2 Not displayed when **ON** is selected for **SCREEN SET-UP** > **LARGE INDICATORS MODE(LCD)**.

3 Camera functions can also be accessed via touch controls.

4 Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.

Choosing a Display Mode

Press the **VIEW MODE** button to cycle through the following display modes. You can choose separate display modes for shooting and playback.



Use **SCREEN SET-UP** > **VIEW MODE SETTING** in the setup menu to choose a display mode for the EVF and LCD monitor.

SHOOTING

Option	Description
EYE SENSOR	Putting your eye to the viewfinder turns the viewfinder on and the LCD monitor off; taking your eye away turns the viewfinder off and LCD monitor on.
LCD ONLY	LCD monitor on, viewfinder off.
EVF ONLY	Viewfinder on, LCD monitor off.
EVF ONLY + EYE SENSOR	Putting your eye to the viewfinder turns the viewfinder on; taking it away turns the viewfinder off. The LCD monitor remains off.
EYE SENSOR + LCD IMAGE DISP.	Putting your eye to the viewfinder during shooting turns the viewfinder on, but the LCD monitor is used for the display of images once you remove your eye from the viewfinder after shooting. The options selected for **SCREEN SET-UP** > **IMAGE DISP.** apply to display in the LCD monitor. This setting cannot be selected while shooting movies.

Go to **SCREEN SET-UP** > **VIEW MODE SETTING** > **SHOOTING** in the setup menu and press the **Q** button to choose the view modes available.

PLAYBACK

Option	Description
EYE SENSOR	Putting your eye to the viewfinder turns the viewfinder on and the LCD monitor off; taking your eye away turns the viewfinder off and LCD monitor on.
LCD ONLY	LCD monitor on, viewfinder off.
EVF ONLY	Viewfinder on, LCD monitor off.

The Eye Sensor

The eye sensor may respond to objects other than your eye or to light shining directly on the sensor.



Eye sensor

Adjusting Display Brightness

The brightness and saturation of the viewfinder and LCD monitor can be adjusted using the items in the **SCREEN SET-UP** menu. Choose **EVF BRIGHTNESS** or **EVF COLOR** to adjust viewfinder brightness or saturation, **LCD BRIGHTNESS** or **LCD COLOR** to do the same for the LCD monitor.

Display Rotation

When **ON** is selected for **SCREEN SET-UP** > **AUTOROTATE DISPLAYS**, the indicators in the viewfinder and LCD monitor automatically rotate to match camera orientation.

The DISP/BACK Button

The **DISP/BACK** button controls the display of indicators in the viewfinder and LCD monitor.



Indicators for the EVF and LCD must be selected separately. To choose the EVF display, place your eye to the viewfinder while using the **DISP/BACK** button.

Viewfinder

Standard indicators



Full screen (no indicators)

LCD Monitor

Standard indicators



No indicators



Info display
(still photography only)

Customizing Display Indicators

To choose the items shown in the standard indicator display:

1 Select DISP. CUSTOM SETTING.
Select **SCREEN SET-UP** > **DISP. CUSTOM SETTING** in the setup menu.

2 Choose items.
Highlight items and press **MENU/OK** to select or deselect.

- FRAMING GUIDELINE
- FOCUS FRAME
- FOCUS INDICATOR
- AF DISTANCE INDICATOR
- MF DISTANCE INDICATOR
- HISTOGRAM
- LIVE VIEW HIGHLIGHT ALERT
- SHOOTING MODE
- APERTURE/S-SPEED/ISO
- INFORMATION BACKGROUND
- Expo. Comp. (Digit)
- Expo. Comp. (Scale)
- FOCUS MODE
- PHOTOMETRY
- SHUTTER TYPE
- FLASH
- CONTINUOUS MODE
- DUAL IS MODE
- TOUCH SCREEN MODE
- WHITE BALANCE
- FILM SIMULATION
- DYNAMIC RANGE
- BOOST MODE
- FRAMES REMAINING
- IMAGE SIZE/QUALITY
- MOVIE MODE & REC. TIME
- COMMUNICATION STATUS
- MIC LEVEL
- GUIDANCE MESSAGE
- NO STORAGE MEDIA WARNING
- DATE/TIME
- BATTERY LEVEL
- FRAMING OUTLINE

3 Press DISP/BACK to save changes.

Framing Outline

Enable **FRAMING OUTLINE** to make the borders of the frame easier to see against dark backgrounds.

Histograms

Histograms show the distribution of tones in the image. Brightness is shown by the horizontal axis, the number of pixels by the vertical axis.



- **Optimal exposure**: Pixels are distributed in an even curve throughout the tone range.
- **Overexposed**: Pixels are clustered on the right side of the graph.
- **Underexposed**: Pixels are clustered on the left side of the graph.



To view separate RGB histograms and a display showing areas of the frame that will be overexposed at current settings superimposed on the view through the lens, press the function button to which **HISTOGRAM** is assigned (📖 311, 339).



① *Overexposed areas blink*
② *RGB histograms*

Virtual Horizon

Check whether the camera is level. The display type can be chosen using **SCREEN SET-UP** > **ELECTRONIC LEVEL SETTING**. Use the virtual horizon to level the camera when mounting it on a tripod or the like.



- **OFF**: The virtual horizon is not displayed.
- **2D**: A white line shows the amount the camera is tilted left or right. The line turns green when the camera is level. The line may vanish if the camera is tilted forward or back.
- **3D**: The display shows whether the camera is tilted left or right and forward or back.

ELECTRONIC LEVEL SWITCH can be assigned to a function button and the button then used to switch between the 2D and 3D displays.

Using the Menus

To display the menus, press **MENU/OK**.



The Menus

Different menus are displayed during still photography, movie recording, and playback.

Still Photography

The photo menus are displayed when a setting other than **MOVIE** is selected in the drive mode options.



Movie Recording

The movie menus are displayed when **MOVIE** is selected in the drive mode options.



Playback

The playback menus are displayed during playback.



Selecting a Menu Tab

To navigate the menus:

1 Press **MENU/OK** to display the menus.



2 Press the focus stick (focus lever) left to highlight the tab for the current menu.



Tab

3 Press the focus stick up or down to highlight the tab containing the desired item.

4 Press the focus stick right to place the cursor in the menu.

Use the front command dial to select menu tabs or page through menus and the rear command dial to highlight menu items.

Touch Screen Mode

The LCD monitor also functions as a touch screen.

Shooting Touch Controls

To enable touch controls, select **ON** for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **TOUCH SCREEN SETTING**.



EVF

The LCD monitor can be used to select the focus area while pictures are being framed in the electronic viewfinder (EVF). Use **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **EVF TOUCH SCREEN AREA SETTINGS** to choose the area of the monitor employed for touch controls.



- When **FACE DETECTION ON** is selected for **AF/MF SETTING** > **FACE/EYE DETECTION SETTING**, you can choose the face used for focus.
- You can choose the type of subject on which the camera preferentially focuses when **SUBJECT DETECTION ON** is selected for **AF/MF SETTING** > **SUBJECT DETECTION SETTING**.

LCD Monitor

The operation performed can be selected by tapping the touch screen mode indicator in the display. Touch controls can be used for the following operations:



Mode	Description
TOUCH SHOOTING	Tap your subject in the display to focus and release the shutter. In burst mode, pictures will be taken while you keep your finger on the display.
AF ↓↑ **AF OFF**	• In focus mode **S** (AF-S), the camera focuses when you tap your subject in the display. Focus locks at the current distance until you tap the **AF OFF** icon. • In focus mode **C** (AF-C), the camera initiates focus when you tap your subject display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the **AF OFF** icon. • In manual focus mode (MF), you can tap the display to focus on the selected subject using autofocus.
AREA	Tap to select a point for focus or zoom. The focus frame will move to the selected point.
OFF	Touch screen mode off.

- The behavior of the touch screen varies with the AF mode.
- Different touch controls are used during focus zoom (📖 172).

- To disable touch controls and hide the touch screen mode indicator, select **OFF** for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **TOUCH SCREEN SETTING**.
- Touch control settings can be adjusted using **AF/MF SETTING** > **TOUCH SCREEN MODE**. For information on the touch controls available during movie recording, see "Movie Recording (**TOUCH SCREEN MODE**; 📖 215)".

MOVIE OPTIMIZED CONTROL

Selecting **ON** for **MOVIE SETTING** > **MOVIE OPTIMIZED CONTROL** or tapping the movie-optimized mode button in the shooting display optimizes the command dials and touch controls for movie recording. This can be used to prevent camera sounds being recorded with movie footage.



Movie-optimized mode button

- SHUTTER SPEED
- APERTURE
- EXPOSURE COMPENSATION
- ISO
- INTERNAL MIC LEVEL ADJUSTMENT/EXTERNAL MIC LEVEL ADJUSTMENT
- WIND FILTER
- HEADPHONES VOLUME
- FILM SIMULATION
- WHITE BALANCE
- IS MODE
- IS MODE BOOST

- Enabling movie-optimized controls disables the aperture ring.
- When movie-optimized control is enabled, the movie-optimized mode button can be used to change shooting settings or disable movie-optimized control.
- **EXTERNAL MIC LEVEL ADJUSTMENT** can be set only when an external mic is connected.

Touch Function



Functions can be assigned to the following flick gestures in much the same way as function buttons (📖 339):

- Flick up: **T-Fn1**
- Flick left: **T-Fn2**
- Flick right: **T-Fn3**
- Flick down: **T-Fn4**

- In some cases, touch-function flick gestures display a menu; tap to select the desired option.



- Touch-function gestures are disabled by default. To enable touch-function gestures, select **ON** for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **T-Fn TOUCH FUNCTION**.

Touch Zoom

If the lens supports touch zoom, you can zoom in and out by touching the display. Tap the touch zoom button in the display to enable touch zoom.



Touch zoom is controlled using the buttons in the display.



Button	Description
Touch zoom	Enable touch zoom.
Zoom in	Zoom in or out. Touch and hold to zoom in or out at a constant speed.
Zoom out	
Rocker switch	The camera zooms in or out at a speed corresponding to the position of the rocker switch.
Disable	Disable touch zoom.

The rate at which the camera zooms in and out in response to the **T** and **W** buttons can be selected using **BUTTON/DIAL SETTING** > **LENS ZOOM/FOCUS SETTING** > **CONSTANT SPEED ZOOM (Fn)**.

Playback Touch Controls

When **ON** is selected for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **TOUCH SCREEN SETTING**, touch controls can be used for the following playback operations:

- **Swipe**: Swipe a finger across the display to view other images.

- **Pinch-out**: Place two fingers on the display and spread them apart to zoom in.

- **Pinch-in**: Place two fingers on the display and slide them together to zoom out.



Pictures can be zoomed out until the entire image is visible but no further.

- **Double-tap**: Tap the display twice to zoom in on the focus point.

- **Drag**: View other areas of the image during playback zoom.



MEMO

2 First Steps

Attaching the Strap

Attach the strap.

Attach the strap to the two strap clips as shown below.



To avoid dropping the camera, be sure the strap is correctly secured.

Attaching a Lens

The camera can be used with lenses for the FUJIFILM X-mount.

Remove the body cap from the camera and the rear cap from the lens. Place the lens on mount, keeping the marks on the lens and camera aligned (①), and then slowly rotate the lens in the direction of the arrow until it clicks into place (②).



- When attaching lenses, ensure that dust or other foreign matter does not enter the camera.
- Be careful not to touch the camera's internal parts.
- Rotate the lens until it clicks securely into place.
- Do not press the lens release button while attaching the lens.

Removing Lenses

To remove the lens, turn the camera off, then press the lens release button (①) and slowly rotate the lens as shown (②).



To prevent dust accumulating on the lens or inside the camera, replace the lens caps and camera body cap when the lens is not attached.

Lenses and Other Optional Accessories

The camera can be used with lenses and accessories for the FUJIFILM X-mount.

Observe the following precautions when attaching or removing (exchanging) lenses.

- Check that the lenses are free of dust and other foreign matter.
- Do not change lenses in direct sunlight or under another bright light source. Light focused into the interior of the camera could cause it to malfunction.
- Attach the lens caps before exchanging lenses.
- Do not rotate the lens while holding moving parts of the camera, such as the aperture ring.
- See the manual provided with the lens for information on use.

Inserting the Battery and a Memory Card

Insert the battery and memory card as described below.

1 Open the battery-chamber cover.

Slide the battery-chamber cover latch as shown and open the battery-chamber cover.





- Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could damage image files or memory cards.
- Do not use excessive force when handling the battery-chamber cover.

2 Insert the battery as shown.



- Insert the battery in the orientation shown. *Do not use force or attempt to insert the battery upside down or backwards.*
- Confirm that the battery is securely latched.

3 Insert the memory card.



4 Close the battery-chamber cover and slide the battery-chamber latch closed.

If the cover does not close, check that the battery is in the correct orientation. Do not attempt to force the cover shut.



Removing the Battery

Before removing the battery, *turn the camera off* and open the battery-chamber cover.

To remove the battery, press the battery latch to the side, and slide the battery out of the camera as shown.



The battery may become hot when used in high-temperature environments. Observe caution when removing the battery.

Removing Memory Cards

To remove the memory card, press it in and release it slowly. The card can then be removed by hand.



- Press the center of the card.
- Suddenly removing your finger from the card could cause the card to fall from the slot. Remove your finger slowly.
- If the camera displays a ! icon, the memory card may be hot to the touch. Wait for the card to cool before removing it.

Compatible Memory Cards

- The camera can be used with SD, SDHC, and SDXC memory cards.
- The camera supports UHS-I memory cards.
- The types of memory cards suitable for movie recording vary with the settings selected (📖 63).
- A list of supported memory cards is available on the Fujifilm website. For details, visit: *https://fujifilm-x.com/support/compatibility/cameras/*.

- *Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card.* Failure to observe this precaution could damage the card.
- Memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting a memory card, slide the write-protect switch to the unlocked position.



- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than memory cards may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels or other objects to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of memory card.
- Formatting a memory card in the camera creates a folder in which pictures are stored when a picture is taken for the first time. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals. Renaming the files can cause problems during playback on the camera.

Charging the Battery

The battery is not charged at shipment. Charge the battery before use.

- An NP-W126S rechargeable battery is supplied with the camera.
- This product does not include an AC adapter or USB cable. Use a USB-IF certified AC adapter or USB-C to USB-C cable when charging with the camera.
- The battery takes about 120 minutes to charge with a recommended AC adapter of 7.5 W or more (📖 384).

Charge the battery.

Plug the AC adapter into an indoor power outlet (①), then connect the camera to the AC adapter using the USB cable (②).



- Connect the cable to the camera's USB connector (Type-C).
- Be sure the connectors are fully inserted.

Charge Status

The indicator lamp shows battery charge status as follows:



Indicator lamp	Battery status
On	Battery charging
Off	Charging complete
Blinks	Charging error

- Do not affix labels or other objects to the battery. Failure to observe this precaution could make it impossible to remove the battery from the camera.
- Do not short the battery terminals. The battery could overheat.
- Read the cautions in "The Battery and Power Supply".
- Use only genuine Fujifilm rechargeable batteries designated for use in this camera. Failure to observe this precaution could result in product malfunction.
- Do not remove the labels from the battery or attempt to split or peel the outer casing.
- The battery gradually loses its charge when not in use. Charge the battery one or two days before use.
- If the battery fails to hold a charge, it has reached the end of its charging life and must be replaced.
- Remove dirt from the battery terminals with a clean, dry cloth. Failure to observe this precaution could prevent the battery from charging.
- Note that charging times increase at low or high temperatures.
- Selecting **ON** for **Bluetooth/SMARTPHONE SETTING** > **Bluetooth ON/OFF** in the network/USB settings menu increases the drain on the battery.

- If the camera is turned on during charging, charging will end and the USB connection will instead be used to power the camera. The battery level will begin to gradually decline (📖 288).



- The camera will display a "power supply" icon when powered via USB.

Charging via Computer

The camera can be charged via USB. USB charging is available with computers with a manufacturer-approved operating system and USB interface.



USB connector (Type-C)
Leave the computer on during charging.

- The battery will not charge while the camera is on.
- Connect a third-party USB cable.
- Connect the camera directly to the computer; do not use a USB hub or keyboard.
- Charging stops if the computer enters sleep mode. To resume charging, activate the computer and disconnect and reconnect the USB cable.
- Charging may not be supported depending on the model of computer, computer settings, and the computer's current state.
- The battery takes about 300 minutes to charge with a charging input of 5 V/500 mA.

Turning the Camera On and Off

Use the **ON/OFF** switch to turn the camera on and off.

Slide the switch to **ON** to turn the camera on, or to **OFF** to turn the camera off.



Fingerprints and other marks on the lens or viewfinder can affect pictures or the view through the viewfinder. Keep the lens and viewfinder clean.

- Pressing the ▶ button during shooting starts playback.
- Press the shutter button halfway to return to shooting mode.
- The camera will turn off automatically if no operations are performed for the length of time selected for **POWER MANAGEMENT** > **AUTO POWER OFF**. To reactivate the camera after it has turned off automatically, press the shutter button halfway or turn the **ON/OFF** switch to **OFF** and then back to **ON**.

Checking the Battery Level

After turning the camera on, check the battery level in the display.

Battery level is shown as follows:



Indicator	Description
	Battery partially discharged.
	Battery about 80% full.
	Battery about 60% full.
	Battery about 40% full.
	Battery about 20% full.
(red)	Low battery. Charge as soon as possible.
(blinks red)	Battery exhausted. Turn camera off and recharge battery.

Basic Setup

When you turn the camera on for the first time, you can choose a language and set the camera clock. Follow the steps below when turning the camera on for the first time.

1 Turn the camera on.

A language-selection dialog will be displayed.



2 Choose a language.

Highlight a language and press **MENU/OK**.



3 Choose a time zone.

When prompted, choose a time zone and turn daylight savings time on or off using the focus stick (focus lever), then highlight **SET** and press **MENU/OK**.



To skip this step, press **DISP/BACK**.

4 Set the clock.

Press **MENU/OK** to proceed to the next step.



5 View information on the smartphone app.

- The camera will display a QR code you can scan with your smartphone to open a website where you can download the smartphone app.
- Press **MENU/OK** to proceed to the next step.



Use the smartphone app to download pictures from the camera or control the camera remotely (📖 256).

6 Choose an **AUTO POWER OFF TEMP**.

- The selected setting determines the temperature at which the camera will turn off automatically.
- Press **MENU/OK** to exit to the shooting display.



7 Format the memory card (📖 290).

Format memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device.

If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.

Choosing a Different Language

To change the language:

1. **Display language options.**
   Select **USER SETTING** > **言語/LANG.**.
2. **Choose a language.**
   Highlight the desired option and press **MENU/OK**.

Changing the Time and Date

To set the camera clock:

1. **Display DATE/TIME options.**
   Select **USER SETTING** > **DATE/TIME**.
2. **Set the clock.**
   Press the focus stick (focus lever) left or right to highlight the year, month, day, hour, or minute and press up or down to change. Press **MENU/OK** to set the clock.

3 Basic Photography and Playback

Taking Photographs

This section explains basic photography.

1 Rotate the auto mode selector lever to **AUTO** to view the shooting display for AUTO mode.



The camera will display the type of scene and focus target detected.



In AUTO (**AUTO**) mode, the camera continuously adjusts focus and searches for eyes, increasing the drain on the battery; in addition, the sound of the camera focusing may be audible.

2 **Ready the camera.**

Hold the camera steady with both hands—shaking or unsteady hands can blur your shots.



To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and AF-assist illuminator.



3 Frame the picture.

Lenses with Zoom Rings

Use the zoom ring to frame the picture in the display. Rotate the ring left to zoom out, right to zoom in.



4 Focus.

Press the shutter button halfway to focus.



Focus indicator

Focus frame

- **If the camera is able to focus,** the focus frame and focus indicator will glow green.
- **If the camera is unable to focus**, the focus frame will turn red, **! AF** will be displayed, and the focus indicator will blink white.

- If the subject is poorly lit, the AF-assist illuminator may light to assist the focus operation.
- Focus and exposure will lock when the shutter button is pressed halfway. Focus and exposure remain locked while the button is kept in this position (AF/AE lock).
- The camera will focus on subjects at any distance in the macro and standard focus ranges for the lens.

5 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.

Viewing Pictures

Pictures can be viewed in the viewfinder or LCD monitor.

To view pictures full frame, press ▶.



Additional pictures can be viewed by pressing the focus stick (focus lever) left or right or rotating the front command dial. Press the focus stick or rotate the dial right to view pictures in the order recorded, left to view pictures in reverse order. Keep the focus stick pressed to scroll rapidly to the desired frame.

Pictures taken using other cameras are marked with a 🎁 ("gift image") icon to warn that they may not display correctly and that playback zoom may not be available.

HDMI Output

Camera shooting and playback displays can be output to HDMI devices.

Connecting to HDMI Devices

Connect the camera to TVs or other HDMI devices using a third-party HDMI cable.

1. Turn the camera off.
2. Connect the cable as shown below.



3. Configure the device for HDMI input as described in the documentation supplied with the device.
4. Turn the camera on. The contents of the camera display will be shown on the HDMI device. The camera display turns off in playback mode (📖 56).

- Making sure the connectors are fully inserted.
- Use an HDMI cable no more than 1.5 m (4.9 ft.) long.

Shooting

Display live view or movie footage on a TV or save it to an external recorder that supports HDMI input.

Playback

To start playback, press the camera ▶ button. The camera monitor turns off and pictures and movies are output to the HDMI device. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.

Some televisions may briefly display a black screen when movie playback begins.

Deleting Pictures

Use the 🗑 button to delete pictures.

Deleted pictures cannot be recovered. Protect important pictures or copy them to a computer or other storage device before proceeding.

1 With a picture displayed full frame, press the 🗑 button and select **FRAME**.



2 Press the focus stick (focus lever) left or right to scroll through pictures and press **MENU/OK** to delete (a confirmation dialog is not displayed). Repeat to delete additional pictures.

- Protected pictures cannot be deleted. Remove protection from any pictures you wish to delete (📖 240).
- Pictures can also be deleted from the menus using the **PLAY BACK MENU** > **ERASE** option (📖 236).

MEMO

4 Movie Recording and Playback

Recording Movies

This section describes how to film movies in auto mode.

1 Press the **DRIVE** button to display the drive mode options and select **MOVIE**.



2 Rotate the auto mode selector lever to **AUTO**.



3 Press the shutter button all the way down.
Recording will start.



- A recording indicator (◉) is displayed while recording is in progress.
- The borders of the display turn red during movie recording, green during high-speed recording.
- The time remaining is shown by a countdown display, while another display counts up to show the recording time.

4 Press the button again to end recording. Recording ends automatically when the maximum length is reached or the memory card is full.

- Sound is recorded via the built-in microphone or an optional external microphone. Do not cover the microphone during recording.
- Note that the microphone may pick up lens noise and other sounds made by the camera during recording.
- Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not indicate a malfunction.

- To maximize recording time:
  - keep the camera out of direct sunlight as much as possible, and
  - turn the camera off any time it is not in use.
- To monitor audio with headphones during recording, you will need to convert the USB connector to an audio jack using the supplied headphone adapter.
- The indicator lamp lights while recording is in progress (the **MOVIE SETTING** > **TALLY LIGHT** option can be used to choose the lamp—indicator or AF-assist—that lights during movie recording and whether the lamp blinks or remains steady). During recording, you can change exposure compensation by up to ±2 EV and adjust zoom using the zoom ring on the lens (if available).
- To prevent the borders of the display changing color during movie recording, select **OFF** for **MOVIE SETTING** > **REC FRAME INDICATOR**.
- While recording is in progress, you can:
  - Refocus using any of the following methods (when the auto mode selector lever is in ●):
    - Press the shutter button halfway
    - Press a function button to which **AF-ON** is assigned
    - Use touch screen controls
  - Adjust sensitivity by pressing the button to which **ISO** has been assigned (when the auto mode selector lever is in ●)
  - Display a histogram or artificial horizon by pressing the button to which **HISTOGRAM** or **ELECTRONIC LEVEL SWITCH** has been assigned
- Recording may be unavailable at some settings, while in other cases settings may not apply during recording.
- To choose the focus area for movie recording, select **AF/MF SETTING** > **FOCUS AREA** and use the focus stick (focus lever) and rear command dial (📖 87).

Temperature Warnings

The camera automatically turns off to protect itself when its temperature or the temperature of the battery rises. If a temperature warning is displayed, image noise may increase. Turn the camera off and wait for it to cool before turning it on again.

Using an External Microphone

External microphones can be used with this camera. Use external microphones that connect using jacks 2.5 mm in diameter. For a microphone that requires plug-in power, use a microphone with an operating voltage of 2 V or less. See the microphone manual for details.



Adjusting Movie Settings

Movie settings can be adjusted from the movie menus or using the **MOVIE SETTING** item in the photo menus (📖 26).

- Use the **MOVIE SETTING** item in the photo menus to quickly adjust settings when recording movies via a button to which **MOVIE RECORDING RELEASE** has been assigned (📖 187).
- Use the movie menus to adjust settings when recording movies via the shutter button after choosing **MOVIE** in the drive mode options (📖 191).
- Settings such as frame rate and frame size can be adjusted using **MOVIE MODE**.
- Use **MEDIA REC SETTING** for such tasks as choosing the file type, bit rate, and destination.
- When the auto mode selector lever is in ●, focus mode for movie recording can be selected using the focus mode selector. Regardless of the option selected, the camera will automatically switch to focus mode **C** (continuous AF) when **FACE DETECTION ON** or **SUBJECT DETECTION ON** is chosen for **AF/MF SETTING** > **FACE/EYE DETECTION SETTING** or **SUBJECT DETECTION SETTING**. Note, however, that choosing focus mode **M** when **FACE DETECTION ON** or **SUBJECT DETECTION ON** is selected disables face and subject detection.

- Changes made using the **MOVIE SETTING** item in the photo menus also apply to the movie menus. Changes made in one set of menus automatically apply in the other.
- The type of memory card supported varies with the option select for **MOVIE SETTING** > **MEDIA REC SETTING**.
  Movies with a bit rate of 100 or 200 Mbps can be recorded to cards with a Video Speed Class of V30 or better.

Depth of Field

To soften backgrounds, set aperture as wide as possible. Aperture can be adjusted manually at settings other than **A**.

Viewing Movies

View movies on the camera.

Any movie selected after the ▶ button is pressed to begin playback will be indicated by a 🎬 icon. Press the focus stick (focus lever) down to start movie playback.



The following operations can be performed while a movie is displayed:



Focus stick (focus lever)	Full-frame playback	Playback in progress (▶)	Playback paused (⏸)
Up	View photo information	End playback	
Down	Start playback	Pause playback	Start/resume playback
Left/right	View other pictures	Adjust speed	Single frame rewind/ advance

Progress is shown in the display during playback.



Do not cover the speaker during playback.

- Press **MENU/OK** to pause playback and display volume controls. Press the focus stick (focus lever) up or down to adjust the volume; press **MENU/OK** again to resume playback. Volume can also be adjusted using **SOUND SET-UP** > **PLAYBACK VOLUME**.
- To listen to audio with headphones, you will need to convert the USB connector to an audio jack using the supplied headphone adapter.
- To view movies on a television connected via HDMI instead of in the camera monitor, press the ▶ button (📖 55).

Playback Speed

Press the focus stick (focus lever) left or right to adjust playback speed during playback. Speed is shown by the number of arrows (▶ or ◀).

Arrows

MEMO

5 Taking Photographs

Choosing a Shooting Mode

Modes **P**, **S**, **A**, and **M** can be selected via adjustments to shutter speed and/or aperture. In auto mode (**AUTO**), you can let the camera automatically recognize the scene and the subject to adjust settings, or you can choose the scene yourself.

AUTO (AUTO)

The camera automatically detects the subject and adjusts focus and chooses a scene mode appropriately.

Rotate the auto mode selector lever to **AUTO** to view the shooting display for AUTO mode.



The camera automatically displays icons showing the selected scene and the type of subject selected for focus.



Icon	Description	
Scene	• : LANDSCAPE • : NIGHT • : NIGHT (TRIPOD) • : MACRO • : SUNSET • : SKY • : GREENERY	• : PORTRAIT • : BACKLIT PORTRAIT • : MOVING OBJECT • : PORTRAIT&MOTION • : BACKLIT PORTRAIT&MOTION
Subject	• : PORTRAIT • : ANIMAL • : BIRD • : AUTOMOBILE	• : MOTORCYCLE&BIKE • : AIRPLANE • : TRAIN

- The mode selected may vary with shooting conditions. The camera may also choose different modes for the same scene depending on shooting conditions. If the mode chosen by the camera does not match the actual scene, you can choose a different mode.
- The additional processing time required in some scene modes may increase save times.

No icon will be displayed if the camera is unable to determine the type of scene.

Choosing a Scene Mode

After rotating the auto mode selector lever to **AUTO**, you can rotate the front command dial to choose from the scene modes listed below, optimizing camera settings for the selected subject type.

Scene	Description
AUTO	The camera automatically optimizes settings to suit the scene and subject.
PORTRAIT	Choose for portraits.
PORTRAIT ENHANCER	Processes portraits to give the subject a smooth, natural-looking complexion.
LANDSCAPE	Choose for daylight shots of buildings and landscapes.
SPORT	Choose when photographing moving subjects.
NIGHT	Choose for poorly lit twilight or night scenes.
NIGHT (TRIPOD)	Choose this mode for slow shutter speeds when shooting at night.
FIREWORKS	Slow shutter speeds are used to capture the expanding burst of light from a firework.
SUNSET	Choose this mode to record the vivid colors in sunrises and sunsets.
SNOW	Choose for crisp, clear shots that capture the brightness of scenes dominated by shining white snow.
BEACH	Choose for crisp, clear shots that capture the brightness of sunlit beaches.
UNDERWATER	Reduces the blue cast typically associated with underwater lighting.
PARTY	Capture indoor background lighting under low-light conditions.
FLOWER	Effective for taking more vivid shots of flowers.
TEXT	Take clear pictures of text or drawings in print.

- You can also choose the scene mode via **SHOOTING SETTING** > **AUTO MODE SETTING**.
- When **FIREWORKS** is selected, you can use the rear command dial to choose a shutter speed.

Mode P: Program AE

Let the camera choose shutter speed and aperture for optimal exposure. Other values that produce the same exposure can be selected with program shift.

1 Rotate the auto mode selector lever to ●.



2 Slide the lens aperture mode switch to **A**.



3 Rotate the shutter speed dial to **A**.



P will appear in the display.



- If the subject is outside the metering range of the camera, the shutter speed and aperture displays will show "– – –".
- If the lens is not equipped with an aperture ring, select **AUTO** for **F BUTTON/DIAL SETTING** > **APERTURE SETTING**.

Program Shift

If desired, you can rotate the rear command dial to select other combinations of shutter speed and aperture without altering exposure (program shift).



Program shift is not available in any of the following circumstances:
- When **TTL** is selected for **FLASH SETTING** > **FLASH FUNCTION SETTING**
- When an auto option is selected for **IQ IMAGE QUALITY SETTING** > **DYNAMIC RANGE**
- In movie mode

When the camera is turned off, program shift is canceled.

Mode S: Shutter-Priority AE

Choose a shutter speed and let the camera adjust aperture for optimal exposure.

1 Rotate the auto mode selector lever to ●.



2 Slide the lens aperture mode switch to **A**.



3 Rotate the shutter speed dial to select a shutter speed.



S will appear in the display.



- If the correct exposure cannot be achieved at the selected shutter speed, aperture will be displayed in red.
- If the subject is outside the metering range of the camera, the aperture display will show "– – –".
- If the lens is not equipped with an aperture ring, select **AUTO** for **BUTTON/DIAL SETTING** > **APERTURE SETTING**.

- Shutter speed can also be adjusted in increments of ⅓ EV by rotating the rear command dial.
- Shutter speed can be adjusted while the shutter button is pressed halfway.
- At shutter speeds slower than 1 second, a count-down timer will be displayed while the exposure is in progress.
- To reduce "noise" (mottling) in long time-exposures, select **ON** for **IMAGE QUALITY SETTING** > **LONG EXPOSURE NR**. Note that this may increase the time needed to record images after shooting.
- The picture will go out of focus if the camera is moved during a long time-exposure; use of a tripod is recommended.
- The roles played by the rear command dial can be changed using **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.

Time (T)

Choose a shutter speed of **T** (time) for long time-exposures. Use of a tripod is recommended to prevent the camera moving during the exposure.

1 Set shutter speed to **T**.



2 Rotate the rear command dial to choose a shutter speed.



3 Press the shutter button all the way down to take a picture at the selected shutter speed. At speeds of 1 s or slower, a count-down timer will be displayed while the exposure is in progress.

- To reduce "noise" (mottling) in long time-exposures, select **ON** for **IMAGE QUALITY SETTING** > **LONG EXPOSURE NR**. Note that this may increase the time needed to record images after shooting.
- A remote release can be used for long time-exposures (📖 81).

Mode A: Aperture-Priority AE

Choose an aperture and let the camera adjust shutter speed for optimal exposure.

1 Rotate the auto mode selector lever to ●.



2 Rotate the shutter speed dial to **A**.



3 Slide the lens aperture mode switch to .



A will appear in the display.

4 Rotate the lens aperture ring to choose an aperture.

- If the lens is not equipped with an aperture ring or if the aperture ring is in the **A** position, aperture can be adjusted by rotating the front command dial.
- The roles played by the front command dial can be changed using **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.

- If the correct exposure cannot be achieved at the selected aperture, shutter speed will be displayed in red.
- If the subject is outside the metering range of the camera, the shutter speed display will show "– – –".

Aperture can be adjusted even while the shutter button is pressed halfway.

Previewing Depth of Field

When **PREVIEW DEPTH OF FIELD** is assigned to a function button, pressing the button displays a icon and stops aperture down to the selected setting, allowing depth of field to be previewed in the display (📖 339).



Mode M: Manual Exposure

In manual mode, the user controls both shutter speed and aperture. Shots can be deliberately overexposed (brighter) or underexposed (darker), opening the door for a variety of individual creative expression. The amount the picture would be under- or over-exposed at current settings is shown by the exposure indicator; adjust shutter speed and aperture until the desired exposure is reached.

---

1 Rotate the auto mode selector lever to ●.



2 Slide the lens aperture mode switch to .



3 Rotate the shutter speed dial to select a shutter speed other than **A**.



M will appear in the display.

4 Rotate the shutter speed dial to choose a shutter speed and the lens aperture ring to choose an aperture.

- The manual exposure display includes an exposure indicator that shows the amount the picture would be under- or over-exposed at current settings.
- If the lens is not equipped with an aperture ring or if the aperture ring is in the **A** position, aperture can be adjusted by rotating the front command dial.
- The roles played by the front command dial can be changed using **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.

Bulb (B)

Choose a shutter speed of **B** (bulb) for long time-exposures in which you open and close the shutter manually. Use of a tripod is recommended to prevent the camera moving during the exposure.

1 Set shutter speed to **B**.



2 Press the shutter button all the way down.

- The shutter will remain open for up to 60 minutes while the shutter button is pressed.
- The display shows the time elapsed since the exposure started.
- Releasing the shutter button closes the shutter, ending the exposure. Processing will begin, and the camera will display the processing time remaining.

Bulb photography is not available in drive modes other than **STILL IMAGE** or multiple exposure or when the electronic shutter is selected for **SHOOTING SETTING** > **SHUTTER TYPE**.

- Selecting an aperture of **A** fixes shutter speed at 30 s.
- To reduce "noise" (mottling) in long time-exposures, select **ON** for **IMAGE QUALITY SETTING** > **LONG EXPOSURE NR**. Note that this may increase the time needed to record images after shooting.

Using a Remote Release

A remote release can be used for long time-exposures. When using an optional RR-100 remote release or an electronic release from third-party suppliers, connect it to the camera's microphone/remote release connector.



Exposure Preview

To preview exposure in the LCD monitor, select **PREVIEW EXP./WB** for **SCREEN SET-UP** > **PREVIEW EXP./WB IN MANUAL MODE**.

Select an option other than **PREVIEW EXP./WB** when using the flash or on other occasions on which exposure may change when the picture is taken.

Autofocus

Take pictures using autofocus.

1 Rotate the focus mode selector to **S** or **C** (📖 83).



2 Use **AF/MF SETTING** > **AF MODE** to choose an AF mode (📖 85).

3 Select **AF/MF SETTING** > **FOCUS AREA** and choose the position and size of the focus frame (📖 87).



4 Take pictures.

Focus Mode

Use the focus mode selector to choose how the camera focuses.



Choose from the following options:

Mode	Description
S (AF-S)	**Single AF**: Focus locks while the shutter button is pressed halfway. Choose for stationary subjects.
C (AF-C)	**Continuous AF**: Focus is continually adjusted to reflect changes in the distance to the subject while the shutter button is pressed halfway. Use for subjects that are in motion.
M (manual)	**Manual**: Focus manually using the lens focus ring. Choose for manual control of focus or in situations in which the camera is unable to focus using autofocus (📖 91).

- Regardless of the option selected, manual focus will be used when the lens is in manual focus mode.
- If **ON** is selected for **AF/MF SETTING** > **PRE-AF**, focus will be adjusted continuously in modes **S** and **C** even when the shutter button is not pressed.

The Focus Indicator

Focus status is shown by the focus indicator.



Focus indicator

Focus indicator	Focus status
( )	Camera focusing.
● (lights green)	Subject in focus; focus locked (focus mode **S**).
(●) (lights green)	Subject in focus (focus mode **C**). Focus is automatically adjusted for changes in distance to subject.
○ (blinks white)	Camera unable to focus.
MF	Manual focus (focus mode **M**).

Autofocus Options (AF Mode)

Focus can be adapted to a variety of subjects by changing the combination of settings selected for focus and AF modes.

1. Press **MENU/OK** and go to the shooting menu.
2. Select **AF/MF SETTING** > **AF MODE**.
3. Choose an AF mode.

How the camera focuses depends on the focus mode.

Focus Mode S (AF-S)

Option	Description	Sample image
SINGLE POINT	Camera focuses on subject in selected focus point. Use for pinpoint focus on selected subject.	
ZONE	Camera focuses on subject in selected focus zone. Focus zones include multiple focus points, making it easier to focus on subjects in motion.	
WIDE	Camera focuses automatically on high-contrast subjects; display shows areas in focus.	
ALL	Rotate the rear command dial in the focus-point selection display (📖 87, 89) to cycle through the AF modes selected for **AF/MF SETTING** > **AF MODE ALL SETTING**.	

Focus Mode C (AF-C)

Option	Description	Sample image
SINGLE POINT	Focus tracks subject at selected focus point. Use for subjects moving toward or away from camera.	
ZONE	Camera tracks focus in selected focus zone. Use for subjects that are moving fairly predictably.	
TRACKING	Focus tracks subjects moving through wide area of frame.	
ALL	Rotate the rear command dial in the focus-point selection display (📖 87, 89) to cycle through the AF modes selected for **AF/MF SETTING** > **AF MODE ALL SETTING**.	

Focus-Point Selection

Viewing the Focus-Point Display

1. Press **MENU/OK** and go to the shooting menu.
2. Select **AF/MF SETTING** > **FOCUS AREA** to view the focus-point display.
3. Use the focus stick (focus lever) and rear command dial to choose a focus area.

The focus point can also be selected using touch controls (📖 28).

Selecting a Focus Point

Use the focus stick (focus lever) to choose the focus point and the rear command dial to choose the size of the focus frame. The procedure varies with the option selected for AF mode.



AF mode	Focus stick		Rear command dial	
	Tilt	Press	Rotate	Press
[•]	Select focus point	Select center focus point	Choose from 6 frame sizes	Restore original size
[⋯]				
[ ]			—	

- Manual focus-point selection is not available when [ ] **WIDE/TRACKING** is selected in focus mode **S**.
- You can also press the **DISP/BACK** button to return the focus area to the center.
- If [ALL] **ALL** is selected for AF mode, you can rotate the rear command dial in the focus-point selection display to cycle through AF modes in the following order: [•] **SINGLE POINT** (6 frame sizes), [⋯] **ZONE** (3 frame sizes), **ZONE CUSTOM 1**, **ZONE CUSTOM 2**, **ZONE CUSTOM 3**, and [ ] **WIDE/TRACKING**. Select **AF/MF SETTING** > **AF MODE ALL SETTING** to choose the AF modes available.

The Focus-Point Display

The focus-point display varies with the option selected for AF mode.

- Focus frames are shown by small squares (□), focus zones by the large squares.
- The dimensions of **ZONE CUSTOM 1**, **ZONE CUSTOM 2**, and **ZONE CUSTOM 3** can be selected using **AF/MF SETTING** > **ZONE CUSTOM SETTING**.

AF mode		
SINGLE POINT	**ZONE**	**WIDE/TRACKING**
		
Number of points available can be selected using **AF/MF SETTING** > **NUMBER OF FOCUS POINTS**.	Choose from zones with 7 × 7, 5 × 5, or 3 × 3 focus points or from **ZONE CUSTOM 1**, **ZONE CUSTOM 2**, and **ZONE CUSTOM 3**.	Position focus frame over subject you want to track using continuous AF.

Autofocus

Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below.

- Very shiny subjects such as mirrors or car bodies.
- Subjects photographed through a window or other reflective object.
- Dark subjects and subjects that absorb rather than reflect light, such as hair or fur.
- Insubstantial subjects, such as smoke or flame.
- Subjects that show little contrast with the background.
- Subjects positioned in front of or behind a high-contrast object that is also in the focus frame (for example, a subject photographed against a backdrop of highly contrasting elements).

Checking Focus

To zoom in on the current focus area for precise focus, press the center of the rear command dial. Use the focus stick (focus lever) to choose another focus area. Press the center of the rear command dial again to cancel zoom.





Normal display *Focus zoom*

- In focus mode **S**, zoom can be adjusted by rotating the rear command dial.
- The focus stick can be used to select the focus area while zoom is in effect.
- In focus mode **S**, select ⊡ **SINGLE POINT** for **AF MODE**.
- Focus zoom is not available in focus mode **C** or when **AF/MF SETTING** > **PRE-AF** is on.
- Use **BUTTON/DIAL SETTING** > **FUNCTION (Fn) SETTING** to change the function performed by the center of the rear command dial. You can also assign its default function to other controls (📖 339).

Manual Focus

Adjust focus manually.

1 Rotate the focus mode selector to **M**.



MF will appear in the display.



2 Focus manually using the lens focus ring. Rotate the ring left to reduce the focus distance, right to increase.



3 Take pictures.

- Use **BUTTON/DIAL SETTING** > **LENS ZOOM/FOCUS SETTING** > **FOCUS RING ROTATE** to reverse the direction of rotation of the focus ring.
- Regardless of the option selected, manual focus will be used when the lens is in manual focus mode.

Quick Focus

- To use autofocus to focus on the subject in the selected focus area, press the button to which focus lock or **AF-ON** has been assigned (the size of the focus area can be chosen with the rear command dial).
- In manual focus mode, you can use this feature to quickly focus on a chosen subject using either single or continuous AF according to the option chosen for **AF/MF SETTING** > **INSTANT AF SETTING**.

Checking Focus

A variety of options are available for checking focus in manual focus mode.

The Manual Focus Indicator

The white line indicates the distance to the subject in the focus area (in meters or feet according to the option selected for **SCREEN SET-UP** > **FOCUS SCALE UNITS** in the setup menu), the blue bar the depth of field, or in other words the distance in front of and behind the subject that appears to be in focus.



- If both **AF DISTANCE INDICATOR** and **MF DISTANCE INDICATOR** are selected in the **SCREEN SET-UP** > **DISP. CUSTOM SETTING** list, the manual focus indicator can also be viewed using the depth-of-field indicator in the standard display. Use the **DISP/BACK** button to display standard indicators.
- Use the **AF/MF SETTING** > **DEPTH-OF-FIELD SCALE** option to choose how depth of field is displayed. Choose **FILM FORMAT BASIS** to help you make practical assessments of depth of field for pictures that will be viewed as prints and the like, **PIXEL BASIS** to help you assess depth of field for pictures that will be viewed at high resolutions on computers or other electronic displays.

Focus Zoom

If **ON** is selected for **AF/MF SETTING** > **FOCUS CHECK**, the camera will automatically zoom in on the selected focus area when the focus ring is rotated. Press the center of the rear command dial to exit zoom.

While zoom is in effect, the focus stick can be used to select the focus area and zoom can be adjusted by rotating the rear command dial. However, a focus area cannot be moved or zoom cannot be adjusted when **DIGITAL SPLIT IMAGE** or **DIGITAL MICROPRISM** is selected for MF assist.

MF Assist

Use **AF/MF SETTING** > **MF ASSIST** (📖 166) in the photo menus or **AF/MF SETTING** > **MF ASSIST** (📖 213) in the movie menus to choose a focus check option.

- The focus check options for movies differ from those for still photography.
- The **MF ASSIST** menu can be displayed by pressing and holding the center of the rear command dial.

- **DIGITAL SPLIT IMAGE**: Displays a split image in the center of the frame. Frame the subject in the split-image area and rotate the focus ring until the four parts of the split image are correctly aligned.



- **DIGITAL MICROPRISM**: A grid pattern that emphasizes blur is displayed when the subject is out of focus, disappearing to be replaced by a sharp image when the subject is in focus.



- **FOCUS PEAK HIGHLIGHT**: Highlights high-contrast outlines. Rotate the focus ring until the subject is highlighted.



- **FOCUS METER**: A meter is displayed below the focus point indicating whether focus is in front of or behind the subject. The needle swings left when focus is in front of the subject and right when it is behind the subject. Adjust focus so the needle is pointing straight up.

The display reverses when **CCW** is selected for **BUTTON/DIAL SETTING** > **LENS ZOOM/FOCUS SETTING** > **FOCUS RING ROTATE**.



- **FOCUS MAP**: Square indicators are displayed in focus frames to indicate points that are in focus and not in focus by color. A green indicator is displayed on a point in focus on the subject and a point the same distance as the subject. A yellow indicator is displayed on a point in front of the focus position, and a blue indicator is displayed on a point behind the focus position.

- You can change the indicator colors to monochrome using **AF/MF SETTING** > **MF ASSIST** in the movie menus. With this setting, a white indicator is displayed on a point in front of the focus position, and a black indicator is displayed on a point behind the focus position.
- Indicators may not be displayed for subjects that are difficult to capture with auto focus (📖 89).

Sensitivity

Adjust the camera's sensitivity to light.

Set sensitivity using **SHOOTING SETTING** > **ISO**.

Option	Description
AUTO1 **AUTO2** **AUTO3**	Sensitivity is automatically adjusted in response to shooting conditions according to combination of standard and maximum sensitivity and minimum shutter speed chosen for **SHOOTING SETTING** > **ISO**. Choose from **AUTO1**, **AUTO2**, and **AUTO3** (📖 97).
160–12800	Adjust sensitivity manually. Selected value is shown in display.
L (80/100/125) **H** (25600/51200)	Choose for special situations. Note that mottling may appear in pictures taken at **H**, while **L** reduces dynamic range.

- Sensitivity is not reset when the camera is turned off.
- If desired, you can use **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING** to configure the camera so that ISO sensitivity can be adjusted using the front or rear command dial.

Adjusting Sensitivity

High values can be used to reduce blur when lighting is poor, while lower values allow slower shutter speeds or wider apertures in bright light; note, however, that mottling may appear in pictures taken at high sensitivities.

AUTO

Choose the base sensitivity, maximum sensitivity, and minimum shutter speed for **AUTO1**, **AUTO2**, and **AUTO3**.

Item	Options	Default		
		AUTO1	AUTO2	AUTO3
DEFAULT SENSITIVITY	160–12800	160		
MAX. SENSITIVITY	400–12800	800	3200	12800
MIN. SHUTTER SPEED	1/4000–30 SEC, AUTO	AUTO		

The camera automatically chooses a sensitivity between the default and maximum values; sensitivity is only raised above the default value if the shutter speed required for optimal exposure would be slower than the value selected for **MIN. SHUTTER SPEED**.

- If the value selected for **DEFAULT SENSITIVITY** is higher than that selected for **MAX. SENSITIVITY**, **DEFAULT SENSITIVITY** will be set to the value selected for **MAX. SENSITIVITY**.
- The camera may select shutter speeds slower than **MIN. SHUTTER SPEED** if pictures would still be underexposed at the value selected for **MAX. SENSITIVITY**.
- If **AUTO** is selected for **MIN. SHUTTER SPEED**, the camera will choose the minimum shutter speed automatically. The minimum shutter speed is not affected by the option selected for image stabilization.

Metering

Choose how the camera meters exposure.

SHOOTING SETTING > **PHOTOMETRY** offers a choice of the following metering options:

The selected option will only take effect if **OFF** is selected for **FACE/EYE DETECTION SETTING** and **SUBJECT DETECTION SETTING** in the **AF/MF SETTING** menu.

Mode	Description
MULTI	The camera instantly determines exposure based on an analysis of composition, color, and brightness distribution. Recommended in most situations.
CENTER-WEIGHTED	The camera meters the entire frame but assigns the greatest weight to the area at the center.
SPOT	The camera meters lighting conditions in an area equivalent to 2% of the frame. Recommended with backlit subjects and in other cases in which the background is much brighter or darker than the main subject.
AVERAGE	Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white.

To meter the subject in the selected focus area, choose **ON** for **AF/MF SETTING** > **INTERLOCK SPOT AE & FOCUS AREA** (📖 168).

Exposure Compensation

Adjust exposure.

Rotate the exposure compensation dial.



- The amount of compensation available varies with the shooting mode.
- Exposure compensation can be previewed in the shooting display, although the display may not accurately reflect its effects if:
  - the exposure compensation amount exceeds ±3 EV,
  - R200 **200%** or R400 **400%** is selected for **DYNAMIC RANGE**, or
  - **STRONG** or **WEAK** is selected for **D RANGE PRIORITY**.

  In one of these cases, exposure compensation can still be previewed in the viewfinder or LCD monitor by pressing the shutter button halfway. In movie mode, the display may not accurately reflect the effects of exposure compensation during F-Log recording or when R200 **200%** or R400 **400%** is selected for **DYNAMIC RANGE**. An accurate preview can be obtained by selecting mode **M** and adjusting exposure directly.

C (Custom)

When the exposure compensation dial is rotated to **C**, exposure compensation can be adjusted by rotating the front command dial.





- The front command dial can be used to set exposure compensation to values between –5 and +5 EV.
- The function assigned to the front command dial can be selected by pressing the dial (📖 312).

Focus/Exposure Lock

Focus and exposure lock when the shutter button is pressed halfway.



1. Position the subject in the focus frame and press the shutter button halfway to lock focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).
2. Press the button all the way down.

Focus and exposure lock via the shutter button is only available when **ON** is selected for **BUTTON/DIAL SETTING** > **SHUTTER AF**, **SHUTTER AE**.

Other Controls

Focus and exposure can also be locked with the **AF-L** and **AE-L** buttons. At default settings, the **AF-L** button locks focus, the **AE-L** button exposure.



- While the assigned control is pressed, pressing the shutter button halfway will not end the lock.
- If **AE&AF ON/OFF SWITCH** is selected for **BUTTON/DIAL SETTING** > **AE/AF-LOCK MODE**, the lock can only be ended by pressing the control a second time.

- The focus lever (focus stick) can be used to reposition the focus point during exposure lock.
- The **AE-L** and **AF-L** buttons can be assigned other roles using **BUTTON/DIAL SETTING** > **FUNCTION (Fn) SETTING**. Exposure and focus lock can also be assigned to other buttons (339).

Bracketing

Automatically vary settings over a series of pictures.

1 Press the **DRIVE** button to display drive mode options.



2 Press the focus stick (focus lever) up or down to highlight one of the following:

Option	📖
ISO ISO BKT	104
WB WHITE BALANCE BKT	104

Option	📖
BKT Bracketing	105

3 Press the focus stick left or right to highlight the desired bracketing settings.

4 Press **MENU/OK** to select.

5 Take pictures.

ISO BKT

Select a bracketing amount (±⅓, ±⅔, or ±1) in the drive mode display. Each time the shutter is released, the camera will take a picture at the current sensitivity and process it to create two additional copies, one with sensitivity raised and the other with sensitivity lowered by the selected amount.

WHITE BALANCE BKT

Select a bracketing amount (±1, ±2, or ±3) in the drive mode display. Each time the shutter is released, the camera takes one shot and processes it to create three copies: one at the current white balanced setting, one with fine-tuning increased by the selected amount, and another with fine-tuning decreased by the selected amount.

BKT Bracketing

AE BKT

Use **SHOOTING SETTING** > **AE BKT SETTING** to choose the bracketing amount, bracketing order, and number of shots. The camera will take the specified number of shots in sequence: one using the metered value for exposure and the others over- or under-exposed by multiples of the selected bracketing amount.

Regardless of the bracketing amount, exposure will not exceed the limits of the exposure metering system.

FILM SIMULATION BKT

Each time the shutter is released, the camera takes one shot and processes it to create copies with different film simulation settings, chosen using **SHOOTING SETTING** > **FILM SIMULATION BKT**.

DYNAMIC RANGE BKT

Each time the shutter button is pressed, the camera takes three shots with different dynamic ranges: 100% for the first, 200% for the second, and 400% for the third.

While dynamic range bracketing is in effect, sensitivity will be restricted to a minimum of ISO 500; the sensitivity previously in effect is restored when bracketing ends.

FOCUS BKT

Each time the shutter button is pressed, the camera takes a series of photos, varying focus with each shot. The **SHOOTING SETTING** > **FOCUS BKT SETTING** item offers a choice of **MANUAL** and **AUTO** bracketing.

- Do not adjust zoom during shooting.
- Use of a tripod is recommended.

MANUAL

In **MANUAL** mode, you choose the following.

Option	Description
FRAMES	Choose the number of shots.
STEP	Choose the amount focus changes with each shot.
INTERVAL	Choose the interval between shots.

Focus and FRAMES/STEP

The relation between focus and the options chosen for **FRAMES** and **STEP** is shown in the illustration.



- Focus proceeds from the starting position toward infinity.
- Small **STEP** values translate to small changes in focus, larger values to larger changes.
- Regardless of the option chosen for **FRAMES**, shooting ends when focus reaches infinity.

AUTO

In **AUTO** mode, the camera calculates **FRAMES** and **STEP** automatically.

1. Select **SHOOTING SETTING** in the shooting menu, highlight **FOCUS BKT SETTING**, and press **MENU/OK**.

2. Select **AUTO** and choose an **INTERVAL**.
The view through the lens will be displayed.

3. Focus on the nearest end of the subject and press **MENU/OK**.
The selected focus distance appears as **A** on the focus distance indicator.



The same focus range can be chosen by focusing on the farthest end of the subject first.

4. Focus on the farthest end of the subject and press **DISP/BACK**.
The selected focus distance (**B**) and focus range (**A** to **B**) appear on the focus distance indicator.



Instead of pressing the **DISP/BACK** button, you can press **MENU/OK** and select **A** again.

5. Take photographs.
The camera will calculate values for **FRAMES** and **STEP** automatically. The number of frames will appear in the display.

Continuous Shooting (Burst Mode)

Capture motion in a series of pictures.

1 Press the **DRIVE** button to display drive mode options.



2 If **CH HIGH SPEED BURST** or **CL LOW SPEED BURST** is selected, the camera will take pictures continuously while the shutter-release button is pressed.

Shooting ends when the shutter button is released or the memory card is full.

- If file numbering reaches 9999 before shooting is complete, the remaining pictures will be recorded to a new folder.
- Shooting ends when the memory card is full; the camera will record all photos shot to that point. Burst shooting may not begin if the space available on the memory card is insufficient.
- Frame rates may slow as more shots are taken.
- Frame rate varies with the scene, shutter speed, sensitivity, and focus mode.
- Depending on shooting conditions, frame rates may slow or the flash may not fire.
- Recording times may increase during burst shooting.
- The choice of burst modes varies with the option selected for **SHOOTING SETTING** > **SHUTTER TYPE**.

Focus and Exposure

- Select focus mode **C** to vary focus with shot.
- To vary exposure with each shot, select **OFF** for **BUTTON/DIAL SETTING** > **SHUTTER AE**.

Depending on such factors as aperture, sensitivity, and exposure compensation, exposure may not be adjusted automatically.

HDR

Each time the shutter button is pressed, the camera takes three shots, varying exposure each time, and combines them into a single picture. The resulting photograph preserves details in highlights and shadows.

1 Press the **DRIVE** button to display the drive mode options and select **HDR**.



2 Choose the amount the brightnesses of the exposures vary.

Option	Description
HDR AUTO	Dynamic range is automatically set to a value of from 200% to 800%.
HDR200	Dynamic range is set to 200%.
HDR400	Dynamic range is set to 400%.
HDR800	Dynamic range is set to 800%.
HDR800+	Camera settings are adjusted for maximum variation in dynamic range.

3 Take photographs.
The camera will create a combined image.

- Keep the camera steady.
- The desired results may not be achieved in the subject moves or the composition or lighting changes during shooting.
- The picture will be cropped a very small amount and the resolution will drop slightly.
- Mottling may appear in pictures taken at higher values. Choose a value according to the scene.
- "Extended" sensitivity values are not supported.
- Depending on the options selected for HDR and sensitivity, pictures may not be taken at the selected shutter speed.
- The flash does not fire.

HDR images are indicated by a icon during playback.

Multiple Exposures

Create a photograph that combines multiple exposures.

1 Press the **DRIVE** button to display the drive mode options and select **MULTIPLE EXPOSURE**.



2 Choose a blend mode.

Option	Description
ADDITIVE	The camera adds the exposures together. You may need to lower exposure compensation depending on the number of shots.
AVERAGE	The camera automatically optimizes exposure for the final picture. The background in series shot without changing the composition will be optimally exposed.
LIGHT	The camera compares the exposures and chooses only the brightest pixel at each location. Colors may be mixed depending on their brightness and hue.
DARK	The camera compares the exposures and chooses only the darkest pixel at each location. Colors may be mixed depending on their brightness and hue.

3 Take the first shot.

4 Press **MENU/OK**. The first shot will be shown superimposed on the view through the lens and you will be prompted to take the second shot.



- To return to the previous step and retake the first shot, press the focus stick (focus lever) left.
- To save the first shot and exit without creating a multiple exposure, press **DISP/BACK**.

5 Take the second shot, using the first frame as a guide.



6 Press **MENU/OK**.
The combined exposures will be displayed as a guide to composing the next shot.



- To return to the previous step and retake the second shot, press the focus stick left.
- To end shooting and create a multiple exposure from the shots taken to this point, press **DISP/BACK**.

7 Make additional exposures.
Each photograph can contain up to nine exposures.

8 Press **DISP/BACK** to end shooting.
The camera will create the combined image and multiple exposure shooting will end.

When the auto mode selector lever is set to **AUTO**, either sensitivity of **AUTO1**, **AUTO2**, or **AUTO3** can be set if ISO sensitivity is assigned to the front command dial function (📖 97).

Panoramas

Follow an on-screen guide to create a panorama.

1 Press the **DRIVE** button to display the drive mode options and select **Adv.** > **PANORAMA**.



2 To select the size of the angle through which you will pan the camera while shooting, press the focus stick (focus lever) left. Highlight a size and press **MENU/OK**.

3 Press the focus stick right to view a choice of pan directions. Highlight a pan direction and press **MENU/OK**.

4 Press the shutter button all the way down to start recording. There is no need to keep the shutter button pressed during recording.

5 Pan the camera in the direction shown by the arrow. Shooting ends automatically when the camera is panned to the end of the guides and the panorama is complete.



For Best Results

- Move the camera slowly in a small circle at a steady speed
- Keep the camera parallel or at right angles to the horizon and be sure to pan only in the direction shown by the guides
- Try panning at a different speed if the desired results are not achieved
- Prop your elbows against your sides
- Use a tripod
- For best results, use a lens with a focal length of 35 mm or less (50 mm or less in 35 mm format).

- If the shutter button is pressed all the way down before the panorama is complete, shooting will end and no panorama may be recorded.
- The last part of the panorama may not be recorded if shooting ends before the panorama is complete.
- Panoramas are created from multiple frames, and the camera may in some cases be unable to stitch the frames together perfectly.
- Panoramas may be blurred if the subject is poorly lit.
- Shooting may be interrupted if the camera is panned too quickly or too slowly. Panning the camera in a direction other than that shown cancels shooting.
- The camera may in some cases record a greater or lesser angle than selected.
- The desired results may not be achieved with:
  - Moving subjects
  - Subjects close to the camera
  - Unvarying subjects such as the sky or a field of grass
  - Subjects that are in constant motion, such as waves and waterfalls
  - Subjects that undergo marked changes in brightness
- If **ON** is selected for **BUTTON/DIAL SETTING** > **SHUTTER AE**, exposure for the entire panorama is determined by the first frame.

When the auto mode selector lever is set to **AUTO**, either sensitivity of **AUTO1**, **AUTO2**, or **AUTO3** can be set if ISO sensitivity is assigned to the front command dial function (📖 97).

Viewing Panoramas

With the panorama displayed full frame, press the focus stick (focus lever) down to start panorama playback.



- In full-frame playback, you can use the rear command dial to zoom panoramas in or out.
- Panorama playback is controlled using the focus stick.

Focus stick (focus lever)	Full-frame playback	Panorama playback	Panorama playback paused
Up	—	End playback	
Down	Start playback	Pause playback	Resume playback
Left/right	View other pictures	Choose pan direction	Scroll panorama manually

Filters

Take photos with filter effects.

1 Press the **DRIVE** button to display the drive mode options and select **Adv.** > **FILTER**.



2 Choose a filter.

3 Take photographs.

When the auto mode selector lever is set to **AUTO**, either sensitivity of **AUTO1**, **AUTO2**, or **AUTO3** can be set on the front command dial (📖 97).

Filter Options

Choose from the following filters:

Filter	Description
TOY CAMERA	Choose for a retro toy camera effect.
MINIATURE	The tops and bottoms of pictures are blurred for a diorama effect.
POP COLOR	Create high-contrast images with saturated colors.
HIGH-KEY	Create bright, low-contrast images.
LOW-KEY	Create uniformly dark tones with few areas of emphasized highlights.
DYNAMIC TONE	Dynamic tone expression is used for a fantasy effect.
SOFT FOCUS	Create a look that is evenly soft throughout the whole image.
PARTIAL COLOR (RED)	Areas of the image that are the selected color are recorded in that color. All other areas of the image are recorded in black-and-white.
PARTIAL COLOR (ORANGE)	
PARTIAL COLOR (YELLOW)	
PARTIAL COLOR (GREEN)	
PARTIAL COLOR (BLUE)	
PARTIAL COLOR (PURPLE)	

Depending on the subject and camera settings, images may in some cases be grainy or vary in brightness or hue.

Flash Photography

Use the built-in flash for additional lighting when shooting at night or indoors under low light.

1 Slide the ϟ lever as shown to raise the flash.



2 Select **FLASH FUNCTION SETTING** in the **ϟ FLASH SETTING** menu. The camera will display options for the built-in flash.



Sync terminal options will be displayed if the built-in flash is lowered and either no flash unit, or an incompatible flash unit, is mounted on the hot shoe (📖 359). Raise the flash before adjusting settings.

3 Highlight items using the focus stick (focus lever) and rotate the rear command dial to change the highlighted setting (📖 122).



4 Press **DISP/BACK** to put the changes into effect.

- Depending on the distance to the subject, some lenses may cast shadows in photos taken with the flash.
- Be careful not to injure yourself on the edges of the raised flash.
- The flash will not fire at some settings, for example in panorama mode or when the electronic shutter is used.
- Choose shutter speeds slower than 1/180 s when using the flash in exposure mode **S** (shutter-priority AE) or manual (**M**).

- In TTL mode, the flash may fire several times with each shot. Do not move the camera until shooting is complete.
- The flash will not fire if **OFF** is selected for **SOUND & FLASH** in the **USER SETTING** menu.

Flash Settings

The following settings are available with the built-in flash.



Setting	Description
(1) Flash control mode	Choose from the following options: • **TTL**: TTL mode. Adjust flash compensation ((2)) and choose a flash mode ((3)). • **M**: The flash fires at the selected output ((2)) regardless of subject brightness or camera settings. Output is expressed in fractions of full power, from 1/1 to 1/64. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results. • **(primary flash)**: Choose if the flash is being used as a primary flash controlling secondly flash units, for example as part of a studio flash system. • **OFF (OFF)**: The flash does not fire.
(2) Flash compensation/ output	Adjust flash level. The options available vary with the flash control mode ((1)).

Setting	Description
③ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (**P**, **S**, **A**, or **M**) selected. • **TTL AUTO (FLASH AUTO)**: The flash fires only as required; flash level is adjusted according to subject brightness. A ⚡ icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • **TTL (STANDARD)**: The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • **TTL SLOW (SLOW SYNC.)**: Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.
④ Sync	Choose whether the flash is timed to fire immediately after the shutter opens (**FRONT/1ST CURTAIN**) or immediately before it closes (**REAR/2ND CURTAIN**). **1ST CURTAIN** is recommended in most circumstances.

Red-Eye Removal

Red-eye removal is available when **FLASH** is selected for **FLASH SETTING** > **RED EYE REMOVAL**. Red-eye removal minimizes "red-eye" caused when light from the flash is reflected from the subject's retinas.

Flash Sync Speed

The flash will synchronize with the shutter at shutter speeds of 1/180 s or slower.

Optional Flash Units from Fujifilm

The camera can be used with optional Fujifilm shoe-mounted flash units.

Third-Party Flash Units

Do not use third-party flash units that apply over 300 V to the camera hot shoe. Set the flash control mode to **M** when using a flash unit that does not support TTL flash control.

MEMO

6 The Shooting Menus

IMAGE QUALITY SETTING (Still Photography)

Adjust image quality settings for still photography.

To display image quality settings, press **MENU/OK** in the photo shooting display and select the IQ (**IMAGE QUALITY SETTING**) tab.



The options available vary with the shooting mode selected.

IMAGE SIZE

Choose the size and aspect ratio at which still pictures are recorded.

Option	Image size	Option	Image size
L 3:2	6240 × 4160	L 1:1	4160 × 4160
L 16:9	6240 × 3512		

Option	Image size	Option	Image size
M 3:2	4416 × 2944	M 1:1	2944 × 2944
M 16:9	4416 × 2488		

Option	Image size	Option	Image size
S 3:2	3120 × 2080	S 1:1	2080 × 2080
S 16:9	3120 × 1760		

Option	Image size	Option	Image size
instax mini	1568 × 2080	instax WIDE	3120 × 1984
instax SQUARE	2080 × 2080		

The following options are available in **SPORTS FINDER MODE** and when **1.25X CROP** is selected in burst mode:

Option	Image size	Option	Image size
M **3 : 2**	4992 × 3328	M **1 : 1**	3328 × 3328
M **16 : 9**	4992 × 2808		

IMAGE SIZE is not reset when the camera is turned off or another shooting mode is selected.

IMAGE QUALITY

Choose a file format and compression ratio.

Option	Description
FINE	Low compression ratios are used for higher-quality images.
NORMAL	Higher compression ratios are used to increase the number of images that can be stored.
FINE + RAW	Record both RAW and fine-quality JPEG or HEIF images.
NORMAL + RAW	Record both RAW and normal-quality JPEG or HEIF images.
RAW	Record RAW images only.

The Function Buttons

To toggle RAW image quality on or off for a single shot, assign **RAW** to a function button (📖 339). Press the button once to select the option in the right column, again to return to the original setting (left column).

Option currently selected for IMAGE QUALITY	Option selected by pressing function button to which RAW is assigned
FINE	**FINE + RAW**
NORMAL	**NORMAL + RAW**
FINE + RAW	**FINE**
NORMAL + RAW	**NORMAL**
RAW	**FINE**

RAW RECORDING

Choose whether to compress RAW images.

Option	Description
UNCOMPRESSED	RAW images are not compressed.
LOSSLESS COMPRESSED	RAW images are compressed using a reversible algorithm that reduces file size with no loss of image data. The images can be viewed in FUJIFILM RAW Converter[1], Capture One[1], RAW FILE CONVERTER EX powered by SILKYPIX[2], FUJIFILM X RAW STUDIO, or other software that supports "lossless" RAW compression. Quality is the same as **UNCOMPRESSED**, but the resulting files are anywhere from about 30 to 90 percent of their uncompressed size.
COMPRESSED	RAW images are compressed using a "lossy", non-reversible algorithm. Quality is about the same as **UNCOMPRESSED**, but the resulting files are anywhere from about 25 to 35 percent of their uncompressed size.

1 For information on when the support will be available, visit:
https://www.captureone.com/

2 For information on when the support will be available, visit:
https://fujifilm-x.com/support/compatibility/software/raw-file-converter-ex-powered-by-silkypix/

SELECT JPEG/HEIF

Choose whether pictures are recorded in JPEG or HEIF.

Option	Description
JPEG	Pictures are recorded in the widely-supported JPEG format.
HEIF	Pictures are recorded in HEIF, a format with excellent compression but limited options for viewing and sharing.

- **JPEG** is automatically selected in place of **HEIF** during multiple-exposure photography.
- **JPEG** is automatically selected in place of **HEIF** when **instax mini**, **instax WIDE**, or **instax SQUARE** is selected for **IMAGE SIZE**.
- Selecting **HEIF** disables **CLARITY** and sets **COLOR SPACE** to **sRGB**.
- HEIF pictures are stored on the memory card as files with the extension ".HIF". Before the pictures can be viewed on a computer, the extension must be changed to ".HEIC". This occurs automatically when HEIF pictures are uploaded from the camera to a computer via USB.

FILM SIMULATION DIAL SETTING

Change settings when the film simulation dial is set to **FS1**, **FS2**, **FS3**, or **ACROS**.

FS1, FS2, FS3

Assign a film simulation to **FS1**, **FS2**, and **FS3** on the film simulation dial or set whether to save the image quality settings.

Option	Description
FILM SIMULATION	Assign the film simulation you want to use to **FS1**, **FS2**, and **FS3** on the film simulation dial. Select **ACROS** or **MONOCHROME** to select a filter to be used also.
FS RECIPE	Select **ON** to separately register image quality setting items when the film simulation dial is set to **FS1**, **FS2**, or **FS3**.

When the auto mode selector lever is in the **AUTO** position, the registered image quality setting will not be applied to the images even if **ON** is selected for **FS RECIPE**.

ACROS

Set a filter when the film simulation dial is set to **ACROS**.

FILM SIMULATION

Simulate the effects of different kinds of film, including black-and-white (with or without color filters). Choose a palette according to your subject and creative intent.

Option	Description
AUTO	The camera will automatically select the best film simulation mode according to the scene. This option is available when the auto mode selector lever is set to **AUTO**.
PROVIA/STANDARD	Ideal for a wide range of subjects.
Velvia/VIVID	Vibrant reproduction, ideal for landscape and nature.
ASTIA/SOFT	Softer color and contrast for a more subdued look.
CLASSIC CHROME	Soft color and enhanced shadow contrast for a calm look.
REALA ACE	Faithful color reproduction with hard tonality suitable for various scenes.
PRO Neg. Hi	Ideal for portrait with slightly enhanced contrast.
PRO Neg. Std	Neutral tonality, best for editing images. Ideal for portrait with soft gradations and skin tones.
CLASSIC Neg.	Enhanced color with hard tonality to increase image depth.
NOSTALGIC Neg.	Amber tinted highlights and rich shadow tone for printed photo look.
ETERNA/CINEMA	Soft color and rich shadow tone suitable for film look movie.
ETERNA BLEACH BYPASS	Unique color with low saturation and high contrast. Suitable for still and movie.

Option	Description
ACROS	Shoot in Black and White In rich details with sharpness. Available with yellow (**Ye**), red (**R**), and green (**G**) filters, which deepen shades of gray corresponding to hues complementary to the selected color. • **ACROS+Ye FILTER**: Slightly enhances contrast and darkens skies. • **ACROS+R FILTER**: Enhances contrast and darkens skies considerably. • **ACROS+G FILTER**: Produces pleasing skin tones in portrait.
MONOCHROME	Shoots in black and white. Available with yellow (**Ye**), red (**R**), and green (**G**) filters, which deepen shades of gray corresponding to hues complementary to the selected color. • **MONOCHROME+Ye FILTER**: Slightly enhances contrast and darkens skies. • **MONOCHROME+R FILTER**: Enhances contrast and darkens skies considerably. • **MONOCHROME+G FILTER**: Produces pleasing skin tones in portrait.
SEPIA	Shoots in sepia tone.

- Film simulation options can be combined with tone and sharpness settings.
- Film simulation settings can also be accessed via shortcuts (📖 330).
- For more information, visit: *https://fujifilm-x.com/products/film-simulation/*

MONOCHROMATIC COLOR

Add a reddish or bluish tinge (warm or cool color cast) to the **ACROS** and **MONOCHROME** monochrome film simulations. Color can be adjusted on the **WARM**–**COOL** and **G** (Green)–**M** (Magenta) axes.



GRAIN EFFECT

Add a film grain effect.

ROUGHNESS

Option	Description
STRONG	Choose for rougher grains.
WEAK	Choose for smoother grains.
OFF	Turn the effect off.

SIZE

Option	Description
LARGE	Choose for coarser grains.
SMALL	Choose for finer grains.

COLOR CHROME EFFECT

Increase the range of tones available for rendering colors that tend to be highly saturated, such as reds, yellows, and greens.

Option	Description
STRONG	Choose for a strong effect.
WEAK	Choose for a weak effect.
OFF	Turn the effect off.

COLOR CHROME FX BLUE

Increase the range of tones available for rendering blues.

Option	Description
STRONG	Choose for a strong effect.
WEAK	Choose for a weak effect.
OFF	Turn the effect off.

WHITE BALANCE

For natural colors, choose a white balance option that matches the light source.

Option	Description
AUTO WHITE PRIORITY	White balance is adjusted automatically. Choose for whiter whites in scenes lit by incandescent bulbs.
AUTO	White balance is adjusted automatically.
AUTO AMBIENCE PRIORITY	White balance is adjusted automatically. Choose for warmer whites in scenes lit by incandescent bulbs.
CUSTOM 1	Measure a value for white balance.
CUSTOM 2	
CUSTOM 3	
COLOR TEMPERATURE	Choose a color temperature.
DAYLIGHT	For subjects in direct sunlight.
SHADE	For subjects in the shade.
FLUORESCENT LIGHT-1	Use under "daylight" fluorescent lights.
FLUORESCENT LIGHT-2	Use under "warm white" fluorescent lights.
FLUORESCENT LIGHT-3	Use under "cool white" fluorescent lights.
INCANDESCENT	Use under incandescent lighting.
UNDERWATER	Reduces the blue cast typically associated with underwater lighting.

- In conditions in which **AUTO** fails to produce the desired results—for example, under certain types of lighting or in close-ups of portrait subjects—use custom white balance or choose a white balance option suited to the light source.
- White balance is adjusted for flash lighting only in **AUTO**, **WHITE PRIORITY**, **AMBIENCE PRIORITY**, and **UNDERWATER** modes. Turn the flash off using other white balance options.
- White balance options can also be accessed via shortcuts (📖 330).

Fine-Tuning White Balance

Pressing **MENU/OK** after selecting a white balance option displays a fine-tuning dialog; use the focus stick (focus lever) to fine-tune white balance.



- To exit without fine-tuning white balance, press **DISP/BACK** after selecting a white balance option.
- You cannot tilt the focus stick diagonally when fine-tuning white balance.

Custom White Balance



Choose CUSTOM_1, CUSTOM_2, or CUSTOM_3 to adjust white balance for unusual lighting conditions using a white object as a reference (colored objects can also be used to lend photos a color cast). A white balance target will be displayed; position and size the target so that it is filled by the reference object and press the shutter button all the way down to measure white balance (to select the most recent custom value and exit without measuring white balance, press **DISP/BACK**, or press **MENU/OK** to select the most recent value and display the fine-tuning dialog).

- **If "COMPLETED !" is displayed**, press **MENU/OK** to set white balance to the measured value.
- **If "UNDER" is displayed**, raise exposure compensation and try again.
- **If "OVER" is displayed**, lower exposure compensation and try again.

K: Color Temperature

Adjust white balance to match the color temperature of the light source.

Color temperature can be adjusted to make pictures "warmer" or "colder" or deliberately produce colors that differ radically from those in real life.

1 Select K in the white balance menu. The option currently selected for color temperature will be displayed.



2 Edit the color temperature using the focus stick (focus lever) and press **MENU/OK**.
A fine-tuning dialog will be displayed.



- You can also adjust color temperature in increments of 10 K by rotating the rear command dial.
- Choose from values of from 2500 to 10000 K.
- To exit without fine-tuning white balance, press **DISP/BACK** after choosing a color temperature.

3 Highlight a fine-tuning amount using the focus stick.

4 Press **MENU/OK**.
The changes will be applied. The selected color temperature will appear in the display.



Color Temperature

Color temperature is an objective measure of the color of a light source, expressed in Kelvin (K). Light sources with a color temperature close to that of direct sunlight appear white; light sources with a lower color temperature have a yellow or red cast, while those with a higher color temperature are tinged with blue.

DYNAMIC RANGE

Adjust dynamic range. Wide dynamic ranges reduce loss of detail in highlights for more natural results with high-contrast or backlit scenes.

Option		Description
AUTO	**R100 100%**	Choose for increased contrast.
	R200 200%	
R400 400%		Reduce loss of detail in highlights.

Mottling may appear in pictures taken at higher values. Choose a value according to the scene.

- If **AUTO** is selected, the camera will automatically choose either **R100 100%** or **R200 200%** according to the subject and shooting conditions. Shutter speed and aperture will be displayed when the shutter button is pressed halfway.
- **R200 200%** is available at sensitivities of from ISO 320 to ISO 12800, **R400 400%** at sensitivities of from ISO 640 to 12800.

D RANGE PRIORITY

Reduce loss of detail in highlights and shadows for natural-looking results when photographing high-contrast scenes.

Option	Description
AUTO	Contrast is adjusted automatically in response to lighting conditions.
STRONG	Adjust dynamic range by a large amount for very high-contrast scenes.
WEAK	Adjust dynamic range by a smaller amount for moderately high-contrast scenes.
OFF	Contrast reduction off.

- **WEAK** is available at sensitivities of from ISO 320 to ISO 12800, **STRONG** at sensitivities of from ISO 640 to 12800.
- When an option other than **OFF** is selected, **TONE CURVE**, and **DYNAMIC RANGE** will be adjusted automatically; if you wish to adjust these settings manually, choose **OFF**.

TONE CURVE

With reference to a tone curve, adjust the appearance of highlights or shadows, making them harsher or softer. Choose higher values to make shadows and highlights harsher, lower values to make them softer.



Option	Description
HIGHLIGHTS	-2 to +4
SHADOWS	-2 to +4

COLOR

Adjust color density.

Options								
–4	**–3**	**–2**	**–1**	**0**	**+1**	**+2**	**+3**	**+4**

SHARPNESS

Sharpen or soften outlines.

Options								
–4	**–3**	**–2**	**–1**	**0**	**+1**	**+2**	**+3**	**+4**

HIGH ISO NR

Reduce noise in pictures taken at high sensitivities. Choose higher values to reduce noise and smooth outlines, lower values to leave outlines visible.

Options								
–4	–3	–2	–1	0	+1	+2	+3	+4

PORTRAIT ENHANCER LV

Choose the portrait enhancement level.

Options			
WEAK	MEDIUM	STRONG	OFF

CLARITY

Increase definition while altering tones in highlights and shadows as little as possible. Choose higher values for increased definition, lower values for a softer effect.

Options										
–5	–4	–3	–2	–1	0	+1	+2	+3	+4	+5

The additional processing required at settings other than 0 increases the time need to save each shot.

Clarity is adjusted automatically when the auto mode selector lever is in the **AUTO** position.

LONG EXPOSURE NR

Select **ON** to reduce mottling in long time-exposures.

Options	
ON	**OFF**

The additional processing required when **ON** is selected increases save times.

LENS MODULATION OPTIMIZER

Select **ON** to improve definition by adjusting for diffraction and the slight loss of focus at the periphery of the lens.

Options	
ON	**OFF**

COLOR SPACE

Choose the gamut of colors available for color reproduction.

Option	Description
sRGB	Recommended in most situations.
Adobe RGB	For commercial printing.

PIXEL MAPPING

Use this option if you notice bright spots in your pictures or movies.

1. Press **MENU/OK** in the shooting display and select the **IMAGE QUALITY SETTING** tab.
2. Highlight **PIXEL MAPPING** and press **MENU/OK** to perform pixel mapping.

- Results are not guaranteed.
- Be sure the battery is fully charged before beginning pixel mapping.
- Pixel mapping is not available when the camera temperature is elevated.
- Processing may take several tens of seconds.

SELECT CUSTOM SETTING

Recall settings saved to custom settings banks 1 through 7 (**CUSTOM 1** through **CUSTOM 7**) using **EDIT/SAVE CUSTOM SETTING**.

Banks			
NOTHING SELECTED	**CUSTOM 1**	**CUSTOM 2**	**CUSTOM 3**
CUSTOM 4	**CUSTOM 5**	**CUSTOM 6**	**CUSTOM 7**

If you would prefer not to recall saved settings, select **NOTHING SELECTED**.

EDIT/SAVE CUSTOM SETTING

Adjust settings as desired and save them to a custom settings bank. Saved settings can be recalled using **IMAGE QUALITY SETTING** > **SELECT CUSTOM SETTING**.

Saving Custom Settings

Create a new custom settings bank.

1. Select **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** in the shooting menu and press **MENU/OK**.

2. Highlight a destination bank for the new settings (**CREATE NEW** C1 through C7) and press **MENU/OK**.
   A confirmation dialog will be displayed.



3. Highlight **OK** and press **MENU/OK**.
   Current camera settings will be saved to the selected bank.



Editing Custom Settings

Edit existing custom settings banks.

1. Select **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** in the shooting menu and press **MENU/OK**.

   To edit settings for movie recording, navigate to **MOVIE SETTING** in the movie menus and select **EDIT/SAVE CUSTOM SETTING**.

2 Highlight the desired custom settings bank and press **MENU/OK**.



3 Highlight **EDIT/CHECK** and press **MENU/OK**.



4 The camera will display a list of shooting menu items; highlight an item you wish to edit and press **MENU/OK**.
Adjust the selected item as desired.

5 Press **MENU/OK** to save the changes and return to the shooting menu list.
Adjust additional items as desired.

If **DISABLE** is selected for **IMAGE QUALITY SETTING** > **AUTO UPDATE CUSTOM SETTING** in the photo menu or for **MOVIE SETTING** > **AUTO UPDATE CUSTOM SETTING** in the movie menu, red dots will appear next to the edited items but the changes will not be saved automatically.

- To save the changes for selected items, highlight the items in the list and press **Q**.
- To save changes for all items, return to Step 3 and select **SAVE THE CHANGES**. To cancel all changes and restore the previous settings, select **RESET THE CHANGES.**
- If you copy an item marked by a red dot, the item will be copied with the changes intact.

Copying Custom Settings

Copy custom settings from one bank to another, overwriting the settings in the destination bank. If the source bank has been renamed, the name will also be copied to the destination bank.

1 Select **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** in the shooting menu and press **MENU/OK**.

To save settings for movie recording, navigate to **MOVIE SETTING** in the movie menus and select **EDIT/SAVE CUSTOM SETTING**.

2 Highlight the source bank and press **MENU/OK**.



3 Highlight **COPY** and press **MENU/OK**.



4 Highlight the destination bank (**C1** through **C7**) and press **MENU/OK**.
A confirmation dialog will be displayed.



Any changes to custom settings in the destination bank will be overwritten.

5 Highlight **OK** and press **MENU/OK**. The selected settings will be copied to the destination bank, overwriting any existing settings.



Deleting Custom Settings

Delete settings from selected custom settings banks.

1 Select **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** in the shooting menu and press **MENU/OK**.

To save settings for movie recording, navigate to **MOVIE SETTING** in the movie menus and select **EDIT/SAVE CUSTOM SETTING**.

2 Highlight the desired custom settings bank and press **MENU/OK**.



3 Highlight **ERASE** and press **MENU/OK**. A confirmation dialog will be displayed.



4 Highlight **OK** and press **MENU/OK**. Any custom settings saved to the selected bank will be deleted.



Renaming Custom Settings Banks

Rename selected custom settings banks.

1. Select **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** in the shooting menu and press **MENU/OK**.

   To save settings for movie recording, navigate to **MOVIE SETTING** in the movie menus and select **EDIT/SAVE CUSTOM SETTING**.

2. Highlight the desired custom settings bank and press **MENU/OK**.



3. Highlight **EDIT CUSTOM NAME** and press **MENU/OK**.



4. Enter a new name for the custom settings bank and select **SET**.
   The selected bank will be renamed.

AUTO UPDATE CUSTOM SETTING

Choose whether changes to saved custom settings apply automatically.

Option	Description
ENABLE	Changes to custom settings banks **CUSTOM 1** through **CUSTOM 7** apply automatically.
DISABLE	Changes do not apply automatically. Any changes to custom settings must be applied manually (📖 145).

MOUNT ADAPTOR SETTING

Adjust settings for lenses attached via a mount adapter. The camera can store settings for multiple lenses (**LENS 1** through **LENS 6**).

- **DISTORTION CORRECTION**, **COLOR SHADING CORRECTION**, and **PERIPHERAL ILLUMINATION CORRECTION** are available with lenses connected via an M mount adapter.
- Any changes made using this item also apply in movie mode (📖 209).

FOCAL LENGTH SETTING

Enter the lens's true focal length.



DISTORTION CORRECTION

Choose from **STRONG**, **MEDIUM**, or **WEAK** options to correct **BARREL** or **PINCUSHION** distortion.



COLOR SHADING CORRECTION

Color (shading) variations between the center and edges of the frame can be adjusted separately for each corner.

To use color shading correction, follow the steps below.



1. Rotate the rear command dial to choose a corner. The selected corner is indicated by a triangle.
2. Use the focus stick (focus lever) to adjust shading until there is no visible difference in color between the selected corner and the center of the image.
   - Press the focus stick left or right to adjust colors on the cyan–red axis.
   - Press the focus stick up or down to adjust colors on the blue–yellow axis.

To determine the amount required, adjust color shading correction while taking photos of blue sky or a sheet of gray paper.

PERIPHERAL ILLUMINATION CORRECTION



Choose from values between –5 and +5. Choosing positive values increases peripheral illumination, while choosing negative values reduces peripheral illumination. Positive values are recommended for vintage lenses, negative values to create the effect of images taken with an antique lens or a pinhole camera.

To determine the amount required, adjust peripheral illumination correction while taking photos of blue sky or a sheet of gray paper.

EDIT LENS NAME

Change the lens name.

AF/MF SETTING (Still Photography)

Adjust focus settings for still photography.

To display AF/MF settings, press **MENU/OK** in the photo shooting display and select the AF/MF (**AF/MF SETTING**) tab.



The options available vary with the shooting mode selected.

FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom (📖 87).

AF MODE

Choose the AF mode for focus modes **S** and **C** (📖 85).

ZONE CUSTOM SETTING

Create custom focus zones for use when **ZONE** is selected for **AF MODE**.

Option		
ZONE CUSTOM 1	**ZONE CUSTOM 2**	**ZONE CUSTOM 3**

AF MODE ALL SETTING

Choose the focus area to be selected when **AF MODE** is **ALL**. You can match the shooting style and set only the focus area to be used. This can be set individually for when the focus mode is **S** (**AF-S**) or **C** (**AF-C**).

Option	
AF-S	**AF-C**

AF-C CUSTOM SETTINGS

Select focus-tracking options for focus mode **C**. Choose from Sets 1–5 according to your subject or select Set 6 for custom focus-tracking options.



Option	Description
SET 1 MULTI PURPOSE	A standard tracking option that works well with the typical range of moving subjects.
SET 2 IGNORE OBSTACLES & CONTINUE TO TRACK SUBJECT	The focus system attempts to track the chosen subject. Choose with subjects that are hard to keep in the focus area or if other objects are likely to enter the focus area with the subject.
SET 3 FOR ACCELERATING/ DECELERATING SUBJECT	The focus system attempts to compensate for subject acceleration or deceleration. Choose for subjects prone to rapid changes in velocity.
SET 4 FOR SUDDENLY APPEARING SUBJECT	The focus system attempts to focus quickly on subjects entering the focus area. Choose for subjects that appear abruptly or when rapidly switching subjects.
SET 5 FOR ERRATICALLY MOVING & ACCEL./DECEL. SUBJECT	Choose for hard-to-track subjects prone not only to sudden changes in velocity but also to large movements front to back and left to right.
SET 6 CUSTOM	Adjust **TRACKING SENSITIVITY**, **SPEED TRACKING SENSITIVITY**, and **ZONE AREA SWITCHING** to suit your preferences based on the values for Sets 1–5 (📖 155, 157).

Focus Tracking Options

The individual parameters that are part of a focus tracking set are described below.

TRACKING SENSITIVITY

This parameter determines how long the camera waits to switch focus when an object enters the focus area behind or in front of the current subject. The higher the value, the longer the camera will wait.



Options				
0	1	2	3	4

- The higher the value, the longer it takes the camera to refocus when you attempt to switch subjects.
- The lower the value, the more likely the camera is to switch focus from your subject to other objects in the focus area.

SPEED TRACKING SENSITIVITY

This parameter determines how sensitive the tracking system is to changes in subject velocity. The higher the value, the greater the precision with which the system attempts to respond to sudden movement.



Options		
0	1	2

The higher the value, the more difficulty the camera will have focusing in situations in which autofocus does not perform well, such as when the subject is highly reflective or low in contrast.

ZONE AREA SWITCHING

This parameter determines the focus area given priority in zone AF.



Option	Description
FRONT	Zone AF assigns priority to the subjects closest to the camera.
AUTO	The camera locks focus on the subject at the center of the zone and then switches focus areas as necessary to track it.
CENTER	Zone AF assigns priority to subjects in the center of the zone.

This option takes effect only when **ZONE** is selected for AF mode.

Set Values

Parameter values for the different sets are listed below.

	TRACKING SENSITIVITY	SPEED TRACKING SENSITIVITY	ZONE AREA SWITCHING
SET 1	2	0	AUTO
SET 2	3	0	CENTER
SET 3	2	2	AUTO
SET 4	0	1	FRONT
SET 5	3	2	AUTO

Custom Focus Tracking Options

Follow the steps below to adjust settings for Set 6.

1 Select **AF-C CUSTOM SETTINGS** > **SET 6 CUSTOM**.



2 Highlight items using the focus stick (focus lever) and rotate the front command dial to change. To reset settings to their original values, press 🗑.

3 Press **DISP/BACK** when settings are complete.

STORE AF MODE BY ORIENTATION

Choose whether the AF mode used when the camera is in portrait orientation is stored separately from that used when the camera is in landscape orientation.

Option	Description
OFF	The same settings are used in both orientations.
FOCUS AREA ONLY	The focus area for each orientation can be selected separately.
ON	The focus mode and focus area can be selected separately.

AF POINT DISPLAY

Choose whether individual focus frames are displayed when **ZONE** or **WIDE/TRACKING** is selected for **AF/MF SETTING** > **AF MODE**.

Options	
ON	**OFF**

WRAP FOCUS POINT

Choose whether focus-area selection is bounded by the borders of the display or "wraps around" from one edge of the display to another.

Option	Description
ENABLE	Focus-area selection "wraps around" from one edge of the display to another.
DISABLE	Focus-area selection is bounded by the borders of the display.

NUMBER OF FOCUS POINTS

Choose the number of focus points available for focus-point selection in manual focus mode or when **SINGLE POINT** is selected for **AF MODE**.

Option	Description
117 POINTS (9 × 13)	Choose from 117 focus points arranged in a 9- by 13-point grid.
425 POINTS (17 × 25)	Choose from 425 focus points arranged in a 17- by 25-point grid.

PRE-AF

If **ON** is selected, the camera will continue to adjust focus even when the shutter button is not pressed halfway. The camera adjusts focus continuously, allowing it to focus faster when the shutter button is pressed halfway. Choosing this option helps prevent missed shots.

Options	
ON	**OFF**

Choosing **ON** increases the drain on the battery.

AF ILLUMINATOR

If **ON** is selected, the AF-assist illuminator will light to assist autofocus.

Options	
ON	**OFF**

- The camera may be unable to focus using the AF-assist illuminator in some cases.
- If the camera is unable to focus, try increasing the distance to the subject.
- Avoid shining the AF-assist illuminator directly into your subject's eyes.

FACE/EYE DETECTION SETTING

If the camera detects human faces, it will assign them priority over the background and adjust settings appropriately for portraits when setting focus and exposure. You can also choose whether the camera focuses on the left or right eye when face detection is on.

Option	Description
FACE DETECTION ON	Adjust settings for Intelligent Face Detection. You can also adjust eye detection settings. • **EYE OFF**: Intelligent Face Detection only. • **EYE AUTO**: The camera automatically chooses which eye to focus on when a face is detected. • **RIGHT EYE PRIORITY**: The camera focuses preferentially on the right eye of subjects detected using Intelligent Face Detection. • **LEFT EYE PRIORITY**: The camera focuses preferentially on the left eye of subjects detected using Intelligent Face Detection.
OFF	Intelligent Face Detection and eye priority off.

- If the subject moves as the shutter button is pressed, the face may not be in the area indicated by the green border when the picture is taken.
- In some modes, the camera may set exposure for the frame as a whole rather than the portrait subject.
- Enabling Intelligent Face Detection via **FACE DETECTION ON** automatically selects **OFF** for **SUBJECT DETECTION SETTING**.

- If **AUTO AUTO** selected for **AUTO MODE SETTING**, the camera will automatically select the face (of if eye detection is enabled, the eye) when the auto mode selector lever is in the **AUTO** position.
- A single face detected in or near the focus area will be marked with a white frame. Faces far from the focus area will not be detected.
- If multiple faces are detected in the focus area, the camera will select one automatically.
- You can choose a different subject by tapping the display to reposition the focus area. The focus stick (focus lever) can also be used if **WIDE** is selected for **AF MODE**.
- When **DIRECT AF POINT SELECTION** or **EDIT FOCUS AREA** is chosen for **BUTTON/DIAL SETTING** > **FOCUS LEVER SETTING** > **TILT**, you can also switch subjects using the focus stick (focus lever) or (during viewfinder photography) touch controls (📖 28).
- When the camera is focused on an eye, you can switch from one eye to the other using a function button to which **RIGHT/LEFT EYE SWITCH** has been assigned.
- If the selected subject leaves the frame, the camera will wait a set time for its return and consequently the white frame may sometimes appear in locations where no face is seen.
- Depending on shooting conditions, face selection may be suspended at the close of burst shooting.
- Faces can be detected with the camera in vertical or horizontal orientation.
- If the camera is unable to detect the subject's eyes because they are hidden by hair, glasses, or other objects, the camera will instead focus on faces.
- Face/eye detection options can also be accessed via shortcuts (📖 330).

SUBJECT DETECTION SETTING

Choose whether the camera prioritizes subjects of a selected type, such as animals or vehicles, when setting focus.

Option	Description
SUBJECT DETECTION ON	Select one of the subject types listed below to enable subject detection. • **ANIMAL**: The camera detects and tracks focus on dogs and cats. • **BIRD**: Camera detects and tracks focus on birds and insects. • **AUTOMOBILE**: The camera detects and tracks focus on the body or front ends of cars, primarily those of types used for motor sports. • **MOTORCYCLE&BIKE**: The camera detects and tracks focus on the riders of motorcycles and bicycles. • **AIRPLANE**: The camera detects and tracks focus on the cockpits, noses, or bodies of airplanes and drones. • **TRAIN**: The camera detects and tracks focus on the driver compartments or front ends of trains.
OFF	Subject detection off.

Enabling subject detection via **SUBJECT DETECTION ON** automatically selects **OFF** for **FACE/EYE DETECTION SETTING**.

- If **AUTO AUTO** selected for **AUTO MODE SETTING**, the camera will automatically select the subject when the auto mode selector lever is in the **AUTO** position.
- A single subject of the chosen type detected in or near the focus area will be marked with a white frame.
- If multiple subjects are detected in the focus area, the camera will select one automatically.
- You can choose a different subject by tapping the display to reposition the focus area. The focus stick (focus lever) can also be used if **WIDE** is selected for **AF MODE**.
- When **DIRECT AF POINT SELECTION** or **EDIT FOCUS AREA** is chosen for **BUTTON/DIAL SETTING** > **FOCUS LEVER SETTING** > **TILT**, you can also switch subjects using the focus stick (focus lever) or (during viewfinder photography) touch controls (📖 28).
- If the selected subject leaves the frame, the camera will wait a set time for its return and consequently the white frame may sometimes appear in locations where no subject of the chosen type is seen.
- Depending on shooting conditions, subject detection may be suspended at the close of burst shooting.
- Subjects can be detected with the camera in vertical or horizontal orientation.
- Subject detection options can also be accessed via shortcuts (📖 330).

AF+MF

If **ON** is selected and focus has been locked (whether by pressing the shutter button halfway or by other means), focus lock can be ended and focus adjusted manually by rotating the focus ring.

Options	
ON	**OFF**

- Lenses with a focus distance indicator must be set to manual focus mode (MF) before this option can be used. Selecting MF disables the focus distance indicator.
- If the lens is equipped with a focus distance indicator, set the focus ring to the center, as the camera may fail to focus if the ring is set to infinity or the minimum focus distance.

- The previously-selected focus mode will be restored if no operations are performed for a set period after the focus ring is rotated.
- **DIGITAL SPLIT IMAGE** and **DIGITAL MICROPRISM** focus assist options selected via **MF ASSIST** cannot be used.

AF + MF Focus Zoom

Selecting **ON** for **AF/MF SETTING** > **FOCUS CHECK** when **SINGLE POINT** is chosen for **AF MODE** lets you zoom in on the current focus area by rotating the focus ring. The zoom ratio can be selected using the rear command dial.

MF ASSIST

Choose how focus is displayed in manual focus mode (📖 94).

Option	Description
DIGITAL SPLIT IMAGE	Displays a black-and-white (**MONOCHROME**) or color (**COLOR**) split image in the center of the frame. Frame the subject in the split-image area and rotate the focus ring until the four parts of the split image are correctly aligned.
DIGITAL MICROPRISM	A grid pattern that emphasizes blur is displayed when the subject is out of focus, disappearing to be replaced by a sharp image when the subject is in focus.
FOCUS PEAK HIGHLIGHT	The camera heightens high-contrast outlines. Choose a color and peaking level.
OFF	Focus is displayed normally (MF assist cannot be used).

You can also choose MF assist options by holding the center of the rear command dial.

INTERLOCK MF ASSIST & FOCUS RING

If **ON** is selected, the display configured by **MF ASSIST** appears only when the focus ring was turned during manual focus mode.

Options	
ON	**OFF**

MF ASSIST ends if no operations are performed for a set period after the focus ring is rotated.

FOCUS CHECK

If **ON** is selected, the display will automatically zoom in on the selected focus area when the focus ring is rotated in manual focus mode.

Options	
ON	**OFF**

- Pressing the center of the rear command dial cancels focus zoom.
- The zoom position is centered on the current focus area and changes when the focus area is changed.

INTERLOCK SPOT AE & FOCUS AREA

Choose **ON** to meter the current focus frame when **SPOT** or **MULTI** metering is selected.

Options	
ON	**OFF**

INSTANT AF SETTING

Choose whether the camera focuses using single AF (**AF-S**) or continuous AF (**AF-C**) when a button to which focus lock or **AF-ON** is assigned is pressed in manual focus mode.

Option	Description
AF-S	The camera focuses when the button is pressed.
AF-C	The camera focuses while the button is pressed.

Any changes made using this item also apply in movie mode (📖 214).

DEPTH-OF-FIELD SCALE

Choose the basis for the depth-of-field scale.

Option	Description
PIXEL BASIS	Provides a precision reference for use when assessing depth of field for pictures that will be viewed at high resolutions on computers or other electronic displays.
FILM FORMAT BASIS	Provides a practical reference for use when assessing depth of field for pictures that will be viewed at lower resolutions, for example as prints.

Any changes made using this item also apply in movie mode (📖 214).

RELEASE/FOCUS PRIORITY

Choose how the camera behaves when the shutter button is pressed all the way down. Settings for **AF-S** and **AF-C** focus modes can be selected separately.

Option	Description
RELEASE	Shutter response is prioritized over focus. Pictures can be taken when the camera is not in focus.
FOCUS	Focus is prioritized over shutter response. Pictures can be only taken when the camera is in focus.

Regardless of the option selected, pictures can still be taken when the camera is not in focus if **ON** is selected for **AF+MF**.

AF RANGE LIMITER

Limit the range of available focus distances for increased focus speed.

Option	Description
OFF	Focus limiter disabled.
CUSTOM	Limit focus to a range of distances defined by a minimum and maximum. • **OK**: Limit focus to the selected range. • **SET**: Choose two objects and limit focus to the distance between them.
PRESET1	Limit focus to a preset range.
PRESET2	

- Choosing a focus range that includes distances shorter than the minimum focus distance of the lens disables the focus limiter.
- The values listed and displayed for the focus limiter may differ from the actual focus distance.
- The focus limiter will be disabled when **FACE/EYE DETECTION SETTING** or **SUBJECT DETECTION SETTING** is on.
- Focus range can be set independently on lenses equipped with focus range selectors. Be sure that the option selected in the camera menus overlaps with that chosen with the lens.

- The following additional operations can be performed when **CUSTOM** is selected:
  - You can tap objects in the touch screen display to choose the focus range.
  - Instead of tapping an object in the display, you can set the maximum focus distance to infinity by rotating the focus ring.
- Any changes made using this item also apply in movie mode (📖 214).

TOUCH SCREEN MODE

Choose the shooting operations performed using touch controls.

Mode	Description
TOUCH SHOOTING	Tap your subject in the display to focus and release the shutter. In burst mode, pictures will be taken while you keep your finger on the display.
AF **AF OFF**	• In focus mode **S** (AF-S), the camera focuses when you tap your subject in the display. Focus locks at the current distance until you tap the **AF OFF** icon. • In focus mode **C** (AF-C), the camera initiates focus when you tap your subject display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the **AF OFF** icon. • In manual focus mode (MF), you can tap the display to focus on the selected subject using autofocus.
AREA	Tap to select a point for focus or zoom. The focus frame will move to the selected point.
OFF	Touch screen mode off.

- The behavior of the touch screen varies with the AF mode.
- To disable touch controls and hide the touch screen mode indicator, select **OFF** for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **TOUCH SCREEN SETTING**.

Touch Controls for Focus Zoom

Different touch controls are used during focus zoom (focus check enabled).

Central Area

Tapping the center of the display performs the operations below.



Mode	Operation performed
TOUCH SHOOTING	**AF-S/MF**: Take a picture
AF	**AF-S**: AF
	MF: Instant AF
AREA	**AF-S**: AF
	MF: Instant AF
OFF	**AF-S/MF**: OFF

Other Areas

Tapping other areas simply scrolls the display, whether during still photography or movie recording and regardless of the option selected for touch screen mode.



SHOOTING SETTING (Still Photography)

Adjust shooting options for still photography.

To display shooting settings, press **MENU/OK** in the photo shooting display and select the 📷 (**SHOOTING SETTING**) tab.



The options available vary with the shooting mode selected.

AUTO MODE SETTING

Choose a scene position when the auto mode selector lever is in **AUTO** (📖 68).

SPORTS FINDER MODE

Take pictures using the crop in the center of the display. Choose this option for pictures of athletes, birds, and other moving subjects.

Option	Description
ON	Pictures are taken using a 1.25× crop, reducing the picture angle by an amount equivalent to increasing lens focal length by 1.25×; the crop is shown by a frame in the display.
OFF	The 1.25× crop is disabled.

- The **IQ IMAGE QUALITY SETTING** > **IMAGE SIZE** item in the shooting menu is fixed at **M**.
- The sports finder is not available in modes that offer an electronic shutter.

PRE-SHOT ES

To reduce the lag between your pressing the shutter button all the way down and the resulting picture being recorded to the memory card, the camera starts shooting with the electronic shutter when the shutter button is pressed halfway and saves a series shots starting just before the shutter button is pressed the rest of the way down.

Options	
ON	**OFF**

- Pre-shot photography is available only when **ES ELECTRONIC SHUTTER** is selected in **CH** (high speed burst) drive mode (📖 178).
- Flash photography is disabled.

SELF-TIMER

Choose a shutter release delay.

Option	Description
2 SEC	The shutter is released two seconds after the shutter button is pressed. Use to reduce blur caused by the camera moving when the shutter button is pressed. The self-timer lamp blinks as the timer counts down.
10 SEC	The shutter is released ten seconds after the shutter button is pressed. Use for photographs in which you wish to appear yourself. The self-timer lamp lights up and then blinks immediately before the picture is taken.
OFF	Self-timer off.

If an option other than **OFF** is selected, the timer will start when the shutter button is pressed all the way down. The display shows the number of seconds remaining until the shutter is released. To stop the timer before the picture is taken, press **DISP/BACK**.

- Stand behind the camera when using the shutter button. Standing in front of the lens can interfere with focus and exposure.
- The self-timer turns off automatically when the camera is turned off.

SAVE SELF-TIMER SETTING

If **ON** is selected, the setting chosen for **SELF-TIMER** will remain in effect after the camera is turned off.

Options	
ON	**OFF**

SELF-TIMER LAMP

If **ON** is selected, the self-timer lamp will light during self-timer photography. Select **OFF** when shooting night scenes or in other situations in which you would prefer that the lamp remain unlit.

Options	
ON	**OFF**

AE BKT SETTING

Adjust exposure bracketing settings.

Option	Description
FRAMES/STEP SETTING	Choose the number of shots in the bracketing sequence and the amount exposure is varied with each shot. • **FRAMES**: Choose the number of shots in the bracketing sequence. • **STEP**: Choose the amount exposure is varied with each shot.
1 FRAME/CONTINUOUS	• **1 FRAME**: The shots in the bracketing sequence are taken one at a time. • **CONTINUOUS**: The shots in the bracketing sequence are taken in a single burst.
SEQUENCE SETTING	Choose the order in which the shots are taken.

AE BKT SETTING can also be displayed by pressing the **Q** button when AE bracketing is selected.

FILM SIMULATION BKT

Choose the three film simulation types used for film simulation bracketing (📖 131).

FILM SIMULATION BKT can also be displayed by pressing the **Q** button when film simulation bracketing is selected.

FOCUS BKT SETTING

Choose from **AUTO** and **MANUAL** focus bracketing modes (📖 106).

FOCUS BKT SETTING can also be displayed by pressing the **Q** button when focus bracketing is selected.

PHOTOMETRY

Choose how the camera meters exposure (📖 98).

SHUTTER TYPE

Choose the shutter type. Choose the electronic shutter to mute the shutter sound.

Option	Description
MS MECHANICAL SHUTTER	Take pictures with the mechanical shutter.
ES ELECTRONIC SHUTTER	Take pictures with the electronic shutter.
EF E-FRONT CURTAIN SHUTTER	Take pictures with the electronic front curtain shutter.
M+E MECHANICAL + ELECTRONIC	The camera chooses the mechanical or electronic shutter according to shooting conditions.
EF+ M E-FRONT + MECHANICAL	The camera chooses the mechanical or electronic front curtain shutter according to shooting conditions.
EF+ M+E E-FRONT + MECHANICAL + ELECTRONIC	The camera chooses the mechanical, electronic, or electronic front curtain shutter according to shooting conditions.

If **ES ELECTRONIC SHUTTER**, **M+E MECHANICAL + ELECTRONIC**, or **EF+ M+E E-FRONT + MECHANICAL + ELECTRONIC** is selected, shutter speeds faster than 1/4000 s can be chosen by rotating the shutter speed dial to **4000** and then rotating the rear command dial.

- When using the electronic shutter, note the following:
  - Distortion may be visible in shots of moving subjects.
  - Distortion may also be visible in hand-held shots taken at high shutter speeds; use of a tripod is recommended.
  - Banding and fog may occur in shots taken under LED lights, fluorescent lights, or other flickering or erratic illumination.
  - When taking pictures with the shutter muted (📖 297), respect your subjects' image rights and right to privacy.
- When using the electronic front-curtain shutter, note the following:
  - Faster shutter speeds are more likely to result in uneven exposure and loss of resolution in out-of-focus areas of the frame.

The following restrictions apply when the electronic shutter is used:
- Sensitivity is restricted to values of ISO 160–12800.
- Long exposure noise reduction has no effect.
- The flash cannot be used.

INTERVAL TIMER SHOOTING

Configure the camera to take photos automatically at a preset interval.

1 Highlight **INTERVAL TIMER SHOOTING** in the (**SHOOTING SETTING**) tab and press **MENU/OK**.



2 Highlight **WITH IN-CAMERA TIMER** and press **MENU/OK**.
Interval-timer settings will be displayed.



If you are using a remote release with its own timer, select **WITH EXTERNAL TIMER**. You will be returned to the shooting display, where you can start interval-timer photography using the remote release.

3 Use the focus stick (focus lever) to choose the interval and number of shots. Press **MENU/OK** to proceed.

4 Use the focus stick to choose the starting time and then press **MENU/OK**. Shooting will start automatically.



Interval timer photography cannot be used at a shutter speed of "bulb" or with multiple exposure photography. In burst mode, only one picture will be taken each time the shutter is released.

- Use of a tripod is recommended.
- Be careful not to run out of battery while shooting.
- To view the pictures taken so far, press the ▶ button during interval-timer photography. To return to the shooting display, press the ▶ button again or wait until the start of the next interval.
- The display turns off between shots and lights a few seconds before the next shot is taken.
- The display can be activated at any time by pressing the shutter button.
- The indicator lamp blinks green whenever the displays are off during interval-timer photography.
- To continue shooting until the number of shots taken equals the number of exposures remaining at the time interval-timer photography started, set the number of shots to ∞.

INTERVAL TIMER SHOOTING EXPOSURE SMOOTHING

Select **ON** to automatically adjust exposure during interval-timer photography to prevent it changing dramatically between shots.

Options	
ON	**OFF**

- Large changes in subject brightness may make exposure appear erratic. We recommend that you choose shorter values for **INTERVAL TIMER SHOOTING** > **INTERVAL** with subjects that brighten or dim dramatically during shooting.
- In manual mode (mode **M**), exposure smoothing is only available if an AUTO option is selected for **ISO**.

INTERVAL PRIORITY MODE

If **ON** is selected, the camera will adjust shutter speed during interval-timer photography to ensure that exposures are not longer than the interval between photographs.

Options	
ON	**OFF**

This option takes effect only when the camera selects the shutter speed automatically.

FLICKER REDUCTION

Reduce flicker in pictures and the display when shooting under fluorescent lighting and other similar light sources.

Option	Description
ALL FRAMES	Flicker reduction is applied to all frames, continuous shooting frame rate decreases.
FIRST FRAME	Flicker measurement is taken prior to the first frame only and the same reduction amount is applied to all subsequent frames that flicker may occur.
OFF	Flicker reduction disabled.

- Flicker reduction increases the time needed to record pictures.
- **OFF** is selected for **FLICKER REDUCTION** when the electronic shutter is used.
- Flicker reduction is not available during movie recording.

FLICKERLESS S.S. SETTING

Select **ON** to allow shutter speed to be fine-tuned to reduce flicker caused by LED lighting and the like.

Options	
ON	**OFF**

This option takes effect only in modes **S** and **M**.

IS MODE

Reduce blur caused by camera shake or subject motion.

Option	Description
CONTINUOUS + MOTION	Image stabilization on. If **+ MOTION** is selected, the camera will adjust shutter speed to reduce motion blur when moving objects are detected.
CONTINUOUS	
SHOOTING + MOTION	As above, except that image stabilization is performed only when the shutter button is pressed halfway (focus mode **C** only) or the shutter is released. If **+ MOTION** is selected, the camera will adjust shutter speed to reduce motion blur when moving objects are detected.
SHOOTING ONLY	
OFF	Image stabilization off. Choose this option when using a tripod.

- **+ MOTION** has no effect when sensitivity is set to a fixed value, and may also be unavailable at some other combinations of settings. The effect may vary with lighting conditions and the speed at which the object is moving.
- The setting selected with the lens image stabilization switch, if any, takes priority over the setting chosen with **IS MODE**.
- Note that vibration or camera sounds may be noticeable as image stabilization takes effect.

ISO

Adjust the camera's sensitivity to light (📖 96).

FLASH SETTING (Still Photography)

Adjust flash-related settings for still photography.

To display flash settings, press **MENU/OK** in the photo shooting display and select the ⚡ (**FLASH SETTING**) tab.



FLASH FUNCTION SETTING

Choose a flash control mode, flash mode, or sync mode or adjust the flash level. The options available vary with the flash.



For more information on flash settings, see "External Flash Units" (📖 357) in "Peripherals and Optional Accessories".

RED EYE REMOVAL

Remove red-eye effects caused by the flash.

Option	Description
FLASH	A red-eye reduction pre-flash to remove red-eye effects.
OFF	Flash red-eye reduction and digital red-eye removal off.

Flash red-eye reduction can be used in TTL flash control mode.

TTL-LOCK MODE

Instead of adjusting flash level with each shot, TTL flash control can be locked for consistent results across a series of photographs.

Option	Description
LOCK WITH LAST FLASH	Flash output is locked at the value metered for the most recent photo.
LOCK WITH METERING FLASH	The camera emits a series of pre-flashes and locks flash output at the metered value.

- To use TTL lock, assign **TTL-LOCK** to a camera control and then use the control to enable or disable TTL lock (📖 339).
- Flash compensation can be adjusted while TTL lock is in effect.
- Selecting **LOCK WITH LAST FLASH** displays an error message if no previously metered value exists.

LED LIGHT SETTING

Choose whether to use the flash unit's LED video light (if available) as a catchlight or AF-assist illuminator when taking photos.

Option	Role of LED video light in still photography
CATCHLIGHT	Catchlight
AF ASSIST	AF-assist illuminator
AF ASSIST+CATCHLIGHT	AF-assist illuminator and catchlight
OFF	None

In some cases, this option can also be accessed via the **FLASH FUNCTION SETTING** menu.

COMMANDER SETTING

Choose groups when using the camera flash unit as a commander for Fujifilm optical wireless remote flash control. This option is available when the camera is used with clip-on flash units that support Fujifilm optical wireless flash control.

Options			
Gr A	**Gr B**	**Gr C**	**OFF**

In some cases, this option can also be accessed via the **FLASH FUNCTION SETTING** menu.

CH SETTING

Choose the channel used for communication between the commander and remote flash units. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.

Options			
CH1	**CH2**	**CH3**	**CH4**

MOVIE SETTING (Still Photography)

Adjust options for movies shot during still photography using function buttons that have been assigned **MOVIE RECORDING RELEASE**.

To display movie settings, press **MENU/OK** in the photo shooting display and select the (**MOVIE SETTING**) tab.



The options available vary with the shooting mode selected.

MOVIE MODE

This item is also found in the movie menus (📖 192). Changes here also apply to the item in the movie menus.

HIGH SPEED REC

This item is also found in the movie menus (📖 193). Changes here also apply to the item in the movie menus.

MEDIA REC SETTING

This item is also found in the movie menus (📖 194). Changes here also apply to the item in the movie menus.

IS MODE

This item is also found in the movie menus (📖 201). Changes here also apply to the item in the movie menus.

IS MODE BOOST

This item is also found in the movie menus (📖 201). Changes here also apply to the item in the movie menus.

AUDIO SETTING

Adjust audio-related settings for movie recording.

INTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for the built-in microphone.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Choose from 25 recording levels.
OFF	Turn the built-in microphone off.

EXTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for external microphones.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Choose from 25 recording levels.
OFF	Disable recording using external microphones.

MIC LEVEL LIMITER

Reduces distortion caused by input that exceeds the limits of the microphone's audio circuits.

Options	
ON	**OFF**

MIC JACK SETTING

Specify the type of hardware connected via the microphone/remote release connector.

Option	Description
MIC	Choose this option for direct connection to an external microphone.
LINE	Choose this option for external audio devices connected via line output.

WIND FILTER

Choose whether to enable wind noise reduction during movie recording.

Options	
ON	**OFF**

LOW CUT FILTER

Choose whether to enable the low-cut filter, reducing low-frequency noise during movie recording.

Options	
ON	**OFF**

HEADPHONES VOLUME

Adjust the headphone volume.

Option	Description
0	Mute output to the headphones.
1—10	Choose a volume of from 1 to 10.

MIC/REMOTE RELEASE

This item is also found in the movie menus (📖 220). Changes here also apply to the item in the movie menus.

REC FRAME INDICATOR

This item is also found in the movie menus (📖 203). Changes here also apply to the item in the movie menus.

MOVIE SETTING (Movie Recording)

Adjust movie-recording options.

To display options for movie recording, press **MENU/OK** in the movie shooting display and select the (**MOVIE SETTING**) tab.

MOVIE SETTING LIST

View current movie recording settings.



Item	
① Destination	④ File Type and Compression
② MOVIE MODE	⑤ Film Simulation/F-Log/HLG
③ MEDIA REC SETTING	⑥ RAW OUTPUT SETTING

These options can also be viewed by pressing the **DISP/BACK** button while the movie quick menu is displayed.

MOVIE MODE

Before shooting movies, choose the frame rate and the frame size and aspect ratio.



1. In the shooting menu, select **MOVIE SETTING**, then highlight **MOVIE MODE** and press **MENU/OK**.
2. Press the focus stick (focus lever) up or down to highlight the desired frame size and aspect ratio (①) and press the stick right.
   - Choose 6.2K **3:2** for 6.2 K movies with an aspect ratio of 3:2.
   - Choose 4K **16:9** or DCI 4K **17:9** for 4K movies with aspect ratios of 16 or 17 to 9.
   - Choose FHD **16:9** or FHD **9:16** or FHD **17:9** for Full HD movies with aspect ratios of 16:9, 9:16, or 17:9, respectively.
3. Press the focus stick (focus lever) up or down to highlight a frame rate (②) and press **MENU/OK**.

Options					
23.98P	24P	25P	29.97P	50P	59.94P

The choice of frame rates varies with the movie mode.

HIGH SPEED REC

Record high-frame-rate movies. High-frame-rate movies can be played back in slow motion, giving you time to view fast-moving subjects or details too fleeting for the naked eye. Select **ON** to choose the recording and playback rates separately.

Choose **ON HDMI ONLY** to record footage only to external recorders connected via HDMI. Note that this option does not support playback frame-rate selection.

Frame Size

Options	
FHD 16:9	FHD 17:9

Recording

Options			
100P	120P	200P	240P

Playback

Options					
23.98P	24P	25P	29.97P	50P	59.94P

- High-speed movies are recorded with no sound.
- The footage recorded to the memory card is compressed with the goal of maintaining the selected bit rate.
- The options available for playback rate vary with the option selected for rate of recording.

9:16 SHORT MOVIE MODE

Preset the recording time to record vertical movies with small file sizes.

Options			
15 sec.	30 sec.	1 min.	OFF

SELF-TIMER

Choose the delay between the shutter button being pressed all the way down and the start of recording.

- The display shows the number of seconds remaining before recording begins.
- To stop the timer before recording begins, press **DISP/BACK**.



Options			
3 SEC	5 SEC	10 SEC	OFF

MEDIA REC SETTING

Choose movie file settings, including destination, file type, compression, and bit rate.

Destination

Choose save options and output destinations for movies.

Option	Description
SD	Movies are saved solely to the memory card.
HDMI	Movies are recorded only to devices connected via HDMI.

File Type and Compression

Choose the movie file type and compression.

Option	Description
H.264 LongGOP 420 MOV	A highly-portable compressed format. Footage is recorded at a depth of 8 bits using Long GOP interframe compression and 4:2:0 chroma sub-sampling.
H.264 LongGOP 420 MP4	A format suitable for movies that will be uploaded to the web.
H.265 LongGOP 420 MOV	A format with a higher compression ratio than H.264. Footage is recorded at a depth of 10 bits using Long GOP interframe compression and 4:2:0 chroma sub-sampling.
H.265 LongGOP 422 MOV	A format with a higher compression ratio than H.264. Footage is recorded at a depth of 10 bits using Long GOP interframe compression and 4:2:2 chroma sub-sampling.

- 4:2:2 chroma sub-sampling is used for footage output to external devices connected via HDMI; H.264 footage is output at a bit depth of 8 bits and footage in other formats at a depth of 10 bits.
- **Long GOP** balances good image quality with high compression. Files are smaller, making it a good choice for longer movies.
- The options available for file type and compression vary with the options selected for **MOVIE MODE**, **HIGH SPEED REC**, and **F-Log/HLG RECORDING**.

Bit Rate

Choose the movie bit rate.

Options				
8Mbps	25Mbps	50Mbps	100Mbps	200Mbps

The options available for bit rate vary with the settings chosen for high-speed movie recording and compression. The actual bit rate may be slower than the selected value depending on the subject.

HDMI OUTPUT SETTING

Adjust settings for use when the shooting display is output to an HDMI device.

HDMI OUTPUT INFO DISPLAY

If **ON** is selected, HDMI devices to which the camera is connected will mirror the information in the camera display.

Options	
ON	**OFF**

HDMI REC CONTROL

Choose whether the camera sends movie start and stop signals to the HDMI device when the shutter button is pressed to start and stop movie recording.

Options	
ON	**OFF**

RAW OUTPUT SETTING

Choose whether to output RAW footage to external recorders connected via HDMI.

Option	Description
RAW OUTPUT SETTING ATOMOS	Output RAW footage to ATOMOS video recorders.
RAW OUTPUT SETTING Blackmagic	Output RAW footage to Blackmagic Design video recorders.
OFF	Do not output RAW footage to external recorders.

- RAW footage output to external devices is not saved to the memory cards inserted in the camera.
- In-camera image enhancements are not applied to the **RAW** output.
- ISO sensitivity is restricted to values between ISO 1000 and ISO 12800.
- Footage output to external devices is generated from the original RAW data and its quality, which varies with device specifications, may not be equal to that achieved as the end result of post-production or the like.
- Focus zoom is not available when **RAW** is selected for HDMI output.
- **RAW** footage output via HDMI to incompatible devices will not display correctly but will instead display as a mosaic.
- RAW output is disabled in some movie and high-speed recording modes.

FIX MOVIE CROP MAGNIFICATION

Fix the movie crop ratio at 1.29:1. This makes it easier to match crops after changing movie settings.

Options	
ON	**OFF**

F-Log/HLG RECORDING

Choose the destination for F-Log and HLG (Hybrid Log-Gamma) movies shot while the camera is connected to an HDMI device.

Option	Description
SD HDMI	The footage is processed using film simulation and both saved to the memory card and output to the HDMI device.
SD F-Log HDMI F-Log	The footage is recorded to the memory card and output to the HDMI device in F-Log format.
SD F-Log2 HDMI F-Log2	The footage is recorded to the memory card and output to the HDMI device in F-Log2 format.
SD HLG HDMI HLG	The footage is recorded to the memory card and output to the HDMI device in HLG format.

- **F-Log** and **F-Log2** offer gentle gamma curves with wide gamuts suitable for further processing post-production. Sensitivity is restricted to values between ISO 640 and ISO 12800 (**F-Log**) or between ISO 1250 and ISO 12800 (**F-Log2**).
- The **HLG** (Hybrid Log-Gamma) recording format conforms to the international ITU-R BT2100 standard. When viewed on HLG-compatible displays, high-quality HLG footage faithfully captures high-contrast scenes and vivid colors. Sensitivity is restricted to values between ISO 1000 and ISO 12800.
- Film simulation ( ) footage is recorded using the option selected for **IMAGE QUALITY SETTING** > **FILM SIMULATION** in the shooting menu.

DATA LEVEL SETTING

Choose a signal range for movie recording.

Option	Description
VIDEO RANGE	The signal range for 8-bit movies is limited to 16–235 and that for 10-bit movies to 64–940.
FULL RANGE	The signal ranges for 8-bit and 10-bit movies are respectively 0–255 and 0–1023.

PHOTOMETRY

Options are the same as those for still photography, but settings must be adjusted separately (📖 98).

FLICKERLESS S.S. SETTING

Options are the same as those for still photography, but settings must be adjusted separately (📖 182).

Options	
ON	**OFF**

IS MODE

Choose the image stabilization mode.

Option	Description
OIS	Enable optical image stabilization (OIS).
OIS + DIS	Enable digital image stabilization (DIS) in addition to optical image stabilization (OIS). The crop is adjusted according to the option selected for **MOVIE MODE**. This setting can compensate for more severe camera shake.
OFF	Image stabilization off; appears in the display.

- The setting selected with the lens image stabilization switch, if any, takes priority over the setting chosen with the IS mode.
- Note that vibration or camera sounds may be noticeable as image stabilization takes effect.

IS MODE BOOST

Choose the image stabilization level.

Option	Description
ON	Suitable for shots with no panning.
OFF	Suitable for shots with panning.

Assigning **IS MODE BOOST** to a function button allows the image stabilization level to be changed while recording is in progress (📖 339).

ISO

Adjust the camera's sensitivity to light.

Option	Description
H (25600)	Choose for special situations. Note that dynamic range may be reduced and that pictures may be mottled.
160–12800	Adjust sensitivity manually. Selected value is shown in display.
AUTO	The ISO sensitivity (ISO 160 to ISO 12800) for the brightness of the subject is set automatically.

ZEBRA SETTING

Highlights that may be overexposed are shown by zebra stripes in the movie mode display.

Option	Description
ZEBRA RIGHT	Right-slanting stripes.
ZEBRA LEFT	Left-slanting stripes.
OFF	Stripes off.

ZEBRA LEVEL

Choose the brightness threshold for the zebra stripe display.

Options										
50	**55**	**60**	**65**	**70**	**75**	**80**	**85**	**90**	**95**	**100**

MOVIE OPTIMIZED CONTROL

Select **ON** to allow movie settings to be adjusted using only the command dials and touch-screen controls. You may find this helpful in preventing the sounds of camera controls being recorded with movies (📖 30).

Options	
ON	**OFF**

REC FRAME INDICATOR

If **ON** is selected, the borders of the display will turn red during movie recording.

Options	
ON	**OFF**

The borders are displayed in green during high-speed movie recording.

TALLY LIGHT

Choose the lamp (indicator or AF-assist) that lights during movie recording and whether the lamp blinks or remains steady.



Indicator lamp



AF-assist illuminator

Option	Description
FRONT OFF **REAR** 🔔	The indicator lamp lights during movie recording.
FRONT OFF **REAR** 🔔	The indicator lamp blinks during movie recording.
FRONT 🔔 **REAR** 🔔	The indicator and AF-assist lamps light during movie recording.
FRONT 🔔 **REAR OFF**	The AF-assist lamp lights during movie recording.
FRONT 🔔 **REAR** 🔔	The indicator and AF-assist lamps blink during movie recording.
FRONT 🔔 **REAR OFF**	The AF-assist lamp blinks during movie recording.
FRONT OFF **REAR OFF**	The indicator and AF-assist lamps remain off during movie recording.

SELECT CUSTOM SETTING

Options are the same as those for still photography, but settings must be adjusted separately (📖 144).

EDIT/SAVE CUSTOM SETTING

Options are the same as those for still photography, but settings must be adjusted separately (📖 145).

AUTO UPDATE CUSTOM SETTING

This item is also found in the photo menus (📖 150).

IMAGE QUALITY SETTING (Movie Recording)

Adjust image quality settings for movies.

To display image quality settings, press **MENU/OK** in the movie shooting display and select the IQ (**IMAGE QUALITY SETTING**) tab.



The options available vary with the shooting mode selected.

FILM SIMULATION DIAL SETTING

Options are the same as those for still photography, but settings must be adjusted separately (📖 130).

FILM SIMULATION

Options are the same as those for still photography, but settings must be adjusted separately (📖 131).

MONOCHROMATIC COLOR

Options are the same as those for still photography, but settings must be adjusted separately (📖 133).

WHITE BALANCE

Options are the same as those for still photography, but settings must be adjusted separately (📖 135).

DYNAMIC RANGE

Choose a dynamic range for movie recording.

Option	Description
100%	See "DYNAMIC RANGE" (📖 139).
200%	
400%	

- **AUTO** (automatic dynamic range control) is not available during movie recording.
- **200%** is available at sensitivities of from ISO 320 to ISO 12800, **400%** at sensitivities of from ISO 640 to 12800.
- This item is available when SD HDMI is selected for **MOVIE SETTING** > **F-Log/HLG RECORDING**.

TONE CURVE

Options are the same as those for still photography, but settings must be adjusted separately (📖 141).

COLOR

Options are the same as those for still photography, but settings must be adjusted separately (📖 141).

SHARPNESS

Options are the same as those for still photography, but settings must be adjusted separately (📖 141).

HIGH ISO NR

Options are the same as those for still photography, but settings must be adjusted separately (📖 142).

PORTRAIT ENHANCER LV

Options are the same as those for still photography, but settings must be adjusted separately (📖 142).

INTERFRAME NR

Select **AUTO** to automatically adjust interframe noise reduction according to shooting conditions.

Options	
AUTO	**OFF**

"Ghosting" may occur with moving subjects or if the camera is moved during shooting.

PERIPHERAL LIGHT CORRECTION

Select **ON** to enable peripheral illumination correction during movie recording.

Options	
ON	**OFF**

- If **ON** is selected when a lens that does not transmit data to the camera is attached, peripheral illumination will be adjusted according to the option selected for **IMAGE QUALITY SETTING** > **MOUNT ADAPTOR SETTING** > **PERIPHERAL ILLUMINATION CORRECTION** in the shooting menu (📖 152).
- Select **OFF** if you notice banding in movies recorded using this option.

MOUNT ADAPTOR SETTING

This item is also found in the photo menus (📖 150). Changes to one apply to the other.

AF/MF SETTING (Movie Recording)

Adjust focus settings for movies.

To display AF/MF settings, press **MENU/OK** in the movie shooting display and select the AF/MF (**AF/MF SETTING**) tab.



The options available vary with the shooting mode selected.

FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom (📖 87).

The focus area cannot be resized while recording is in progress.

AF MODE

Choose how the camera selects the focus point for movie recording.

Option	Description
MULTI	The camera selects the focus area automatically.
WIDE/TRACKING	The camera tracks the subject automatically if the focus stick (focus lever) is pushed to the center or the screen is touched when the focus mode is **C**. The camera selects the focus subject automatically when the focus mode is **S**.
AREA	The camera focuses on the subject in the selected focus area.

AF-C CUSTOM SETTING

Select focus-tracking options when recording movies in focus mode **C**.

TRACKING SENSITIVITY

Choose how long the camera waits to switch focus when an object enters the focus area behind or in front of the current subject. See "TRACKING SENSITIVITY" (📖 155).

Options				
0	1	2	3	4

- The higher the value, the longer it takes the camera to refocus when you attempt to switch subjects.
- The lower the value, the more likely the camera is to switch focus from your subject to other objects in the focus area.

AF SPEED

Adjust the autofocus response speed. Choose higher values for faster response times, lower values for slower response times.

Options										
−5	−4	−3	−2	−1	0	+1	+2	+3	+4	+5

WRAP FOCUS POINT

This item is also found in the photo menus (📖 159). Changes to one apply to the other.

FACE/EYE DETECTION SETTING

Enable or disable Intelligent Face Detection when recording movies.

Option	Description
FACE DETECTION ON	See "FACE/EYE DETECTION SETTING" (📖 161).
OFF	Intelligent Face Detection and eye priority off.

When Intelligent Face Detection is enabled, the camera will focus using continuous AF even when single AF (**S**) is chosen with the focus mode selector. Intelligent Face Detection is not available in manual focus mode.

SUBJECT DETECTION SETTING

Options are the same as those for still photography, but settings must be adjusted separately (📖 163).

The camera automatically switches to continuous AF when **SUBJECT DETECTION ON** is selected for **AF/MF SETTING** > **SUBJECT DETECTION SETTING**, even if the focus mode selector is rotated to **S**. Subject detection is not available in manual focus mode.

AF+MF

Select **ON** to enable manual focus in focus modes **S** and **C**. Manual focus can be suspended by pressing the shutter button halfway.

Options	
ON	**OFF**

MF ASSIST

Choose how focus is displayed in manual focus mode (📖 94).

Option	Description
FOCUS PEAK HIGHLIGHT	The camera heightens high-contrast outlines. Choose a color and peaking level.
FOCUS METER	A needle indicates whether focus is in front of or behind the subject.
FOCUS METER + PEAK HIGHLIGHT	Focus is indicated by both a meter and peak highlights.
FOCUS MAP	Indicators for locations in and out of focus are displayed on the screen.
OFF	Focus is displayed normally (MF assist cannot be used).

INTERLOCK MF ASSIST & FOCUS RING

Options are the same as those for still photography, but settings must be adjusted separately (📖 167).

FOCUS CHECK

Options are the same as those for still photography, but settings must be adjusted separately (📖 167).

INSTANT AF SETTING

This item is also found in the photo menus (📖 168). Changes to one apply to the other.

DEPTH-OF-FIELD SCALE

This item is also found in the photo menus (📖 169). Changes to one apply to the other.

AF RANGE LIMITER

This item is also found in the photo menus (📖 170). Changes to one apply to the other.

TOUCH SCREEN MODE

Choose the shooting operations performed using touch controls.

Mode	Description
AF	Tapping the display focuses the camera on the selected point. *Use the shutter button to start and stop recording.* • In focus mode **S** (AF-S), you can refocus at any time by tapping your subject in the display. • In focus mode **C** (AF-C), the camera will continuously adjust focus for changes in the distance to the subject at point selected by tapping the display. • When shooting movies in focus mode **M** (MF), you can tap the display before recording begins to focus on the selected point using Instant AF, and tap the display during recording to position the focus point.
AREA	Tap to position the focus area. *Use the shutter button to start and stop recording.* • In focus mode **S** (AF-S), you can reposition the focus area at any time by tapping your subject in the display. To focus, use the button to which **AF-ON** is assigned. • In focus mode **C** (AF-C), the camera will continuously adjust focus for changes in the distance to the subject at point selected by tapping the display. • In manual focus mode (MF), you can tap the display to position the focus area over your subject.
OFF	Touch screen mode off.

- The behavior of the touch screen varies with the AF mode.
- To disable touch controls and hide the touch screen mode indicator, select **OFF** for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **TOUCH SCREEN SETTING**.

Touch Controls for Focus Zoom

Different touch controls are used during focus zoom (focus check enabled).

Central Area

Tapping the center of the display performs the operations below.



Mode	Operation performed
AF	**AF-S**: AF
	MF: Instant AF
AREA	**AF-S**: AF
	MF: Instant AF
OFF	**AF-S/MF**: OFF

Other Areas

Tapping other areas simply scrolls the display, whether during still photography or movie recording and regardless of the option selected for touch screen mode.



FOCUS CHECK LOCK

Choose whether focus zoom remains in effect once movie recording begins.

Options	
ON	**OFF**

AUDIO SETTING (Movie Recording)

Adjust settings for audio recorded during filming.

To display audio settings, press **MENU/OK** in the movie shooting display and select the (**AUDIO SETTING**) tab.



INTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for the built-in microphone.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Choose from 25 recording levels.
OFF	Turn the built-in microphone off.

EXTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for external microphones.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Choose from 25 recording levels.
OFF	Disable recording using external microphones.

MIC LEVEL LIMITER

Reduces distortion caused by input that exceeds the limits of the microphone's audio circuits.

Options	
ON	**OFF**

MIC JACK SETTING

Specify the type of hardware connected via the microphone/remote release connector.

Option	Description
MIC	Choose this option for direct connection to an external microphone.
LINE	Choose this option for external audio devices connected via line output.

WIND FILTER

Choose whether to enable wind noise reduction during movie recording.

Options	
ON	**OFF**

LOW CUT FILTER

Choose whether to enable the low-cut filter, reducing low-frequency noise during movie recording.

Options	
ON	**OFF**

HEADPHONES VOLUME

Adjust the headphone volume.

Option	Description
0	Mute output to the headphones.
1—10	Choose a volume of from 1 to 10.

MIC/REMOTE RELEASE

Specify whether the device connected to the microphone/remote release connector is a microphone or a remote release.

Options	
MIC	**REMOTE**

TIME CODE SETTING (Movie Recording)

Adjust time code (hour, minute, second, and frame number) display settings for movie recording.

To display time code settings, press **MENU/OK** in the movie shooting display and select the TC (**TIME CODE SETTING**) tab.



TIME CODE DISPLAY

Select **ON** to display time codes during movie recording and playback.

Options	
ON	**OFF**

START TIME SETTING

Choose the time code starting time.

Option	Description
MANUAL INPUT	Choose a start time manually.
CURRENT TIME	Set the start time to the current time.
RESET	Set the start time to 00:00:00.

COUNT UP SETTING

Choose whether time is clocked continuously or only during movie recording.

Option	Description
REC RUN	Time is clocked only during movie recording.
FREE RUN	Time is clocked continuously.

DROP FRAME

At frame rates of **59.94P**, and **29.97P**, a discrepancy will gradually develop between the time code (measured in seconds) and the actual recording time (measured in fractions of a second). Choose whether the camera drops frames as necessary to match the recording time to the time code.

Option	Description
ON	The camera drops frames as necessary to maintain a strict match between the time code and the actual recording time.
OFF	Frames are not dropped.

• The time code display varies with the option selected.



ON



OFF

• Selecting a frame rate of **23.98P** disables frame drop.

HDMI TIME CODE OUTPUT

Choose whether time codes are output to HDMI devices.

Options	
ON	**OFF**

TIME CODE SYNC. SETTING

Choose whether to synchronize time codes with an external device.

CONNECT TO ATOMOS AirGlu BT

If **ON** is selected, the camera connects with paired external devices and synchronizes time codes. Because simultaneous connection with a smartphone is not possible, the smartphone icon is displayed in the yellow on the screen.

Options	
ON	**OFF**

PAIRING REGISTRATION

Pair the ATOMOS AirGlu BT and camera.

- If the camera connects with the ATOMOS AirGlu BT, an icon appears on the screen.



- The pairing with the ATOMOS AirGlu BT can be ended using **Bluetooth/SMARTPHONE SETTING** > **Bluetooth DEVICE LIST** in the network/USB setting menu.

Time code synchronization state

You can check the time code synchronization state by the icons displayed on the EVF or LCD.



Icon	Synchronization state
TC 00:00:00:00 **(white)**	The time code synchronization function is not being used.
TC 00:00:00:00 **(white)**	Time codes are being synchronized.
TC —:—:—:— **(amber)**	External devices have been disconnected or time codes are not being synchronized. If time codes have been synchronized once, and the camera continues to count internally after **CONNECT TO ATOMOS AirGlu BT** was set to **ON**, a value is displayed.
TC —:—:—:— **(red)**	Time codes are not being synchronized because the frame rate settings are different. If time codes have been synchronized once, and the camera continues to count internally after **CONNECT TO ATOMOS AirGlu BT** was set to **ON**, a value is displayed.

7 Playback and the Playback Menu

The Playback Display

This section lists the indicators that may be displayed during playback.

For illustrative purposes, displays are shown with all indicators lit.



① *Date and time*.....48, 50, 291
② *Frame-number display*
③ *Image transfer order*
④ *Frame.io image transfer order*
⑤ *Image transfer status*
⑥ *Frame.io upload progress*
⑦ *Frame number*.....326
⑧ *Protected image*.....240
⑨ *Location data*.....328
⑩ *Low battery*.....47
⑪ *Image quality*.....127
⑫ *Movie mode*.....192
⑬ *HEIF*.....129
⑭ *Image size*.....126
⑮ *Film format*.....195
⑯ *Film simulation*.....131
⑰ *Dynamic range*.....139
⑱ *White balance*.....135
⑲ *Sensitivity*.....96
⑳ *Exposure compensation*.....99
㉑ *Aperture*.....72, 76, 78
㉒ *Time code*.....221
㉓ *Shutter speed*.....72, 73, 78
㉔ *Playback mode indicator*.....54
㉕ *Movie icon*.....64
㉖ *Four-channel (quadrophonic) audio*
㉗ *Bluetooth host*.....256
㉘ *Photobook assist indicator*.....247
㉙ *Bluetooth ON/OFF*
㉚ *DPOF print indicator*.....249
㉛ *Frame.io connection status*.....270
㉜ *Voice memo*.....242
㉝ *Gift image*.....54
㉞ *Rating*.....243
㉟ *Face detection indicator*.....161

The DISP/BACK Button

The **DISP/BACK** button controls the display of indicators during playback.





Viewing Photo Information

The photo information display changes each time the focus stick (focus lever) is pressed up.



Basic data



Info display 1



Info display 3



Info display 2



Zooming in on the Focus Point

Press the center of the rear command dial to zoom in on the focus point. Press again to return to full-frame playback.



Viewing Pictures

Read this section for information on playback zoom and multi-frame playback.

Use the rear command dial to go from full-frame playback to playback zoom or multi-frame playback. Rotate the rear command dial to right or left, the display changes as shown. The display changes in reverse order when rotate the dial to opposite direction.

To cancel playback zoom or multi-frame playback, press **DISP/BACK** or **MENU/OK**.





Playback Zoom

Rotate the rear command dial right to zoom in on the current picture, left to zoom out. To exit zoom, press **DISP/BACK**, **MENU/OK**, or the center of the rear command dial.

The maximum zoom ratio varies with the option selected for **IMAGE QUALITY SETTING** > **IMAGE SIZE**.

Scroll

When the picture is zoomed in, the focus stick (focus lever) can be used to view areas of the image not currently visible in the display.

Navigation window

Multi-Frame Playback

To change the number of images displayed, rotate the rear command dial left when a picture is displayed full frame.

- Use the focus stick (focus lever) to highlight images and press **MENU/OK** to view the highlighted image full frame.
- In the nine- and hundred-frame displays, press the focus stick up or down to view more pictures.

The Playback Menu

Adjust playback settings.

The playback menu is displayed when you press **MENU/OK** in playback mode.



RAW CONVERSION

Even if you don't have a computer, you can use the camera to modify RAW pictures and save them in other formats.

Saving RAW Pictures in Another Format

1. Display a RAW picture.
2. Highlight **RAW CONVERSION** in the playback menu.
3. Press **MENU/OK**.
   A list of settings will be displayed.



4. Press the focus stick (focus lever) up or down to highlight a setting.
5. Press the focus stick right to display options.



6 Press the focus stick up or down to highlight the desired option.

7 Press **MENU/OK** to select the highlighted option. The settings list shown in Step 3 will be displayed. Repeat Steps 4 to 7 to adjust additional settings.

8 Press the **Q** button.
A preview of the copy will be displayed.

9 Press **MENU/OK**.
The copy will be saved.

RAW conversion options can also be displayed by pressing the **Q** button when RAW pictures are displayed during playback.

The settings that can be adjusted when converting pictures from RAW to another format are:

Setting	Description
REFLECT SHOOTING COND.	Create a copy using the settings in effect at the time the photo was taken.
FILE TYPE	Choose a file format.
IMAGE SIZE	Choose an image size.
IMAGE QUALITY	Adjust image quality.
PUSH/PULL PROCESSING	Adjust exposure.
DYNAMIC RANGE	Enhance details in highlights for natural contrast.
D RANGE PRIORITY	Reduce loss of detail in highlights and shadows for natural-looking results when photographing high-contrast scenes.
FILM SIMULATION	Simulate the effects of different types of film.
MONOCHROMATIC COLOR	Choose a monochrome tint for photographs taken using **FILM SIMULATION** > **ACROS** and **MONOCHROME**.
GRAIN EFFECT	Add a film grain effect.
COLOR CHROME EFFECT	Increase the range of tones available for rendering colors that tend to be highly saturated, such as reds, yellows, and greens.
COLOR CHROME FX BLUE	Increase the range of tones available for rendering blues.
WHITE BALANCE	Adjust white balance.
WB SHIFT	Fine-tune white balance.
TONE CURVE	Adjust highlights and shadows.
COLOR	Adjust color density.
SHARPNESS	Sharpen or soften outlines.
HIGH ISO NR	Process the copy to reduce mottling.
PORTRAIT ENHANCER LV	Choose the portrait enhancement level.
CLARITY	Increase definition.
LENS MODULATION OPTIMIZER	Improve definition by adjusting for diffraction and the slight loss of focus at the periphery of the lens.

Setting	Description
COLOR SPACE	Choose the color space used for color reproduction.
HDR MODE	Reduce loss of detail in highlights and shadows.

Some settings may be unavailable depending on the options chosen when the picture was taken.

HEIF TO JPEG/TIFF CONVERSION

Convert HEIF pictures to JPEG or TIFF.

SELECT IMAGES

Select HEIF pictures for conversion.

FILE FORMAT

Choose a format for the converted pictures.

Options		
JPEG	**TIFF 8bit**	**TIFF 16bit**

ERASE

Delete individual pictures, multiple selected pictures, or all pictures.

Deleted pictures cannot be recovered. Protect important pictures or copy them to a computer or other storage device before proceeding.

Option	Description
FRAME	Delete pictures one at a time.
SELECTED FRAMES	Delete multiple selected pictures.
ALL FRAMES	Delete all unprotected pictures.

FRAME

1. Select **FRAME** for **ERASE** in the playback menu.
2. Press the focus stick (focus lever) left or right to scroll through pictures and press **MENU/OK** to delete.

- A confirmation dialog is not displayed before pictures are deleted; be sure the correct picture is selected before pressing **MENU/OK**.
- Additional pictures can be deleted by pressing **MENU/OK**. Press the focus stick left or right to scroll through pictures and press **MENU/OK** to delete.

SELECTED FRAMES

1. Select **SELECTED FRAMES** for **ERASE** in the playback menu.
2. Highlight pictures and press **MENU/OK** to select.
   - Selected pictures are indicated by check marks (☑).
   - To deselect a highlighted picture, press **MENU/OK** again.
3. When the operation is complete, press **DISP/BACK** to display a confirmation dialog.
4. Highlight **OK** and press **MENU/OK** to delete the selected pictures.

Pictures in photobooks or printer orders are shown by !.

ALL FRAMES

1. Select **ALL FRAMES** for **ERASE** in the playback menu.
2. A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK** to delete all unprotected pictures.

- Pressing **DISP/BACK** cancels deletion; note that any pictures deleted before the button was pressed cannot be recovered.
- If a message appears stating that the selected images are part of a DPOF print order, press **MENU/OK** to delete the pictures.

CROP

Create a cropped copy of the current picture.

1. Display the desired picture.
2. Select **CROP** in the playback menu.
3. Use the rear command dial to zoom in and out and press the focus stick (focus lever) up, down, left, or right to scroll the picture until the desired portion is displayed.
4. Press **MENU/OK** to display a confirmation dialog.
5. Press **MENU/OK** again to save the cropped copy to a separate file.

- The higher the zoom ratio, the smaller the number of pixels in the cropped copy.
- If the size of the final copy will be 640, **YES** will be displayed in yellow.
- All copies have an aspect ratio of 3:2.

RESIZE

Create a small copy of the current picture.

1. Display the desired picture.
2. Select **RESIZE** in the playback menu.
3. Highlight a size and press **MENU/OK** to display a confirmation dialog.
4. Press **MENU/OK** again to save the resized copy to a separate file.

The sizes available vary with the size of the original image.

PROTECT

Protect pictures from accidental deletion. Highlight one of the following options and press **MENU/OK**.

Option	Description
FRAME	Protect selected pictures. Press the focus stick (focus lever) left or right to view pictures and press **MENU/OK** to select or deselect. Press **DISP/BACK** when the operation is complete.
SET ALL	Protect all pictures.
RESET ALL	Remove protection from all pictures.

Protected pictures will be deleted when the memory card is formatted.

- Protecting images currently selected for upload to paired smartphones or tablets removes upload marking.
- Protection can also be added or removed by pressing the **AF-L** button during playback.

IMAGE ROTATE

Rotate pictures.

1. Select **ON** for **SCREEN SET-UP** > **AUTOROTATE PB**.
2. Display the desired picture.
3. Select **IMAGE ROTATE** in the playback menu.
4. Press the focus stick (focus lever) down to rotate the picture 90° clockwise, up to rotate it 90° counterclockwise.
5. Press **MENU/OK**. The picture will automatically be displayed in the selected orientation whenever it is played back on the camera.

- Protected pictures cannot be rotated. Remove protection before rotating pictures.
- The camera may not be able to rotate pictures created with other devices. Pictures rotated on the camera will not be rotated when viewed on a computer or on other cameras.
- Pictures taken with **SCREEN SET-UP** > **AUTOROTATE PB** are automatically displayed in the correct orientation during playback.

VOICE MEMO SETTING

Add a voice memo to the current photograph.

1. Select **ON** for **VOICE MEMO SETTING** in the playback menu.
2. Display a photo to which you wish to add a voice memo.
3. Press and hold the center of the front command dial to record the memo. Recording ends after 30 s or when you release the dial.

- The new memo will be recorded over any existing memos.
- Voice memos cannot be added to protected pictures.
- Deleting the picture also deletes the memo.

Playing Voice Memos

Pictures with voice memos are indicated by icons during playback.

- To play a memo, select the picture and press the center of the front command dial.
- A progress bar will be displayed while the memo plays back.
- Volume can be adjusted by pressing **MENU/OK** to pause playback and then pressing the focus stick (focus lever) up or down to adjust the volume. Press **MENU/OK** again to resume playback. Volume can also be adjusted using **SOUND SET-UP** > **PLAYBACK VOLUME**.

RATING

Rate pictures using stars.

1. Select **RATING** in the playback menu.
2. Rotate the front command dial to choose a picture and the rear command dial to choose a rating of from 0 to 5 stars ("★").

- The focus stick (focus lever) can be used in place of the front command dial to choose a picture.
- The rating dialog can also be displayed by pressing the **AE-L** button in single-frame, nine-frame, or hundred-frame playback.
- Use touch controls to zoom in or out.
- Ratings cannot be applied to:
  - Protected pictures
  - Movies
  - "Gift" pictures (pictures taken with other cameras)

TRANSFER IMAGE TO SMARTPHONE

Select photos for upload to a paired smartphone or tablet via Bluetooth (📖 256).

1 Select **TRANSFER IMAGE TO SMARTPHONE** > **SELECT IMAGE & TRANSFER**.

Select **RESET ORDER** to remove "upload to smartphone" marking from all pictures before proceeding.

2 Mark pictures for upload.
Highlight pictures and press **MENU/OK** to mark them for upload.

- To display only pictures that meet selected criteria, press **DISP/BACK** before marking begins.
- To select all pictures, press the **Q** button.
- Selecting any two pictures with the **AE-L** button also selects all pictures between them.



3 Press **DISP/BACK** and select **START TRANSFER**.
The selected pictures will be uploaded.



Filtering Pictures

To display only pictures that meet selected criteria, press **DISP/BACK** in the picture-selection dialog and select **FILTERING**.



Selecting **FILTERING** removes any existing upload marking.

- Image transfer orders can contain a maximum of 999 pictures.
- The following cannot be selected for upload:
  - Protected pictures
  - Movies
  - RAW images
  - "Gift" pictures (pictures taken with other cameras)
- If **ON** is selected for both **IMAGE TRANSFER WHILE POWER OFF** and **Bluetooth/SMARTPHONE SETTING** > **Bluetooth ON/OFF** in the network/USB settings menu, upload to the paired device will continue even while the camera is off.
- When **SELECT & SMARTPHONE TRANSFER ORDER** is selected for **BUTTON/DIAL SETTING** > **Fn BUTTON SETTING**, the picture-selection dialog can be displayed by pressing the **Fn** button.

SLIDE SHOW

View pictures in an automated slide show. Press **MENU/OK** to start and press the focus stick (focus lever) right or left to skip ahead or back. Press **DISP/BACK** at any time during the show to view on-screen help. The show can be ended at any time by pressing **MENU/OK**.

The camera will not turn off automatically while a slide show is in progress.

PHOTOBOOK ASSIST

Create books from your favorite photos.

Creating a Photobook

1. Select **NEW BOOK** for ▶ **PLAY BACK MENU** > **PHOTOBOOK ASSIST**.
2. Scroll through the images and press the focus stick (focus lever) up to select or deselect. Press **MENU/OK** to exit when the book is complete.

> • Neither photographs 640 or smaller nor movies can be selected for photobooks.
> • The first picture selected becomes the cover image. Press the focus stick down to select the current image for the cover instead.

3. Highlight **COMPLETE PHOTOBOOK** and press **MENU/OK** (to select all photos for the book, choose **SELECT ALL**). The new book will be added to the list in the photobook assist menu.

> • Books can contain up to 300 pictures.
> • Books that contain no photos are automatically deleted.

Viewing Photobooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the focus stick (focus lever) left or right to scroll through the pictures.

Editing and Deleting Photobooks

Display the photobook and press **MENU/OK**. The following options will be displayed; select the desired option and follow the on-screen instructions.

- **EDIT**: Edit the book as described in "Creating a Photobook".
- **ERASE**: Delete the book.

PRINT ORDER (DPOF)

Create a digital "print order" for DPOF-compatible printers.

1. Select **PLAY BACK MENU** > **PRINT ORDER (DPOF)**.
2. Select **WITH DATE** to print the date of recording on pictures, **WITHOUT DATE** to print pictures without dates, or **RESET ALL** to remove all pictures from the print order before proceeding.
3. Display a picture you wish to include in or remove from the print order.
4. Press the focus stick (focus lever) up or down to choose the number of copies (up to 99).

   To remove a picture from the order, press the focus stick down until the number of copies is 0.



Total number of prints

Number of copies

Repeat steps 3–4 to complete the print order.

5. The total number of prints is displayed in the monitor. Press **MENU/OK** to exit.

- The pictures in the current print order are indicated by a icon during playback.
- Print orders can contain a maximum of 999 pictures from a single memory card.
- If a memory card is inserted containing a print order created by another camera, you will need to delete the order before creating as described above.

instax PRINTER PRINT

Print pictures on optional Fujifilm instax Link printers. First register the printer you will use (📖 264).

instax IMAGE QUALITY MODE

Set the image quality when printing pictures on optional Fujifilm instax Link printers.

Option	Description
instax-Rich Mode	Print with rich color expression.
instax-Natural Mode	Print with conventional image quality.

These options are only available when using a compatible printer.

DISP ASPECT

Choose the aspect ratio used for the display of still pictures on High Definition (HD) devices (this option is available only when an HDMI cable is connected).



Options	
16:9	**3:2**

Choose **16:9** to display photos with an aspect ratio of 3:2 full screen. The pictures will be displayed full screen with tops and bottoms cropped out.

MEMO

8 Network/USB Features and Settings

Overview

This chapter outlines features that can among other things be used to upload pictures to, or control the camera and take pictures remotely from, a smartphone or computer.

Supported Features

This camera supports the following features:

Feature	Description	📖
Connecting to the smartphone app	Connect to smartphones via Bluetooth® and upload pictures or control the camera remotely while the smartphone displays the view through the lens.	256
USB card readers	Connect a card reader to a computer or smartphone via USB and copy pictures from memory cards.	260
Web camera	Connect the camera to a computer via USB for use as a webcam.	263
instax printers	Print pictures on connected instax printers.	264
Upload to Frame.io	Upload files to Frame.io.	267
RAW processing	Harness the power of the camera's image processing engine when processing RAW pictures on a computer.	274
Saving and Loading Settings	Save camera settings to, or load existing from, a computer.	275

Camera indicator lamp display

The camera indicator lamp shows the status of its connection to Frame.io and the like.



Indicator lamp	Connection status
Blinks red	No network connection.
Glows red	No network connection; pictures awaiting upload.
Blinks orange	Connected to network but not to Frame.io.
Blinks orange and red	Connected to network but not to Frame.io; pictures awaiting upload.
Blinks green	Ready for upload to Frame.io.
Blinks green and red	Ready for upload to Frame.io; pictures awaiting upload.

The EVF/LCD Displays

The status of the connection to Frame.io and the like is also shown by an icon in the electronic viewfinder or LCD monitor.



Icon	Connection status
	No network connection.
	Connected to network but not to Frame.io.
	Ready for upload to Frame.io.

Connecting to Smartphones (Bluetooth)

Connect the camera with a smartphone via Bluetooth® to copy pictures to the smartphone or control the camera remotely while previewing the view through the lens in the smartphone display.

The camera automatically switches to a wireless LAN connection when copying pictures to the smartphone.

Installing Smartphone Apps

Before establishing a connection between the smartphone and camera, you will need to install at least one dedicated smartphone app. Visit the following website and install the desired apps on your phone.

https://fujifilm-dsc.com/

The apps available vary with the smartphone operating system.

Connecting to a Smartphone

Pair the camera with the smartphone and connect via Bluetooth®.

1 Press **DISP/BACK** in the shooting display.



You can also proceed directly to Step 3 by holding the **DISP/BACK** button during playback.

2 Highlight **Bluetooth** and press **MENU/OK**.



3 Highlight **PAIRING** and press **MENU/OK**.



4 A code will be displayed on both your camera and smartphone. Make sure that the same code is displayed before pairing.

When pairing is complete, the camera and smartphone will automatically connect via Bluetooth. A smartphone icon and a white Bluetooth icon will appear in the camera display when a connection is established.



- Once the devices have been paired, the smartphone will automatically connect to the camera when the app is launched.
- Disabling Bluetooth when the camera is not connected to a smartphone reduces the drain on the battery.

Using the Smartphone App

Read this section for information on the options available for downloading pictures to your smartphone using the smartphone app.

Before proceeding, select **ON** for **Bluetooth/SMARTPHONE SETTING** > **Bluetooth ON/OFF**.

Selecting and Downloading Pictures Using the Smartphone App

You can download selected pictures to a smartphone using the smartphone app.

More information is available from the following website:
https://fujifilm-dsc.com/

Uploading Pictures as They Are Taken

Pictures taken with **ON** selected for **Bluetooth/SMARTPHONE SETTING** > **AUTO IMAGE TRANSFER ORDER** in the network/USB setting menu will automatically be uploaded to the paired device.

- If **ON** is selected for both **IMAGE TRANSFER WHILE POWER OFF** and **Bluetooth/SMARTPHONE SETTING** > **Bluetooth ON/OFF** in the network/USB settings menu, upload to the paired device will continue even while the camera is off.
- Selecting **ON** for **Bluetooth/SMARTPHONE SETTING** > **RESIZE IMAGE FOR SMARTPHONE** in the network/USB setting menu enables resizing, reducing file size for upload (📖 281).
- Pictures are uploaded in the format chosen for **Bluetooth/SMARTPHONE SETTING** > **SELECT FILE TYPE** in the network/USB setting menu.

Selecting Pictures for Upload in the Playback Menu

Use **TRANSFER IMAGE TO SMARTPHONE** > **SELECT IMAGE & TRANSFER** to select pictures for upload to a paired smartphone or tablet via Bluetooth® (📖 244).

Connecting to Smartphones (USB)

Connect to smartphones and computers via USB to upload pictures from the camera.

Copying Pictures to a Smartphone

Before connecting to the smartphone to upload pictures via USB, select either **AUTO** or **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.

For Customers Using Android Devices

1. Select either **AUTO** or **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.
2. Select **USB CARD READER** for **CONNECTION MODE**.
3. Connect the camera and smartphone using a USB cable (📖 276).

   If the smartphone asks for permission for an app other than the "Camera Importer" to access the camera, tap "Cancel" and move on to the next step.

4. On your smartphone, tap the notification "Connected to USB PTP".
5. From the recommended apps, select "Camera Importer".
   The app will automatically start and allow you to import photos and movies to your smartphone.

   If the message "There is no MTP device connected" appears on the app, please try again from step 3.

For Customers Using iOS

1. Select **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.
2. Select **USB CARD READER** for **CONNECTION MODE**.
3. Connect the camera and smartphone using a USB cable (📖 276).
   Launch the Photos app to import photos and movies to your smartphone.

Connecting the Camera and Computer

1. Select either **AUTO** or **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.
2. Select **USB CARD READER** for **CONNECTION MODE**.
3. Connect the camera to the computer via USB and then turn the camera on (📖 278).
4. Copy pictures to your computer.
   - **Mac OS X/OS X/macOS**: Pictures can be copied to your computer using Image Capture (supplied with your computer) or other software. Use a card reader to copy files over 4 GB in size.
   - **Windows**: Pictures can be copied to your computer using apps supplied with the operating system.

- Turn the camera off before disconnecting the USB cable.
- When connecting USB cables, be sure the connectors are fully inserted in the correct orientation. Connect the camera directly to the computer; do not use a USB hub or keyboard.
- Loss of power during transfer could result in loss of data or damage to the memory card. Insert a fully-charged battery before connecting the camera.
- If a memory card containing a large number of images is inserted, there may be a delay before the software starts and you may be unable to import or save images. Use a memory card reader to transfer pictures.
- Make sure that the indicator lamp is off or lit green before turning the camera off.
- Do not disconnect the USB cable while transfer is in progress. Failure to observe this precaution could result in loss of data or damage to the memory card.
- Disconnect the camera before inserting or removing memory cards.
- In some cases, it may not be possible to access pictures saved to a network server using the software in the same way as on a standalone computer.
- Do not immediately remove the camera from the system or disconnect the USB cable once the message stating that copying is in progress clears from the computer display. If the number of images copied is very large, data transfer may continue after the message has ceased to be displayed.
- The user bears all applicable fees charged by the phone company or Internet service provider when using services that require an Internet connection.

Using the Camera as a Webcam

The camera can be connected to a computer for use as a webcam.

1. Select either **AUTO** or **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.
2. Select **USB WEBCAM** for **CONNECTION MODE**.
3. Connect the camera to the computer via USB and then turn the camera on (📖 278).
4. Select the camera in the app where it will be used as a webcam.

instax Printers

Print pictures using the optional smartphone printer "FUJIFILM instax Link" series.

Visit the following website about compatible printers.
https://www.fujifilm-x.com/support/compatibility/cameras/

Establishing a Connection

Select **Bluetooth/SMARTPHONE SETTING** in the network/USB setting menu to pair the camera with instax Link printers in **PAIRING REGISTRATION**. Once paired, the camera and printers will be automatically connected via Bluetooth.

Printing Pictures

1 Turn the printer on.

2 Select **instax PRINTER PRINT** in the playback menu.

3 Use the focus stick (focus lever) to display the picture you want to print, then press **MENU/OK**.

- Pictures taken with other cameras cannot be printed.
- The area printed is smaller than the area visible in the LCD monitor.
- The displays may vary depending on the printer connected.

4 The cropping screen is displayed.

Adjust the cropping position and press **MENU/OK**.

Cropping is not available if the aspect ratio of the film to be printed and the image are the same.

5 The picture will be sent to the printer and printing will start.

instax Image Quality Mode

In addition to the existing "instax-Natural Mode", the **instax IMAGE QUALITY MODE** offers an "instax-Rich Mode" featuring vibrant colors.

These options are only available when using a compatible printer.

Uploading Files to Frame.io

Upload files to Frame.io (📖 373).

Confirm that the camera clock is set to the correct time and date before proceeding.

Connecting via Wireless LAN

Connect to Frame.io via wireless LAN.

1. Select **NETWORK SETTING** in the network/USB setting menu.
2. Select **NOT CREATED**.



You can also select or edit existing network.

3. Select **ACCESS POINT SETTING**.

   Select **IP ADDRESS SETTING** to choose the IP address manually as described in "Connecting Using an IP Address" (📖 269).



4. Select **SIMPLE SETUP**.



To select a wireless LAN router or enter the router SSID manually, choose **MANUAL SETUP**.

5 Follow the on-screen instructions to ready the wireless LAN router.



You also have the option of connecting using a PIN. Display the camera PIN by pressing the focus stick (focus lever) up and enter it on the wireless LAN router.

6 Press **MENU/OK** when setup is complete.



7 Select **Frame.io Camera to Cloud** > **CONNECT** in the network/USB settings menu.



8 Once connected, select **GET PAIRING CODE**.

A pairing code will be displayed.



9 Sign in to Frame.io from a computer or other device and enter the pairing code displayed on the camera.

10 Upload files to Frame.io (📖 271).

Connecting Using an IP Address

Connect to Frame.io using a manually-created network/USB setting profile giving the IP address and other network settings.

1 Select **MANUAL**.



Select **AUTO** to assign the camera an IP address automatically.

2 Enter an IP address.



- Select **IP ADDRESS** and enter an IP address.

- Select **SUBNET MASK** and enter a subnet mask.



- Select **GATEWAY ADDRESS** and enter a gateway address.

- Select **DNS SERVER ADDRESS** and enter a DNS server address.



Connection Status

The status of the connection to Frame.io is shown by an icon in the electronic viewfinder or LCD monitor.



Icon	Connection status
frame.io **(white)**	Connected to Frame.io.
frame.io **(amber)**	Camera has temporarily suspended upload to Frame.io. To resume, select **Frame.io Camera to Cloud** > **UPLOAD SETTING** > **TRANSFER/SUSPEND** > **TRANSFER**.
frame.io **(gray)**	Not connected to Frame.io.
frame.io ⊗ **(red)**	Frame.io server has set camera status to "paused". To restore connection, clear "paused" status using a computer or other device.

Uploading Items to Frame.io

Uploading Selected Items Using "Frame.io Camera to Cloud"

1 Select **Frame.io Camera to Cloud** in network/USB settings menu.

2 Select **UPLOAD SETTING** > **SELECT IMAGE & TRANSFER**.



- The **NETWORK** and **Frame.io** field show the status of the connection to Frame.io.
- The **PROJECT** and **USER** fields show information supplied to Frame.io using a computer or other device. Note that some characters may not display correctly, in which case they will be replaced by question marks ("?").

3 Mark items for upload.
Highlight photos and movies and press **MENU/OK** to mark them for upload.



- To display only items that meet selected criteria, press **DISP/BACK** before marking begins.
- To select all items, press the **Q** button.
- Selecting any two items with the **AE-L** button also selects all items between them.

4 Press **DISP/BACK** and select **START TRANSFER**.
The selected items will be uploaded to Frame.io.



Filtering Items

To display only items that meet selected criteria, press **DISP/BACK** in the selection dialog and select **FILTERING**.



Selecting **FILTERING** removes any existing upload marking.

- Image transfer orders can contain a maximum of 9999 items.
- If **ON** is selected for **Frame.io Camera to Cloud** > **IMAGE TRANSFER WHILE POWER OFF**, upload will continue even while the camera is off.

Uploading Photos and Movies as They Are Taken

Photos and movies shot with **ON** selected for **Frame.io Camera to Cloud** > **UPLOAD SETTING** > **AUTO IMAGE TRANSFER ORDER** in the network/USB setting menu are automatically marked for upload.

Selecting Photos and Movies for Upload During Playback

If **Frame.io TRANSFER ORDER** is selected for **BUTTON/DIAL SETTING** > **Fn BUTTON SETTING**, you can mark files for upload or change or remove their upload marking using the **Fn** button during playback.

RAW Processing

Using X RAW STUDIO, you can harness the power of the camera's image processing engine when processing RAW pictures on a computer.

1. Select either **AUTO** or **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.
2. Select **USB RAW CONV./BACKUP RESTORE** for **CONNECTION MODE**.
3. Connect the camera to the computer via USB and then turn the camera on (📖 278).
4. Launch X RAW STUDIO.
   RAW processing can be performed using X RAW STUDIO.

Visit the website below for information on the software used.
https://fujifilm-x.com/products/software/

Saving and Loading Settings

Camera settings can be saved to or loaded from computers using FUJIFILM TETHER APP.

Saving and Loading Settings Using a Computer

1. Select either **AUTO** or **POWER SUPPLY OFF/COMM ON** for **USB POWER SUPPLY/COMM SETTING** in the network/USB setting menu.
2. Select **USB RAW CONV./BACKUP RESTORE** for **CONNECTION MODE**.
3. Connect the camera to the computer via USB and then turn the camera on (📖 278).
4. Launch FUJIFILM TETHER APP.
   Camera settings can be saved or loaded using FUJIFILM TETHER APP.

Visit the website below for information on the software used.
https://fujifilm-x.com/products/software/

Connecting via a USB Cable

Depending on the Network/USB features used, you can connect the camera to smartphones or computers via a USB cable.

Connecting to a Smartphone

How you connect the camera depends on your smartphone model or the type of USB connector on your smartphone.

USB Type-C Connector (Android/iOS)

Ready a cable equipped with connectors matching the USB (Type-C) connector on the camera.



Lightning Connector (iOS)

Requires a third-party USB cable and an Apple adapter. *



* Use an Apple Lightning to USB Camera Adapter or Lightning to USB 3 Camera Adapter.

The desired results cannot be achieved with a USB Type-C–to–Lightning cable. Use an Apple Lightning to USB Camera Adapter or Lightning to USB 3 Camera Adapter.

Connecting to a Computer

1. Turn the camera off.
2. Turn the computer on.
3. Connect a USB cable.



USB connector (Type-C)

The USB cable must be no more than 1 m (3.3 ft.) long and be suitable for data transfer.

Network/USB Setting Menus

Adjust camera network and USB settings.

To access network/USB settings from the shooting or playback display, press **MENU/OK** and select the (network/USB setting) tab.



Bluetooth/SMARTPHONE SETTING

Adjust Bluetooth-related settings as well as a variety of smartphone-related settings.

Be sure your smartphone or tablet is running the latest version of the smartphone app.

PAIRING REGISTRATION

Pair the camera with a smartphone or tablet to which the smartphone app has been installed.

SELECT PAIRING DESTINATION

Choose a connection from a list of devices with which the camera has been paired using **PAIRING REGISTRATION**. Select **NO CONNECTION** to exit without connecting.

DELETE PAIRING REG.

Delete existing pairing information for a smartphone or tablet.

The selected device will be removed from the pairing list.

Bluetooth DEVICE LIST

List the devices with which the camera is paired (other than the smartphone) or end pairing with selected devices.

Bluetooth ON/OFF

If **ON** is selected, the camera will automatically connect with paired smartphones or tablets running the smartphone app.

Options	
ON	**OFF**

AUTO IMAGE TRANSFER ORDER

Select **ON** to upload pictures automatically as they are taken.

Options	
ON	**OFF**

SMARTPHONE LOCATION SYNC.

Select **ON** to enable ongoing download of location data from paired smartphones or tablets.

Options	
ON	**OFF**

Location data will only be downloaded while the smartphone app is running. Download will be interrupted if pairing is ended. The camera location data icon will be displayed in red if location data have not been updated for over 30 minutes.

NAME

Choose a name (**NAME**) to identify the camera on the wireless network (the camera is assigned a unique name by default).

CONNECT WHILE POWER OFF

Select **ON** to maintain a Bluetooth connection with a smartphone even when the camera is turned off. With the smartphone app FUJIFILM XApp, images can be transferred and the camera can be turned on to take photos even when the camera is turned off.

Options	
ON	**OFF**

IMAGE TRANSFER WHILE POWER OFF

If **ON** is selected, the camera will continue to upload pictures to paired smartphones or tablets even while off.

Options	
ON	**OFF**

RESIZE IMAGE FOR SMARTPHONE

Select **ON** (recommended) to enable compression, reducing file size for upload.

Options	
ON	**OFF**

- The pictures on the camera memory card are not affected.
- Compression is used only for pictures taken at sizes of L and M.

SELECT FILE TYPE

Choose the types of files uploaded. You can select or deselect each file type individually.

Options		
JPEG	RAW	HEIF

AIRPLANE MODE

Select **ON** to disable the camera's wireless LAN and Bluetooth features.

Options	
ON	**OFF**

NETWORK SETTING

Adjust settings for connection to wireless networks. Select a registered network and then select **EDIT** to change the selected network setting.

Option	Description
ACCESS POINT SETTING	• **SIMPLE SETUP**: Connect to an access point using simple settings. • **MANUAL SETUP**: Manually adjust settings for connection to a wireless network. Choose the network from a list (**SELECT FROM NETWORK LIST**) or enter the name manually (**ENTER SSID**).
IP ADDRESS SETTING	• **AUTO**: The IP address is assigned automatically. • **MANUAL**: Assign an IP address manually. Manually choose the IP address (**IP ADDRESS**), subnet mask (**SUBNET MASK**), gateway address (**GATEWAY ADDRESS**), and DNS server address (**DNS SERVER ADDRESS**).

instax IMAGE QUALITY MODE

Set the image quality when printing pictures using the optional smartphone printer "FUJIFILM instax Link" series (📖 250).

Frame.io Camera to Cloud

Adjust settings for use with Frame.io.

CONNECT

You can connect to the Frame.io project via wireless LAN.

If you have not registered the network, register the network in the **NETWORK SETTING** before proceeding.

DISCONNECT

End the connection to the Frame.io project and terminate the network connection.

GET PAIRING CODE

A pairing code will be displayed to connect to the Frame.io project. Enter this code on the Frame.io screen accessed from your personal computer or tablet to connect Frame.io and the camera.

SELECT FILE TYPE

Choose the types of files uploaded to Frame.io. You can select or deselect each file type individually.

Options		
MOV/MP4	JPEG	RAW
HEIF	TIFF	

UPLOAD SETTING

Adjust Frame.io upload settings.

SELECT IMAGE & TRANSFER

Mark pictures for upload.

AUTO IMAGE TRANSFER ORDER

Select **ON** to automatically mark photos and movies for upload as they are taken.

Options	
ON	**OFF**

TRANSFER/SUSPEND

Pause or resume upload to Frame.io.

Options	
TRANSFER	**SUSPEND**

IMAGE TRANSFER WHILE POWER OFF

If **ON** is selected, upload of files to Frame.io will continue while the camera is off.

Options	
ON	**OFF**

ROOT CERTIFICATE

Copy a root certificate to the camera for use with Frame.io.

Option	Description
LOAD FROM STORAGE MEDIA	Copy the root certificate from the camera memory card.
DELETE	Delete the current root certificate.

UPLOAD STATUS

View Frame.io upload status.

TRANSFER QUEUE

View a list of the files awaiting upload.

RESET TRANSFER ORDER

Remove upload marking from all files selected for upload to Frame.io.

CONNECTION MODE

Adjust settings for connection to external devices.

Option	Description
USB CARD READER	Connecting the camera to a computer via USB automatically enables data transfer mode, allowing data to be copied to the computer. The camera functions normally when not connected.
USB WEBCAM	Connect the camera to a computer via USB for use as a webcam.
USB RAW CONV./ BACKUP RESTORE	Connecting the camera to a computer via USB automatically enables USB RAW conversion/backup restore mode. The camera functions normally when not connected. • **USB RAW CONV. (requires FUJIFILM X RAW STUDIO)**: Use the camera's image processing engine to rapidly convert RAW files to other formats while maintaining image quality. • **BACKUP RESTORE (requires FUJIFILM TETHER APP)**: Save and load camera settings. Reconfigure the camera in an instant or share settings with other cameras of the same type.

For information on compatible computer software, see "Software and Services for Use with Your Camera" (📖 371).

USB POWER SUPPLY/COMM SETTING

Choose whether USB connections to computers, smartphones, or other devices are used for power delivery or data transfer.

Option	Description
AUTO	The camera switches between power delivery and data transfer automatically.
POWER SUPPLY ON/ COMM OFF	The camera draws power from the connected device, reducing the drain on the battery. Data transfer is disabled.
POWER SUPPLY OFF/COMM ON	The camera can exchange data with, but not draw power from, the connected device.

The camera cannot draw power from Lightning connections or from devices that do not supply power. Select **POWER SUPPLY OFF/COMM ON** before connecting the camera to such devices. The connection may not be available for data transfer or the like when **POWER SUPPLY ON/COMM OFF** is selected.

Regardless of the option selected, the battery will charge while the camera is off.

INFORMATION

View the camera's MAC, Bluetooth, and wireless network IP addresses.

RESET NETWORK/USB SETTING

Reset network/USB settings to default values.

9 The Setup Menus

USER SETTING

Adjust basic camera settings.

To access basic camera settings, press **MENU/OK**, select the (**SET UP**) tab, and choose **USER SETTING**.



FORMAT

To format a memory card:

1. Select **USER SETTING** > **FORMAT** in the (**SET UP**) tab.
2. A confirmation dialog will be displayed. To format the memory card, highlight **OK** and press **MENU/OK**.



To exit without formatting the memory card, select **CANCEL** or press **DISP/BACK**.

- All data—including protected pictures—will be deleted from the memory card. Be sure important files have been copied to a computer or other storage device.
- Do not open the battery-chamber cover during formatting.

The format menu can also be displayed by pressing and holding the center of the rear command dial while pressing and holding the (Delete) button.

AREA SETTING

Adjust settings for your current time zone.

AREA SETTING

Choose your time zone from a map.

DAYLIGHT SAVINGS

Turn daylight saving time on or off.

Option	Description
ON	Daylight saving time on.
OFF	Daylight saving time off.

DATE/TIME

To set the camera clock:

1. Select **USER SETTING** > **DATE/TIME** in the (**SET UP**) tab.
2. Press the focus stick (focus lever) left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the focus stick up or down.
3. Press **MENU/OK** to set the clock.

TIME DIFFERENCE

Switch the camera clock instantly from your home time zone to the local time at your destination when traveling. To specify the difference between your local and home time zone:

Use **AREA SETTING** to choose your home time zone before selecting a local time zone using **LOCAL**.

1. Highlight **LOCAL** and press **MENU/OK**.
2. Use the focus stick (focus lever) to choose the local time zone. Press **MENU/OK** when settings are complete.

Select **ON** to enable daylight saving time.

To set the camera clock to local time, highlight **LOCAL** and press **MENU/OK**. To set the clock to the time in your home time zone, select **HOME**.

Options	
LOCAL	**HOME**

If **LOCAL** is selected, will be displayed in yellow for about three seconds when the camera is turned on.

言語/LANG.

Choose a language.

MY MENU SETTING

Edit the items listed in the MY (**MY MENU**) tab, a personalized custom menu of frequently-used photo menu options (📖 331).

MY MENU SETTING

Edit the items listed in the MY (**MY MENU**) tab, a personalized custom menu of frequently-used movie menu options (📖 331).

SENSOR CLEANING

Remove dust from the camera image sensor.

Option	Description
OK	Clean the sensor immediately.
WHEN SWITCHED ON	Sensor cleaning will be performed when the camera is turned on.
WHEN SWITCHED OFF	Sensor cleaning will be performed when the camera turns off (sensor cleaning is not however performed if the camera turns off in playback mode).

Dust that cannot be removed using sensor cleaning can be removed using a blower (📖 389).

SOUND & FLASH

Select **OFF** to disable the speaker, flash, illuminator, and self-timer lamp in situations in which camera sounds and lights may be unwelcome.

Options	
ON	**OFF**

FIRMWARE UPDATE

Use the firmware stored on a memory card to update the firmware for the camera, lenses, and other accessories (📖 390).

RESET

Reset shooting or setup menu options to default values.

1 Highlight the desired option and press **MENU/OK**.

Option	Description
STILL MENU RESET	Reset all photo menu settings other than custom white balance and custom settings banks created using **EDIT/SAVE CUSTOM SETTING** to default values.
MOVIE MENU RESET	Reset all movie menu settings other than custom white balance and custom settings banks created using **EDIT/SAVE CUSTOM SETTING** to default values.
SET-UP RESET	Reset all setup menu settings other than **DATE/TIME**, **AREA SETTING**, **TIME DIFFERENCE**, and **COPYRIGHT INFO** to default values.
INITIALIZE	Reset all settings other than custom white balance to default values.

2 A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK**.

SUPPORT WEBSITE

Display the QR code for the support website of the camera. Use your smartphone or another device to scan the code to access the website.

REGULATORY

To view electronic copies of the product model number, FCC/ISED regulatory information, and other certificates, select **USER SETTING** > **REGULATORY** in the setup menu.

SOUND SETTING

Make changes to camera sounds.

To access sound settings, press **MENU/OK**, select the (**SET UP**) tab, and choose **SOUND SET-UP**.



AF BEEP VOL.

Choose the volume of the beep that sounds when the camera focuses. The beep can be muted by selecting **OFF**.

Options			
(high)	(medium)	(low)	**OFF** (mute)

SELF-TIMER BEEP VOL.

Choose the volume of the beep that sounds while the self-timer is active. The beep can be muted by selecting **OFF**.

Options			
(high)	(medium)	(low)	**OFF** (mute)

OPERATION VOL.

Adjust the volume of the sounds produced when camera controls are operated. Choose **OFF** to disable control sounds.

Options			
(high)	(medium)	(low)	**OFF** (mute)

REC START/STOP VOLUME

Choose the volume at the start and end of movie recording.

Options			
(high)	(medium)	(low)	**OFF** (mute)

M S EF ELECTRONIC SHUTTER VOLUME

Adjust the volume of the sounds produced by the mechanical or electronic front-curtain shutter.

Options			
(high)	(medium)	(low)	**OFF** (mute)

MSEF ELECTRONIC SHUTTER SOUND

Choose the sound made by the mechanical or electronic front-curtain shutter.

Options		
♪ 1 SOUND 1	♪ 2 SOUND 2	♪ 3 SOUND 3

ES ELECTRONIC SHUTTER VOLUME

Adjust the volume of the sounds produced by the electronic shutter. Choose **OFF** to disable the shutter sound.

Options			
(high)	(medium)	(low)	**OFF** (mute)

ES ELECTRONIC SHUTTER SOUND

Choose the sound made by the electronic shutter.

Options		
♪ 1 SOUND 1	♪ 2 SOUND 2	♪ 3 SOUND 3

PLAYBACK VOLUME

Adjust the volume for movie playback.

Options										
0	1	2	3	4	5	6	7	8	9	10

SCREEN SETTING

Make changes to display settings.

To access display settings, press **MENU/OK**, select the (**SET UP**) tab, and choose **SCREEN SET-UP**.



VIEW MODE SETTING

Adjust settings for eye sensor, EVF (electronic viewfinder), or LCD monitor view modes (18).

EVF BRIGHTNESS

Adjust the brightness of the display in the electronic viewfinder.

Option	Description
AUTO	The camera automatically adjusts brightness around a selected level in response to changes in ambient lighting conditions.
MANUAL	Adjust brightness manually; choose from options between –7 and +5.

Selecting –6 or –7 darkens the display and does not indicate a malfunction.

EVF COLOR

Adjust the saturation of the display in the electronic viewfinder.

Options										
–5	**–4**	**–3**	**–2**	**–1**	**0**	**+1**	**+2**	**+3**	**+4**	**+5**

EVF COLOR ADJUSTMENT

Adjust the color of the display in the electronic viewfinder.

1 Adjust colors using the focus stick (focus lever).



2 Press **MENU/OK**.

LCD BRIGHTNESS

Adjust monitor brightness.

Options										
–5	**–4**	**–3**	**–2**	**–1**	**0**	**+1**	**+2**	**+3**	**+4**	**+5**

LCD COLOR

Adjust monitor saturation.

Options										
–5	**–4**	**–3**	**–2**	**–1**	**0**	**+1**	**+2**	**+3**	**+4**	**+5**

LCD COLOR ADJUSTMENT

Adjust the color of the display in the LCD monitor.

1 Adjust colors using the focus stick (focus lever).

2 Press **MENU/OK**.

IMAGE DISP.

Choose how long images are displayed after shooting.

Option	Description
CONTINUOUS	Pictures are displayed until the **MENU/OK** button is pressed or the shutter button is pressed halfway. To zoom in on the active focus point, press the center of the rear command dial; press again to cancel zoom.
1.5 SEC	Pictures are displayed for the selected time or until the shutter button is pressed halfway.
0.5 SEC	
OFF	Pictures are not displayed after shooting.

- Colors may differ slightly from those in the final image.
- "Noise" mottling may be visible at high sensitivities.

AUTOROTATE DISPLAYS

Choose whether the indicators in the viewfinder and LCD monitor rotate to match camera orientation.

Options	
ON	**OFF**

PREVIEW EXP./WB IN MANUAL MODE

Choose whether to enable exposure and/or white balance preview in manual exposure mode.

Option	Description
PREVIEW EXP./WB	Enable exposure and white balance preview.
PREVIEW WB	Preview white balance only. Choose this option in situations in which exposure is likely to change during shooting, as may be the case when you use a flash during daylight.
OFF	Disable exposure and white balance preview. Choose this option in situations in which both exposure and white balance are likely to change during shooting, as may be the case when you use a flash with an incandescent monitoring lamp.

NATURAL LIVE VIEW

Choose whether the effects of film simulation, white balance, and other settings are visible in the monitor.

Option	Description
ON	The effects of camera settings are not visible in the monitor, but shadows in low-contrast, back-lit scenes and other hard-to-see subjects more visible. Colors and tone will differ from those in the final picture. The display will however be adjusted to show the effects of monochrome and sepia settings.
OFF	The effects of film simulation, white balance, and other settings can be previewed in the monitor.

F-Log VIEW ASSIST

Select **ON** to display a tone-corrected preview (equivalent to BT.709) when recording or viewing F-log movies.

Options	
ON	**OFF**

ELECTRONIC LEVEL SETTING

Adjust settings for use when taking pictures using the virtual horizon display (📖 25).

FRAMING GUIDELINE

Choose a framing grid for shooting mode.

	Option		
	GRID 9	**GRID 24**	**HD FRAMING**
Display	 *For "rule of thirds" composition.*	 *A six-by-four grid.*	 *Frame HD pictures in the crop shown by the lines at the top and bottom of the display.*

Framing guides are not shown at default settings but can be displayed using **SCREEN SET-UP** > **DISP. CUSTOM SETTING** (📖 23).

AUTOROTATE PB

Choose **ON** to automatically rotate "tall" (portrait-orientation) pictures during playback.

Options	
ON	**OFF**

FOCUS SCALE UNITS

Choose the units used for the focus distance indicator.

Options	
METERS	**FEET**

APERTURE UNIT FOR CINEMA LENS

Choose whether the camera displays aperture as a T-number (used for movie camera lenses) or an f/-number (used for still camera lenses) when an optional FUJINON MKX-series lens is attached. For information on using cinema lenses, see the documentation provided with the lens.

Option	Description
T NUMBER	A measure of lens aperture commonly used by cinematographers. Lens transmittance is taken into account to better calculate exposure.
F NUMBER	A measure of lens aperture commonly used by photographers. Lens transmittance is assumed to be 100%, meaning that the same aperture may produce different exposures depending on the lens.

DISP. CUSTOM SETTING

Choose the items shown in the standard indicator display (📖 23).

LARGE INDICATORS MODE(EVF)

Select **ON** to display large indicators in the electronic viewfinder. The indicators displayed can be selected using **SCREEN SET-UP** > **LARGE INDICATORS DISP. SETTING**.



OFF



ON

Some icons are not displayed when **ON** is selected for **LARGE INDICATORS MODE(EVF)** (📖 15).

If **LARGE INDICATORS MODE** is assigned to a function button, the button can be used to toggle **LARGE INDICATORS MODE** on (**ON**) and off (**OFF**) (📖 339).

LARGE INDICATORS MODE(LCD)

Select **ON** to display large indicators in the LCD monitor. The indicators displayed can be selected using **SCREEN SET-UP** > **LARGE INDICATORS DISP. SETTING.**



OFF



ON

Some icons are not displayed when **ON** is selected for **LARGE INDICATORS MODE(LCD)** (17).

If **LARGE INDICATORS MODE** is assigned to a function button, the button can be used to toggle **LARGE INDICATORS MODE** on (**ON**) and off (**OFF**) (339).

LARGE INDICATORS DISP. SETTING

Choose the indicators displayed when **ON** is selected for **SCREEN SET-UP** > **LARGE INDICATORS MODE(EVF)** or **LARGE INDICATORS MODE(LCD)**.



Option	Description
① **Expo. DISP.**	Choose the items listed at the bottom of the display. Selected items are indicated by check marks (☑); to deselect, highlight the check marks and press **MENU/OK**.
② **Scale**	Select **ON** to display the exposure indicator.
③ **L1, L2, L3, L4**	Choose up to four large icons for display on the left side of the screen.
④ **R1, R2, R3, R4**	Choose up to four large icons for display on the right side of the screen.

INFORMATION CONTRAST ADJ.

Adjust display contrast.

Option	Description
HIGH CONTRAST	High contrast.
STANDARD	Normal contrast.
LOW CONTRAST	Low contrast.
DARK AMBIENT LIGHTING	Contrast adjusted for dim ambient lighting.

LOCATION INFO

Select **ON** to display location info downloaded from a smartphone.

Options	
ON	**OFF**

Q MENU BACKGROUND

Choose the background color used for the quick menu when it is displayed during still photography.

Options	
TRANSPARENT	**BLACK**

Q MENU BACKGROUND

Choose the background color used for the quick menu when it is displayed during movie recording.

Options	
TRANSPARENT	**BLACK**

BUTTON/DIAL SETTING

Access options for camera controls.

To access control options, press **MENU/OK**, select the (**SET UP**) tab, and choose **BUTTON/DIAL SETTING**.



FOCUS LEVER SETTING

Choose the functions performed by pressing the center of the focus stick (focus lever) or by pressing the stick up, down, left, or right.

PUSH

Option	Description
OFF	Pressing the center of the stick has no effect.
EDIT FOCUS AREA	Press the center of the stick to choose the focus area size. If **FACE/EYE DETECTION SETTING** or **SUBJECT DETECTION SETTING** is on, you can instead position the focus frame over the desired face, eye, animal, or object.
ZOOM	Press the center of the stick to zoom in on the active focus area (📖 90).
RESET TO CENTER	Press the center of the stick to select the center focus area.

TILT ☼

Option	Description
OFF	Pressing the stick up, down, left, or right has no effect.
DIRECT AF POINT SELECTION	Choose the focus area without leaving the shooting display.
EDIT FOCUS AREA	Press the stick up, down, left, or right to view a focus-area display and choose the focus area.

EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu during still photography (📖 333).

EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu when filming movies (📖 333).

FUNCTION (Fn) SETTING

Choose the roles played by the function buttons (📖 339).

POWER ZOOM LENS FUNCTION (Fn) SETTING

Choose the roles played by the function buttons available on some power zoom lenses (📖 345).

COMMAND DIAL SETTING

Choose the roles played by the command dials.

Option	Description
FRONT COMMAND DIAL 1	Assign **S.S. (PROGRAM SHIFT)**, **APERTURE**, or **FILM SIMULATION** to **FRONT COMMAND DIAL 1**.
FRONT COMMAND DIAL 2	Assign **S.S. (PROGRAM SHIFT)**, **APERTURE**, **EXPOSURE COMPENSATION**, **ISO**, **FILM SIMULATION**, or **NONE** to **FRONT COMMAND DIAL 2**, **FRONT COMMAND DIAL 3**, or **FRONT COMMAND DIAL 4**.
FRONT COMMAND DIAL 3	
FRONT COMMAND DIAL 4	
REAR COMMAND DIAL	Assign **S.S. (PROGRAM SHIFT)**, **APERTURE**, **EXPOSURE COMPENSATION**, **ISO**, **FILM SIMULATION**, or **NONE** to the rear command dial.

- **COMMAND DIAL SETTING** can also be accessed by pressing and holding the center of the front command dial.
- You can also press the center of the front command dial to cycle through settings in the order **FRONT COMMAND DIAL 1**, **FRONT COMMAND DIAL 2**, **FRONT COMMAND DIAL 3**, and **FRONT COMMAND DIAL 4**.

S.S. OPERATION

Select **OFF** to disable shutter-speed fine-tuning using the command dials.

Options	
ON	**OFF**

COMMAND DIAL DIRECTION

Choose the direction in which the command dials are rotated to choose values. Settings for the front and rear command dials can be adjusted separately.

Option	Description
− ⟷ +	Rotate the dial right for higher values or to move to the next item.
+ ⟷ −	Rotate the dial left for higher values or to move to the next item.

SHUTTER AF

Choose whether the camera focuses when the shutter button is pressed halfway.

Option	Description
AF-S	• **ON**: Focus locks when the shutter button is pressed halfway. • **OFF**: No focus operation is performed when the shutter button is pressed halfway.
AF-C	• **ON**: The camera focuses while the shutter button is pressed halfway. • **OFF**: No focus operation is performed when the shutter button is pressed halfway.

SHUTTER AE

If **ON** is selected, exposure will lock while the shutter button is pressed halfway. The setting for focus mode **C** (AF-C) can be adjusted separately from that for modes **S** (AF-S) and **M** (manual focus).

Options	
ON	**OFF**

Select **OFF** to allow the camera to adjust exposure before each shot taken in burst mode.

SHOOT WITHOUT LENS

Choose **ON** to enable the shutter release when no lens is attached.

Options	
ON	**OFF**

SHOOT WITHOUT CARD

Choose whether the shutter can be released without a memory card inserted in the camera.

Option	Description
ON	When no memory card is inserted, the shutter can be released to test camera function and the shooting and setup menus can be displayed.
OFF	The shutter is disabled if no memory card is inserted, preventing accidental loss of pictures taken without a memory card.

LENS ZOOM/FOCUS SETTING

Adjust settings for compatible lenses with focus rings or power zoom.

FOCUS RING ROTATE

Choose the direction in which the focus ring is rotated to increase the focus distance.

Options	
CW (clockwise)	**CCW** (counterclockwise)

FOCUS RING OPERATION

Adjust settings for the focus shift when operating the focus ring during still photography.

NONLINEAR

Focus is adjusted at the same rate as the ring is rotated.

LINEAR

Focus is adjusted linearly according to the amount the ring is rotated. The rotation angle of the focus ring can also be set when focusing between the minimum focus distance and infinity.

Option	Description
DEFAULT	Disable the settings for the maximum rotation angle of the focus ring. The maximum rotation angle varies depending on the lens.
90°/180°/270°/360°	Set the maximum rotation angle of the focus ring. Select **CUSTOM 1**, **CUSTOM 2**, or **CUSTOM 3** to set the rotation angle from 60 ° to 900 ° in 10 ° increments.
CUSTOM 1 **CUSTOM 2** **CUSTOM 3**	

FOCUS RING OPERATION

Adjust settings for the focus shift when operating the focus ring during movie recording.

NONLINEAR

Focus is adjusted at the same rate as the ring is rotated.

LINEAR

Focus is adjusted linearly according to the amount the ring is rotated. The rotation angle of the focus ring can also be set when focusing between the minimum focus distance and infinity.

Option	Description
DEFAULT	Disable the settings for the maximum rotation angle of the focus ring. The maximum rotation angle varies depending on the lens.
90°/180°/270°/360°	Set the maximum rotation angle of the focus ring. Select **CUSTOM 1**, **CUSTOM 2**, or **CUSTOM 3** to set the rotation angle from 60 ° to 900 ° in 10 ° increments.
CUSTOM 1 **CUSTOM 2** **CUSTOM 3**	

MF CONSTANT SPEED FOCUS (Fn)

Choose the rate at which the focus distance changes when adjusted using function buttons during manual focus with compatible power zoom lenses. The higher the number, the higher the rate.

Options							
1(SLOW)	**2**	**3**	**4**	**5**	**6**	**7**	**8(FAST)**

CONSTANT SPEED ZOOM (Fn)

Choose the rate at which compatible power zoom lenses can be zoomed in or out using function buttons. The higher the number, the higher the rate.

Options							
1(SLOW)	2	3	4	5	6	7	8(FAST)

CONSTANT SPEED ZOOM/FOCUS (Fn) OPERATION

Choose whether the function buttons on compatible power zoom lenses need only be pressed once to start and stop power focus or power zoom.

Option	Description
START/STOP SWITCH	The operation starts when the button is pressed and stops when it is pressed a second time.
ACTIVE WHILE PRESSING	The operation continues while the button is pressed and stops when the button is released.

ZOOM RING ROTATE

Choose whether to reverse the rotation of the zoom ring on compatible power zoom lenses.

Options	
CW (clockwise)	**CCW** (counterclockwise)

ZOOM/FOCUS CONTROL RING

Choose role played by the zoom/focus control ring on compatible power zoom lenses.

Options	
ZOOM	FOCUS

AE/AF-LOCK MODE

This option determines the behavior of the button to which exposure and/or focus lock is assigned.

Option	Description
AE&AF ON WHEN PRESSING	Exposure and/or focus will lock while the button is pressed.
AE&AF ON/OFF SWITCH	Exposure and/or focus will lock when the button is pressed and remain locked until it is pressed again.

AWB-LOCK MODE

Choose the behavior of function buttons assigned auto white balance (AWB) lock. Auto white balance lock is used to lock white balance at the value metered by the camera when **WHITE PRIORITY**, **AUTO**, or **AMBIENCE PRIORITY** is selected for white balance.

Option	Description
AWB ON WHEN PRESSING	Auto white balance locks while the button is pressed.
AWB ON/OFF SWITCH	Press the button once to lock auto white balance and again to end the lock.

APERTURE RING SETTING (A)

Choose whether the front command dial can be used to adjust aperture when aperture is set to **A** (auto).

Option	Description
AUTO	The camera adjusts aperture automatically.
COMMAND	Aperture can be adjusted using the front command dial.

APERTURE SETTING

Choose the method used to adjust aperture when using lenses with no aperture rings.

Option	Description
AUTO + MANUAL	Rotate the front command dial to choose the aperture. Rotate past minimum aperture to choose **A** (auto).
AUTO	Aperture is selected automatically; camera functions in exposure mode **P** (program AE) or **S** (shutter-priority AE).
MANUAL	Rotate the front command dial to choose the aperture; camera functions in exposure mode **A** (aperture-priority AE) or **M** (manual).

Fn BUTTON SETTING

Choose the role performed by the **Fn** button during playback.

Option	Description
SMARTPHONE TRANSFER ORDER	Pressing the button marks the current picture for transfer. If the camera is not currently paired with a smartphone, **Bluetooth/SMARTPHONE SETTING** options will be displayed.
SELECT & SMARTPHONE TRANSFER ORDER	Pressing the button displays a dialog where pictures can be selected for upload to a smartphone with which the camera is paired (📖 244). If the camera is not currently paired with a smartphone, **Bluetooth/SMARTPHONE SETTING** options will be displayed instead.
Frame.io TRANSFER ORDER	Pressing the button marks the current picture for upload to Frame.io.

TOUCH SCREEN SETTING

Enable or disable touch-screen controls.

TOUCH SCREEN SETTING

Option	Description
ON	The LCD monitor functions as a touch screen during shooting.
OFF	Touch controls disabled.

DOUBLE TAP SETTING

Option	Description
ON	Tap the LCD monitor twice to zoom in on your subject during shooting.
OFF	Touch zoom disabled.

TOUCH FUNCTION

Option	Description
ON	Enable touch-function gestures.
OFF	Disable touch-function gestures.

TOUCH ZOOM

Option	Description
ON	If the lens supports touch zoom, you can zoom in and out by touching the LCD monitor (📖 32).
OFF	Touch zoom disabled.

▶ TOUCH SCREEN SETTING

Option	Description
ON	The LCD monitor functions as a touch screen during playback.
OFF	Touch controls disabled.

EVF TOUCH SCREEN AREA SETTINGS

Select the area of the LCD monitor used for touch controls while the viewfinder is active. The area used for touch controls can be selected from:

Option	Description
	All.
	Right half.
	Top right quarter.
	Bottom right quarter.
	Left half.
	Top left quarter.
	Bottom left quarter.
OFF	Touch controls disabled.

LOCK

Lock selected controls to prevent unintended operation.

Option	Description
LOCK SETTING	Choose from the following: • **UNLOCK**: Reset lock options. • **ALL FUNCTION**: Lock all controls in the **FUNCTION SELECTION** list. • **SELECTED FUNCTION**: Lock only the controls selected in the **FUNCTION SELECTION** list.
FUNCTION SELECTION	Choose the controls locked when **SELECTED FUNCTION** is chosen for **LOCK SETTING**.

The controls selected using **SELECTED FUNCTION** can be locked at any time during shooting by pressing and holding **MENU/OK**. To unlock the controls, press and hold the button again.

POWER MANAGEMENT

Adjust power management settings.

To access power management settings, press **MENU/OK**, select the (**SET UP**) tab, and choose **POWER MANAGEMENT**.



AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually.

Options					
5 MIN	2 MIN	1 MIN	30 SEC	15 SEC	OFF

PERFORMANCE

Select **BOOST** to improve focus and viewfinder display performance.

Option	Description
BOOST	Boost camera focus and viewfinder display performance. The battery drains faster than when is **NORMAL** selected.
NORMAL	Choose for standard focus and viewfinder display performance and battery endurance.
ECONOMY	Limit autofocus and viewfinder performance. This option offers better battery endurance than does **NORMAL**.

EVF/LCD BOOST SETTING

Adjust the behavior of the EVF and LCD monitor when **BOOST** is selected for **PERFORMANCE**.

Option	Description
EVF/LCD LOW LIGHT PRIORITY	Display brightness is adjusted to make subjects in shadows easier to see. Motion blur may cause ghosting.
EVF/LCD RESOLUTION PRIORITY	Display resolution is increased to make details easier to see.
EVF FRAME RATE PRIORITY (100P)	The refresh rate for the EVF is increased, smoothing motion.

AUTO POWER OFF TEMP.

If its temperature rises beyond a certain point, the camera will first display a message and then, if the temperature rise continues, automatically end shooting and power down. Choose the temperature at which the camera turns off automatically.

Option	Description
STANDARD	The camera turns off automatically when its temperature reaches the **STANDARD** value.
HIGH	Shooting can continue at temperatures higher than the **STANDARD** value, extending the time available to record movies and the like. Because remaining in contact with the camera at these high temperatures could result in low-temperature burns, this option should only be used after mounting the camera on a tripod or taking other steps to avoid prolonged contact with the camera.

SAVE DATA SETTING

Make changes to file management settings.

To access file management settings, press **MENU/OK**, select the **SET UP** (**SET UP**) tab, and choose **SAVE DATA SET-UP**.



FRAME NO.

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed during playback as shown. **FRAME NO.** controls whether file numbering is reset to 0001 when a new memory card is inserted or the current memory card is formatted.



Option	Description
CONTINUOUS	Numbering continues from the last file number used or the first available file number, whichever is higher. Choose this option to reduce the number of pictures with duplicate file names.
RENEW	Numbering is reset to 0001 after formatting or when a new memory card is inserted.

- If the frame number reaches 999-9999, the shutter release will be disabled. Select **RENEW**, turn the camera off, and insert a formatted memory card before resuming shooting.
- Selecting **USER SETTING** > **RESET** sets **FRAME NO.** to **CONTINUOUS** but does not reset the file number.
- Frame numbers for pictures taken with other cameras may differ.

EDIT FILE NAME

Change the file name prefix. sRGB images use a four-letter prefix (default "DSCF"), Adobe RGB images a three-letter prefix ("DSF") preceded by an underscore.

Option	Default prefix	Sample file name
sRGB	DSCF	ABCD0001
AdobeRGB	_DSF	_ABC0001

SELECT FOLDER

Create folders and choose the folder used to store subsequent pictures.

Option	Description
SELECT FOLDER	To choose the folder in which subsequent pictures will be stored, press the focus stick (focus lever) up or down to highlight an existing folder and press **MENU/OK**.
CREATE FOLDER	Enter a five-character folder name. The new folder will be created with the next picture you take and subsequent pictures will be stored in that folder.

COPYRIGHT INFO

Copyright information, in the form of Exif tags, can be added to new images as they are taken. Changes to copyright information are reflected only in images taken after the changes are made.

Option	Description
DISP COPYRIGHT INFO	View the current copyright information.
ENTER AUTHOR'S INFO	Enter the creator's name.
ENTER COPYRIGHT INFO	Enter the name of the copyright holder.
DELETE COPYRIGHT INFO	Delete the current copyright information. This change applies only to images taken after this option is selected; copyright information recorded with existing images is not affected.

GEOTAGGING

If **ON** is selected, location data downloaded from a smartphone will be embedded in pictures as they are taken.

Options	
ON	**OFF**

10 Shortcuts

Shortcut Options

Customize camera controls to suit your style or situation.

Frequently-used options can be added to the Q menu or a custom "my" menu or assigned to a function button or touch-function gesture for direct access:

Shortcut Option	Description	📖
"My menu"	Add frequently-used options to this custom menu, which can be viewed by pressing **MENU/OK** and selecting the MY ("MY MENU") tab.	331
The Quick Menu	The **Q** menu is displayed by pressing the **Q** button. Use the **Q** menu to view or change the options selected for frequently-used menu items.	333
The function buttons	Use the function buttons for direct access to selected features.	339
Touch-function gestures	Use touch function button flick gestures (**T-Fn1**, **T-Fn2**, **T-Fn3**, and **T-Fn4**) for direct access to selected features.	343
Lens function buttons	Use the function buttons on the lens (if any) for direct access to selected features.	345

MY MENU

Access a personalized menu of frequently-used options.

To display "my menu", press **MENU/OK** in the shooting display and select the MY (**MY MENU**) tab.

The MY tab is only available if options have been assigned to **MY MENU**.

MY MENU SETTING

To choose the items listed in the MY (**MY MENU**) tab:

1. In the setup menu, select **USER SETTING** > **MY MENU SETTING** or **MY MENU SETTING**.



To reorder items, select **RANK ITEMS**. To delete items, select **REMOVE ITEMS**.

2. Press the focus stick (focus lever) up or down to highlight **ADD ITEMS** and press **MENU/OK**. Options that can be added to "my menu" are highlighted in blue.



Items currently in "my menu" are indicated by check marks.

3 Select a menu to be registered and press the **MENU/OK** button. Press the **MENU/OK** button again to return to the menu selection screen.

4 Select a menu to be registered next and press the **MENU/OK** button. Select the order of the menus to be registered and press the **MENU/OK** button.



5 Repeat Step 4 and register "my menu".
To exit "my menu" registration, press the **DISP/BACK** button.

"My menu" can contain up to 16 items.

The Quick Menu

Use the quick menu for quick access to selected options. To view the quick menu, press the **Q** button.

The Quick Menu Display

The quick menu offers different options in photo and movie modes. At default settings, it contains the following items:

Still photography



Default	
① SELECT CUSTOM SETTING *	⑨ SELF-TIMER
② AF MODE	⑩ FACE/EYE DETECTION SETTING
③ ISO	⑪ SUBJECT DETECTION SETTING
④ FLASH FUNCTION SETTING	⑫ EVF/LCD BRIGHTNESS
⑤ IMAGE SIZE	⑬ HIGHLIGHT TONE
⑥ IMAGE QUALITY	⑭ SHADOW TONE
⑦ FILM SIMULATION	⑮ COLOR
⑧ WHITE BALANCE	⑯ SHARPNESS

* If no settings bank is currently selected for **SELECT CUSTOM SETTING**, the shooting mode will be displayed instead.

The quick menu shows the options currently selected for items ②–⑯, which can be changed.

Movie recording



Default	
① SELECT CUSTOM SETTING*	⑤ APERTURE (MOVIE OPTIMIZED CONTROL)
② S.S. (MOVIE OPTIMIZED CONTROL)	⑥ ISO
③ MOVIE MODE RESOLUTION/ ASPECT RATIO	⑦ MOVIE MODE FRAME RATE
④ WHITE BALANCE	⑧ WHITE BALANCE COLOR TEMP. (WHEN K SELECTED)

* If no settings bank is currently selected for **SELECT CUSTOM SETTING**, the shooting mode will be displayed instead.

The quick menu shows the options currently selected for items ②–⑧, which can be changed.

Viewing and Changing Settings

1 Press **Q** to display the quick menu during shooting.



2 Use the focus stick (focus lever) to highlight items and rotate the rear command dial to change.





To jump to the **EDIT/SAVE CUSTOM SETTING** or **EDIT/SAVE CUSTOM SETTING** menu, press and hold the **Q** button when the quick menu is displayed.

3 Press **Q** to exit when settings are complete.

- The quick menu can also be edited using touch controls.
- Using **BUTTON/DIAL SETTING** > **FUNCTION (Fn) SETTING**, you can assign the **Q** button roles normally reserved for the function buttons or assign the **Q** button's default role to a function button (339).
- To disable the **Q** (quick menu) button, select **NONE** for **BUTTON/DIAL SETTING** > **FUNCTION (Fn) SETTING** > **Q BUTTON SETTING**.

Editing the Quick Menu

To choose the items displayed in the quick menu:

1 Press and hold the **Q** button during shooting.



The camera displays the photo quick menu during still photography and the movie quick menu when in movie mode.

2 The current quick menu will be displayed; use the focus stick (focus lever) to highlight the item you wish to change and press **MENU/OK**.

3 Highlight the item you wish to change and press **MENU/OK**. The following can be assigned to the quick menu.

The quick menus can also be edited using **BUTTON/DIAL SETTING** > **EDIT/SAVE QUICK MENU** or **EDIT/SAVE QUICK MENU**.

Available Items (Still Photography)

Choose from:

- IMAGE SIZE
- IMAGE QUALITY
- FILM SIMULATION
- GRAIN EFFECT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- WHITE BALANCE COLOR TEMP. (WHEN K SELECTED)
- HIGHLIGHT TONE
- SHADOW TONE
- COLOR
- SHARPNESS
- CLARITY
- HIGH ISO NR
- PORTRAIT ENHANCER LV
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE/EYE DETECTION SETTING
- SUBJECT DETECTION SETTING
- MF ASSIST
- TOUCH SCREEN MODE
- SELF-TIMER
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- ISO
- FLASH FUNCTION SETTING
- FLASH COMPENSATION
- MOVIE MODE RESOLUTION/ASPECT RATIO
- MOVIE MODE FRAME RATE
- BIT RATE
- HIGH SPEED REC
- IS MODE
- IS MODE BOOST
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- CONNECT TO ATOMOS AirGlu BT
- SOUND & FLASH
- EVF/LCD BRIGHTNESS
- EVF/LCD COLOR
- NONE

To disable the quick menu item, choose **NONE**.

Available Items (Movies)

- FILM SIMULATION
- DYNAMIC RANGE
- WHITE BALANCE
- WHITE BALANCE COLOR TEMP. (WHEN K SELECTED)
- HIGHLIGHT TONE
- SHADOW TONE
- COLOR
- SHARPNESS
- HIGH ISO NR
- PORTRAIT ENHANCER LV
- FACE/EYE DETECTION SETTING
- SUBJECT DETECTION SETTING
- MF ASSIST
- TOUCH SCREEN MODE
- PHOTOMETRY
- MOVIE ISO
- MOVIE MODE RESOLUTION/ASPECT RATIO
- MOVIE MODE FRAME RATE
- BIT RATE
- HIGH SPEED REC
- 9:16 SHORT MOVIE MODE
- SELF-TIMER
- MOVIE AF MODE
- FIX MOVIE CROP MAGNIFICATION
- IS MODE
- IS MODE BOOST
- S.S. (MOVIE OPTIMIZED CONTROL)
- APERTURE (MOVIE OPTIMIZED CONTROL)
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- CONNECT TO ATOMOS AirGlu BT
- SOUND & FLASH
- EVF/LCD BRIGHTNESS
- EVF/LCD COLOR
- NONE

To disable the quick menu item, choose **NONE**.

Function Controls

Assign a role to each function button or touch-function gesture for quick access to the selected feature.

The Function Buttons

Assign a role to the function buttons for quick access to the selected feature.

Function Button Defaults

The default assignments are:

Back-of-Camera Function Buttons



Function buttons	Default
① **VIEW MODE button**	VIEW MODE SETTING
② **AE-L (exposure lock) button**	AE LOCK ONLY
③ **Center of rear command dial**	FOCUS CHECK
④ **AF-L (focus lock) button**	AF LOCK ONLY
⑤ **Q (quick menu) button**	QUICK MENU

Top-of-Camera Function Buttons



Function buttons	Default
① **Fn button**	FACE DETECTION ON/OFF

Assigning Roles to the Function Buttons

The roles played by the function buttons can be selected using the **BUTTON/DIAL SETTING** > **FUNCTION (Fn) SETTING** option in the setup menu.

- IMAGE SIZE
- IMAGE QUALITY
- RAW
- FS RECIPE
- FILM SIMULATION
- GRAIN EFFECT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- SELECT CUSTOM SETTING
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/LEFT EYE SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- MF ASSIST ON/OFF
- SPORTS FINDER MODE
- PRE-SHOT **ES**
- SELF-TIMER
- AE BKT SETTING

- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- FLASH COMPENSATION
- FLASH FUNCTION SETTING
- TTL-LOCK
- MODELING FLASH
- MOVIE RECORDING RELEASE
- HIGH SPEED REC
- 9:16 SHORT MOVIE MODE
- SELF-TIMER
- FIX MOVIE CROP MAGNIFICATION
- IS MODE BOOST
- PORTRAIT ENHANCER LV
- ZEBRA SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- MOVIE OPTIMIZED CONTROL
- CONNECT TO ATOMOS AirGlu BT
- VIEW MODE SETTING
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP./WB IN MANUAL MODE
- NATURAL LIVE VIEW
- HISTOGRAM
- ELECTRONIC LEVEL SWITCH
- LARGE INDICATORS MODE
- F-Log VIEW ASSIST
- COMMAND DIAL LOCK
- ZOOM/FOCUS CONTROL RING
- CONSTANT SPEED ZOOM (T)
- CONSTANT SPEED ZOOM (W)
- MF CONSTANT SPEED FOCUS (N)
- MF CONSTANT SPEED FOCUS (F)
- AE LOCK ONLY
- AF LOCK ONLY
- AE/AF LOCK
- AF-ON
- AWB LOCK ONLY
- APERTURE SETTING
- LOCK SETTING
- PERFORMANCE
- AUTO IMAGE TRANSFER ORDER
- Bluetooth ON/OFF
- QUICK MENU
- PLAYBACK
- NONE

To disable the function button, choose **NONE**.

AF-ON

Controls to which **AF-ON** is assigned can be used for autofocus.

MODELING FLASH

If **MODELING FLASH** is selected when a compatible shoe-mounted flash unit is attached, you can press the control to test-fire the flash and check for shadows and the like (modeling flash).

TTL-LOCK

If **TTL-LOCK** is selected, you can press the control to lock flash output according to the option selected for **FLASH SETTING** > **TTL-LOCK MODE** (📖 185).

RECALL CUSTOM 1 SETTING

Controls to which **RECALL CUSTOM 1 SETTING** has been assigned can be pressed to temporarily recall the settings saved to **C1** (CUSTOM 1). Pressing the button a second time restores the previous settings.

Touch-Function Gestures

Assign roles to touch-function gestures (**T-Fn1**, **T-Fn2**, **T-Fn3**, or **T-Fn4**) for quick access to selected features.

Touch-function gestures are disabled by default. To enable touch-function gestures, select **ON** for **BUTTON/DIAL SETTING** > **TOUCH SCREEN SETTING** > **TOUCH FUNCTION**.

Touch-Function Gesture Defaults

The default assignments for the different gestures are:



Touch-Function Gestures	Default
① **T-Fn1 (flick up)**	HISTOGRAM
② **T-Fn2 (flick left)**	FILM SIMULATION
③ **T-Fn3 (flick right)**	ELECTRONIC LEVEL SWITCH
④ **T-Fn4 (flick down)**	AF MODE

Assigning Roles to Touch-Function Gestures

The roles played by touch-function gestures can be selected using the **BUTTON/DIAL SETTING** > **FUNCTION (Fn) SETTING** option in the setup menu.

- IMAGE SIZE
- IMAGE QUALITY
- RAW
- FS RECIPE
- FILM SIMULATION
- GRAIN EFFECT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- SELECT CUSTOM SETTING
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/LEFT EYE SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- MF ASSIST ON/OFF
- SPORTS FINDER MODE
- PRE-SHOT ES
- SELF-TIMER
- AE BKT SETTING
- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- FLASH COMPENSATION
- FLASH FUNCTION SETTING
- TTL-LOCK
- MODELING FLASH
- HIGH SPEED REC
- SELF-TIMER
- FIX MOVIE CROP MAGNIFICATION
- IS MODE BOOST
- PORTRAIT ENHANCER LV
- ZEBRA SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- MOVIE OPTIMIZED CONTROL
- CONNECT TO ATOMOS AirGlu BT
- VIEW MODE SETTING
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP./WB IN MANUAL MODE
- NATURAL LIVE VIEW
- HISTOGRAM
- ELECTRONIC LEVEL SWITCH

- LARGE INDICATORS MODE
- F-Log VIEW ASSIST
- COMMAND DIAL LOCK
- ZOOM/FOCUS CONTROL RING
- APERTURE SETTING
- LOCK SETTING
- PERFORMANCE
- AUTO IMAGE TRANSFER ORDER
- Bluetooth ON/OFF
- QUICK MENU
- PLAYBACK
- NONE

To disable touch-function gestures, choose **NONE**.

Lens Function Buttons

Choose the roles played by the function buttons on the lens (where applicable).

Lens Function Button Defaults

The default assignments are:

A XF18-120mmF4 LM PZ WR lens is used here for illustrative purposes.



Lens function button	Default
① **Z/F**	ZOOM/FOCUS CONTROL RING
② **L-Fn1 (rocker zoom button pressed up)**	CONSTANT SPEED ZOOM (T)
③ **L-Fn2 (rocker zoom button pressed down)**	CONSTANT SPEED ZOOM (W)

Assigning Roles to the Lens Function Buttons

The roles played by the lens function buttons can be selected using the **BUTTON/DIAL SETTING** > **POWER ZOOM LENS FUNCTION (Fn) SETTING** option in the setup menu.

- IMAGE SIZE
- IMAGE QUALITY
- RAW
- FS RECIPE
- FILM SIMULATION
- GRAIN EFFECT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- SELECT CUSTOM SETTING
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/LEFT EYE SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- MF ASSIST ON/OFF
- SPORTS FINDER MODE
- PRE-SHOT ES
- SELF-TIMER
- AE BKT SETTING
- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- FLASH COMPENSATION
- FLASH FUNCTION SETTING
- TTL-LOCK
- MODELING FLASH
- MOVIE RECORDING RELEASE
- HIGH SPEED REC
- 9:16 SHORT MOVIE MODE
- SELF-TIMER
- FIX MOVIE CROP MAGNIFICATION
- IS MODE BOOST
- PORTRAIT ENHANCER LV
- ZEBRA SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- MOVIE OPTIMIZED CONTROL
- CONNECT TO ATOMOS AirGlu BT
- VIEW MODE SETTING
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP./WB IN MANUAL MODE
- NATURAL LIVE VIEW
- HISTOGRAM
- ELECTRONIC LEVEL SWITCH

- LARGE INDICATORS MODE
- F-Log VIEW ASSIST
- COMMAND DIAL LOCK
- ZOOM/FOCUS CONTROL RING
- CONSTANT SPEED ZOOM (T)
- CONSTANT SPEED ZOOM (W)
- MF CONSTANT SPEED FOCUS (N)
- MF CONSTANT SPEED FOCUS (F)
- AE LOCK ONLY
- AF LOCK ONLY
- AE/AF LOCK
- AF-ON
- AWB LOCK ONLY
- APERTURE SETTING
- LOCK SETTING
- PERFORMANCE
- AUTO IMAGE TRANSFER ORDER
- Bluetooth ON/OFF
- QUICK MENU
- PLAYBACK
- NONE

- To disable the function button, choose **NONE**.
- Selected function lock is not available when **CONSTANT SPEED ZOOM (T)** or **CONSTANT SPEED ZOOM (W)** is assigned to a lens function button (📖 323).

MEMO

11 Peripherals and Optional Accessories

Lenses

The camera can be used with lenses for the FUJIFILM X-mount.

Lens Parts



1. *Lens hood*
2. *Mounting marks*
3. *Focus ring*
4. *Zoom ring*
5. *Aperture ring*
6. *Mounting marks (focal length)*
7. *Aperture mode switch*
8. *Lens signal contacts*
9. *Front lens cap*
10. *Rear lens cap*

A XF16-50mmF2.8-4.8 R LM WR lens is used here for illustrative purposes.

Lens Care

- Use a blower to remove dust, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of Fujifilm lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied.
- Replace the front and rear caps when the lens is not in use.

Removing Lens Caps

Remove lens caps as shown.





Lens caps may differ from those shown.

Attaching Lens Hoods

When attached, lens hoods reduce glare and protect the front lens element.



Lenses with Aperture Rings

At settings other than **A**, you can adjust aperture by rotating the lens aperture ring (exposure modes **A** and **M**).



Aperture ring

- Selecting **ON** for **MOVIE OPTIMIZED CONTROL** disables the aperture ring.
- When the aperture ring is set to **A**, rotate the command dials to adjust aperture.

The Aperture Mode Switch

If the lens has an aperture mode switch, aperture can be adjusted manually by sliding the switch to and rotating the aperture ring.



Aperture ring

Aperture mode switch

Lenses with No Aperture Rings

Aperture can be adjusted using the front command dial in modes **A** (aperture-priority AE) and **M** (manual).



Aperture control can be reassigned to the rear command dial using **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.

Lenses with O.I.S. Switches

If the lens supports optical image stabilization (O.I.S.), the image stabilization mode can be chosen in the camera menus. To activate image stabilization, slide the O.I.S. switch to **ON**.



O.I.S. switch

Manual Focus Lenses

Slide the focus ring to the front for auto-focus.



For manual focus, slide the focus ring to the back and rotate it while checking the results in the camera display. The focus distance and depth-of-field indicators can be used to assist manual focus.



Note that manual focus may not be available in all shooting modes.

The Depth-of-Field Indicator

The depth-of-field indicator shows the approximate depth of field (the distance in front of and behind the focus point that appears to be in focus). The indicator is displayed in film format.



Power Zoom Lenses

Zoom can be adjusted on power zoom lenses using the zoom/focus control ring, zoom button, or zoom ring.

Adjusting zoom while the lens is wet makes it easier for water to find its way inside the lens. Wipe any water from the lens before adjusting zoom.

A XF18-120mmF4 LM PZ WR lens is used here for illustrative purposes.



Control	Description
① **Zoom ring**	Rotate the zoom ring to zoom in or out manually.
② **Zoom/focus control ring**	Rotate the zoom/focus control ring to zoom in or out using powered zoom. The zoom speed is proportional to the speed with which the ring is rotated.
③ **Z/F (zoom/focus) button**	Switch the role of zoom/focus control ring from focus to zoom or *vice versa*.
④ **Zoom buttons**	Press a zoom button to zoom in or out at a steady speed using powered zoom. Zoom ends when the button is pressed a second time.

- The **Z/F** and zoom buttons can be assigned other roles using **BUTTON/DIAL SETTING** > **POWER ZOOM LENS FUNCTION (Fn) SETTING**.
- The speed at which zoom can be adjusted via the zoom buttons can be chosen using **BUTTON/DIAL SETTING** > **LENS ZOOM/FOCUS SETTING**.

External Flash Units

Use optional external flash units for flash photography. Some units support high-speed sync (FP) and can be used at shutter speeds faster than the flash sync speed, while others can function as commanders controlling remote units via optical wireless flash control.

You may be unable to test-fire the flash in some circumstances, for example when a setup menu is displayed on the camera.

Red-Eye Removal

Red-eye removal is available when **FLASH** is selected for **FLASH SETTING** > **RED EYE REMOVAL**. Red-eye removal minimizes "red-eye" caused when light from the flash is reflected from the subject's retinas.

Flash Sync Speed

The flash will synchronize with the shutter at shutter speeds of 1/180 s or slower.

Optional Flash Units from Fujifilm

The camera can be used with optional Fujifilm shoe-mounted flash units.

Third-Party Flash Units

Do not use third-party flash units that apply over 300 V to the camera hot shoe. Set the flash control mode to **M** when using a flash unit that does not support TTL flash control.

Using an External Flash

1 Connect the unit to the camera.

2 In shooting mode, select **FLASH FUNCTION SETTING** in the ϟ (**FLASH SETTING**) menu tab. The options available vary with the flash unit.



Menu	Description	📖
Built-In Flash	Displayed when the built-in flash is raised.	120
SYNC TERMINAL	Sync terminal options will be displayed if the built-in flash is lowered and either no flash unit, or an incompatible flash unit, is mounted on the hot shoe.	359
SHOE MOUNT FLASH	Displayed when an optional flash unit other than the EF-X8 is mounted on the hot shoe and turned on.	360
COMMANDER (OPTICAL)	Displayed if an optional flash unit functioning as a commander for Fujifilm optical wireless remote flash control is connected and turned on.	363

3 Highlight items using the focus stick (focus lever) and rotate the rear command dial to change the highlighted setting.



4 Press **DISP/BACK** to put the changes into effect.

SYNC TERMINAL

SYNC TERMINAL is displayed if the built-in flash is lowered and either no flash unit, or an incompatible flash unit, is mounted on the hot shoe.



Setting	Description
(1) Flash control mode	Choose from the following options: • **M**: A trigger signal is transmitted via the hot shoe X contacts when a picture is taken. Choose a shutter speed slower than the sync speed; even slower speeds may be required if the unit uses long flashes or has a slow response time. • **OFF (OFF)**: The trigger signal is disabled.
(2) Sync	Choose whether the flash is timed to fire immediately after the shutter opens (**1ST CURTAIN**) or immediately before it closes (**2ND CURTAIN**). **1ST CURTAIN** is recommended in most circumstances.

SHOE MOUNT FLASH

The following options are available when an optional shoe-mounted flash unit is attached and turned on.



Setting	Description
① Flash control mode	The flash control mode selected with the flash unit. This can in some cases be adjusted from the camera; the options available vary with the flash. • **TTL**: TTL mode. Adjust flash compensation (②). • **M**: The flash fires at the selected output regardless of subject brightness or camera settings. Output in some cases can be adjusted from the camera (②). • **MULTI**: Repeating flash. Compatible shoe-mounted flash units will fire multiple times with each shot. • **OFF (OFF)**: The flash does not fire. Some flash units can be turned off from the camera.

Setting	Description
② Flash compensation/ output	The options available vary with flash control mode. • **TTL**: Adjust flash compensation (the full value may not be applied if the limits of the flash control system are exceeded). In the cases of the EF-X20, EF-20, and EF-42, the selected value is added to the value selected with the flash unit. • **M/MULTI**: Adjust flash output (compatible units only). Choose from values expressed as fractions of full power, from 1⁄1 (mode **M**) or 1⁄4 (**MULTI**) down to 1⁄512 in increments equivalent to 1⁄3 EV. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results.
③ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (**P**, **S**, **A**, or **M**) selected. • **TTL AUTO (FLASH AUTO)**: The flash fires only as required; flash level is adjusted according to subject brightness. A ⚡ icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • **TTL (STANDARD)**: The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • **TTL SLOW (SLOW SYNC.)**: Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.

Setting	Description
④ Sync	Control flash timing. • **(1ST CURTAIN)**: The flash fires immediately after the shutter opens (generally the best choice). • **(2ND CURTAIN)**: The flash fires immediately before the shutter closes. • **(AUTO FP(HSS))**: High-speed sync (compatible units only). The camera automatically engages front-curtain high-speed sync at shutter speeds faster than the flash sync speed. Equivalent to **1ST CURTAIN** when **MULTI** is selected for flash control mode. Note: Horizontal bands may appear in pictures taken using **AUTO FP(HSS)** at some shutter speeds.
⑤ Zoom	The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to be made from the camera. If **AUTO** is selected, zoom will automatically be adjusted to match coverage to lens focal length.
⑥ Lighting	If the unit supports this feature, choose from: • **(FLASH POWER PRIORITY)**: Gain range by slightly reducing coverage. • **(STANDARD)**: Match coverage to picture angle. • **(EVEN COVERAGE PRIORITY)**: Slightly increase coverage for more even lighting.
⑦ LED light	Choose how the built-in LED light functions during still photography (compatible units only): as a catchlight (/**CATCHLIGHT**), as an AF-assist illuminator (**AF**/**AF ASSIST**), or as both a catchlight and an AF-assist illuminator (/**AF ASSIST+CATCHLIGHT**). Choose **OFF** to disable the LED during photography.
⑦ Number of flashes *	Choose the number of times the flash fires each time the shutter is released in **MULTI** mode.
⑧ Frequency *	Choose the frequency at which the flash fires in **MULTI** mode.

* Full value may not be applied if limits of flash control system are exceeded.

COMMANDER(OPTICAL)

The options will be displayed if the unit is currently functioning as a commander for Fujifilm optical wireless remote flash control.



Fujifilm optical wireless remote flash control offers a choice of four channels (Channels 1 through 4) for the exchange of optical signals between the commander and remote flash units. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.

The flash units can also be placed in up to three groups (A, B, and C) and flash mode and flash level adjusted separately for each group.



Setting	Description
① Flash control mode (group A)	Choose flash control modes for groups A, B, and C. **TTL%** is available for groups A and B only. • **TTL**: The units in the group fire in TTL mode. Flash compensation can be adjusted separately for each group. • **TTL%**: If **TTL%** is selected for either group A or B, you can specify the output of the selected group as a percentage of the other and adjust overall flash compensation for both groups. • **M**: In mode **M**, the units in the group fire at the selected output (expressed as a fraction of full power) regardless of subject brightness or camera settings. • **MULTI**: Choosing **MULTI** for any group sets all the units in all groups to repeating flash mode. All units will fire multiple times with each shot. • **OFF (OFF)**: If **OFF** is selected, the units in the group will not fire.
② Flash control mode (group B)	
③ Flash control mode (group C)	
④ Flash compensation/ output (group A)	Adjust flash level for the selected group according to option selected for flash control mode. Note that the full value may not be applied if the limits of the flash control system are exceeded. • **TTL**: Adjust flash compensation. • **M/MULTI**: Adjust flash output. • **TTL%**: Choose the balance between groups A and B and adjust overall flash compensation.
⑤ Flash compensation/ output (group B)	
⑥ Flash compensation/ output (group C)	

Setting	Description
⑦ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (**P**, **S**, **A**, or **M**) selected. • **i-TTL AUTO (FLASH AUTO)**: The flash fires only as required; flash level is adjusted according to subject brightness. A ⚡ icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • **i-TTL (STANDARD)**: The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • **i-TTL SLOW (SLOW SYNC.)**: Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.
⑧ Sync	Control flash timing. • **FRONT (1ST CURTAIN)**: The flash fires immediately after the shutter opens (generally the best choice). • **REAR (2ND CURTAIN)**: The flash fires immediately before the shutter closes. • **FP (AUTO FP(HSS))**: High-speed sync (compatible units only). The camera automatically engages front-curtain high-speed sync at shutter speeds faster than the flash sync speed. Equivalent to **1ST CURTAIN** when **MULTI** is selected for flash control mode.
⑨ Zoom	The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to be made from the camera. If **AUTO** is selected, zoom will automatically be adjusted to match coverage to lens focal length.

Setting	Description
⑩ Lighting	If the unit supports this feature, choose from: • **(FLASH POWER PRIORITY)**: Gain range by slightly reducing coverage. • **(STANDARD)**: Match coverage to picture angle. • **(EVEN COVERAGE PRIORITY)**: Slightly increase coverage for more even lighting.
⑪ Commander	Choose the group for units functioning as a commander for Fujifilm optical wireless remote flash control in **TTL**, **TTL%**, or **M** mode. This option is available only with clip-on flash units that support Fujifilm optical wireless remote flash control. • **Gr A**: Assign the commander to group A. • **Gr B**: Assign the commander to group B. • **Gr C**: Assign the commander to group C. • **OFF**: Output from the commander is held to a level that does not affect the final picture.
⑪ Number of flashes	Choose the number of times the flash fires each time the shutter is released in **MULTI** mode.
⑫ Channel	Choose the channel used by the commander for communication with the remote flash units. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.
⑫ Frequency	Choose the frequency at which the flash fires in **MULTI** mode.

12 Technical Notes

Accessories from Fujifilm

The following accessories are available from Fujifilm. For the latest information on the accessories available in your region, check with your local Fujifilm representative or visit *https://fujifilm-x.com/support/compatibility/cameras/*.

Rechargeable Li-ion batteries

NP-W126S: Additional high-capacity NP-W126S rechargeable batteries can be purchased as required.

Battery chargers

BC-W126S: Replacement battery chargers can be purchased as required. At +20 °C/+68 °F, the BC-W126S charges an NP-W126S in about 150 minutes.

Remote releases

RR-100: Use to reduce camera shake or keep the shutter open during a time exposure. The RR-100 has a connector with a diameter of 2.5 mm.

Stereo microphones

MIC-ST1: An external microphone for movie recording.

FUJINON lenses

XF-/XC-series lenses: Interchangeable lenses for use exclusively with the FUJIFILM X-mount.

FUJINON MKX-series lenses: Cinema lenses for the FUJIFILM X-mount.

Macro extension tubes

MCEX-11/16: Attach between the camera and the lens to shoot at high reproduction ratios.

Teleconverters

XF1.4X TC WR: Increases the focal length of the compatible lenses by about 1.4×.

XF2X TC WR: Increases the focal length of the compatible lenses by about 2.0×.

Mount adapters

FUJIFILM M MOUNT ADAPTER: Allows the camera to be used with a wide selection of M-mount lenses.

Shoe-mounted flash units

EF-X500: In addition to manual and TTL flash control, this clip-on flash unit has a Guide Number of 50/164 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. Featuring support for the optional EF-BP1 battery pack and Fujifilm optical wireless flash control, it can be used as a commander or remote flash unit for remote wireless flash photography.

EF-BP1: A battery pack for EF-X500 flash units. Takes up to 8 AA batteries.

EF-60: In addition to manual and TTL flash control, this clip-on flash unit has a Guide Number of 60/197 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. It can also be used as remote flash under the control of an optional EF-W1 wireless commander.

EF-W1: With support for the NAS* wireless communication standard developed by Nissin Japan, this wireless flash commander can be used with optional EF-60 clip-on flash units and other NAS-compliant units.

* NAS is a registered trademark of Nissin Japan Ltd.

EF-42: This clip-on flash unit has a Guide Number of 42/137 (ISO 100, m/ft.) and supports manual and TTL flash control.

EF-X20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.) and supports manual and TTL flash control.

EF-20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.) and supports TTL flash control (manual flash control is not supported).

Tripod grips

TG-BT1: Record movies, take photographs, or adjust zoom on compatible power zoom lenses while holding this Bluetooth tripod grip.

Hand grips

MHG-XT10: Features an improved grip. Batteries and memory cards can be removed with the grip in place, and the grip is equipped with a rail for quick-shoe camera mounts.

Grip belts

GB-001: Improves grip.

Body caps

BCP-001: Cover the camera lens mount when no lens is attached.

Smartphone printers

instax Link series printers: When connected to a paired device via Bluetooth, this printer can be used to quickly and easily print pictures on instax film.

Software and Services for Use with Your Camera

The camera can be used with the following software and services. For the latest information on software available from Fujifilm, visit

https://fujifilm-x.com/support/compatibility/cameras/.

Smartphone Apps

Establish a wireless connection between your camera and a smartphone or tablet.

https://fujifilm-dsc.com/

RAW FILE CONVERTER EX powered by SILKYPIX

RAW FILE CONVERTER EX powered by SILKYPIX is RAW conversion software from Adwaa Co., Ltd. View RAW pictures on your computer and convert them into other formats. RAW FILE CONVERTER EX powered by SILKYPIX is available free of charge from the Fujifilm website.

https://fujifilm-x.com/support/download/software/raw-file-converter-ex-powered-by-silkypix/

- "RAW FILE CONVERTER EX powered by SILKYPIX" is supplied by Adwaa Co., Ltd.
- Visit the website above for information on when support will be available.

FUJIFILM RAW Converter

View RAW pictures on your computer and convert them into other formats. FUJIFILM RAW Converter is available free of charge from Capture One A/S.

https://www.captureone.com/a/leaflet-fujifilm#rawconverter

Visit the website above for information on when the support will be available.

Capture One

Capture One workflow software from Capture One A/S supports tethered shooting and the conversion of RAW pictures into other formats.

https://www.captureone.com/a/leaflet-fujifilm

The camera does not support tethered photography.

Visit the website above for information on when the support will be available.

FUJIFILM TETHER APP

This provides the functionality to utilize the "GFX/X Series" digital cameras by connecting them to computers. The save/load function for camera settings can be used even for cameras that do not support tethered photography. This can also be used as a tethered photography plug-in for Adobe Lightroom Classic.

https://fujifilm-x.com/products/software/tether-app/

FUJIFILM X RAW STUDIO

When the camera is connected to a computer via USB, FUJIFILM X RAW STUDIO can use the camera's unique image processing engine to rapidly convert RAW files to create high-quality images in other formats.

https://fujifilm-x.com/products/software/x-raw-studio/

Frame.io Camera to Cloud

Send still images and movies directly from the camera to the Frame.io platform via a network.

https://frame.io/

IMPORTANT SAFETY INSTRUCTIONS

- ***Read Instructions***: All the safety and operating instructions should be read before the appliance is operated.
- ***Retain Instructions***: The safety and operating instructions should be retained for future reference.
- ***Heed Warnings***: All warnings on the appliance and in the operating instructions should be adhered to.
- ***Follow Instructions***: All operating and use instructions should be followed.

Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

Alternate Warnings: This video product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

Overloading: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

Ventilation: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. This video product should never be placed near or over a radiator or heat register.

Attachments: Do not use attachments not recommended by the video product manufacturer as they may cause hazards.

Water and Moisture: Do not use this video product near water—for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.

Power-Cord Protection: Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

Antennas

Outdoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE



Power Lines: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

Use

Cleaning: Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service: Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged
- If liquid has been spilled, or objects have fallen into the video product.
- If the video product has been exposed to rain or water.
- If the video product has been dropped or the cabinet has been damaged.

If the video product does not operate normally follow the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performance — this indicates a need for service.

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

Be sure to read these notes before use

Safety Notes

- Make sure that you use your camera correctly. Read these safety notes and your *Basic Manual* carefully before use.
- After reading these safety notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.

WARNING	This icon indicates that death or serious injury can result if the information is ignored.
CAUTION	This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the instructions which are to be observed.

	Triangular icons tell you that this information requires attention ("Important").
	Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").
	Filled circles with an exclamation mark indicate an action that must be performed ("Required").

The symbols on the product (including the accessories) represent the following:

	AC
	DC
	Class II equipment (The construction of the product is double-insulated.)

⚠ WARNING

Unplug from power socket	***If a problem arises, turn the camera off, remove the battery, and disconnect the USB cable.*** Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock. Contact your Fujifilm dealer.
	Do not allow water or foreign objects to enter the camera or connecting cables. Do not use the camera or connecting cables following ingress of fresh or salt water, milk, beverages, detergents, or other liquids. ***Should liquid find its way into the camera or connecting cables, turn the camera off, remove the battery, and disconnect the USB cable.*** Continued use of the camera can cause a fire or electric shock. Contact your Fujifilm dealer.

⚠ WARNING

Do not use in the bathroom or shower

Do not use the camera in the bathroom or shower. This can cause a fire or electric shock.

Do not disassemble

Never attempt to change or take apart the camera (never open the case). Failure to observe this precaution can cause fire or electric shock.

Do not touch internal parts

Should the case break open as the result of a fall or other accident, do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.

Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord. These actions could damage the cord and cause a fire or electric shock. If the cord is damaged, contact your Fujifilm dealer. Do not use cables with bent connectors.

Do not place the camera on an unstable surface. This can cause the camera to fall or tip over and cause injury.

Never attempt to take pictures while in motion. Do not use shooting, playback, or any other operations of the camera while operating a car or other vehicle. This can result in you falling down or being involved in a traffic accident. If you take pictures while walking, pay attention to your surroundings.

Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from the lightning discharge.

Do not use the battery except as specified. Load the battery as shown by the indicator.



Do not disassemble, modify, or heat batteries. Do not drop, strike, or throw batteries or otherwise subject them to strong impacts. Do not use batteries that show signs of leaking, deformation, discoloration, or other abnormalities. Use only designated chargers to recharge rechargeable batteries and do not attempt to recharge non-rechargeable lithium or alkaline batteries. Do not short batteries or store them with metallic objects. Failure to observe these precautions could result in the batteries overheating, igniting, rupturing, or leaking, causing fire, burns, or other injury.

Use only batteries specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources can cause a fire.

⚠ WARNING

If the battery leaks and fluid gets in contact with your eyes, skin or clothing, flush the affected area with clean water and seek medical attention or call an emergency number right away.

Using a flash too close to a person's eyes may cause visual impairment. Take particular care when photographing infants and young children.

Do not remain in prolonged contact with hot surfaces. Do not leave one part of the body in contact with the product for prolonged periods while the product is on. Failure to observe this precaution could result in low-temperature burns, particularly during prolonged use, at high ambient temperatures, when **HIGH** is selected for **AUTO POWER OFF TEMP.**, or with users who suffer from poor circulation or reduced sensation, in which case use of a tripod or similar precautions are recommended.

Do not use in the presence of flammable objects, explosive gases, or dust.



When carrying the battery, install it in a digital camera or keep it in the hard case. When storing the battery, keep it in the hard case. When discarding, cover the battery terminals with insulation tape. Contact with other metallic objects or batteries could cause the battery to ignite or burst.

Keep memory cards, shoe covers, and other small parts out of the reach of small children. Children may swallow small parts; keep out of reach of children. Should a child swallow a small part, seek medical attention or call emergency.

Keep out of reach of small children. Among the elements that could cause injury are the strap, which could become entangled about a child's neck, causing strangulation, and the flash, which could cause visual impairment.

Follow the directions of airline and hospital personnel. This product generates radio-frequency emissions that could interfere with navigational or medical equipment.

⚠ CAUTION

Do not use this camera in locations affected by oil fumes, steam, humidity or dust. This can cause a fire or electric shock.

Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.

⚠ CAUTION	
	Do not place heavy objects on the camera. This can cause the heavy object to tip over or fall and cause injury.
	Do not cover or wrap the camera or the charger in a cloth or blanket. This can cause heat to build up and distort the casing or cause a fire.
	Do not use the plug if it is damaged or if it does not fit securely into the outlet. Failure to observe this precaution could result in fire or electric shock.
	When you are cleaning the camera or you do not plan to use the camera for an extended period, remove the battery. Failure to do so can cause a fire or electric shock.
	When charging ends, unplug the charger from the power socket. Leaving the charger plugged into the power socket can cause a fire.
	When a memory card is removed, the card could come out of the slot too quickly. Use your finger to hold it and gently release the card. Injury could result to those struck by the ejected card.
	Do not handle the memory card immediately after shooting. The memory card may be hot, resulting in burns. Wait for the card to cool before removing it from the camera.
	Request regular internal testing and cleaning for your camera. Build-up of dust in your camera can cause a fire or electric shock. Contact your Fujifilm dealer to request internal cleaning every two years. Please note that this service is not free of charge.
	Dispose of the product in accord with location regulations.
	Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
	Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Note: *Check the type of battery used in your camera and read the appropriate sections.*

⚠ **WARNING**: *Battery shall not be exposed to excessive heat such as sunshine, fire or the like.*

The following describes the proper use of batteries and how to prolong their life. Incorrect use can shorten battery life or cause leakage, overheating, fire, or explosion.

Li-ion Batteries

Read this section if your camera uses a rechargeable Li-ion battery.

The battery is not charged at shipment. Charge the battery before use. Keep the battery in its case when not in use.

■ Notes on the Battery

The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

Battery life can be extended by turning the camera off when not in use.

Battery capacity decreases at low temperatures; a depleted battery may not function when cold. Keep a fully charged spare battery in a warm place and exchange as necessary, or keep the battery in your pocket or other warm place and insert it in the camera only when shooting. Do not place the battery in direct contact with hand warmers or other heating devices.

■ Charging the Battery

The battery can also be charged using an optional BC-W126S battery charger. Charging times will increase at ambient temperatures below +10 °C (+50 °F) or above +35 °C (+95 °F). Do not attempt to charge the battery at temperatures above +40 °C (+104 °F); at temperatures below +5 °C (+41 °F), the battery will not charge.

Do not attempt to recharge a fully charged battery. The battery does not however need to be fully discharged before charging.

The battery may be warm to the touch immediately after charging or use. This is normal.

■ Battery Life

A noticeable decrease in the length of time the battery will hold a charge indicates that it has reached the end of its service life and should be replaced.

■ Storage

If the camera will not be used for an extended period, store it at room temperature with the battery charged to approximately one half to ⅔ capacity.

If the camera will not be used for an extended period, remove the battery and store it in a dry place with an ambient temperature of from +15 °C to +25 °C (+59 °F to +77 °F). Do not store in locations exposed to extremes of temperature.

■ Cautions: Handling the Battery

- Do not transport or store with metal objects such as necklaces or hairpins.
- Do not expose to flame or heat.
- Do not disassemble or modify.
- Do not expose to low atmospheric pressures.
- Use with designated chargers only.
- Dispose of used batteries promptly.
- Do not drop or subject to strong physical shocks.
- Do not expose to water.
- Keep the terminals clean.
- The battery and camera body may become warm to the touch after extended use. This is normal.

■ Caution: Disposal

Dispose of used batteries in accord with local regulations. Attention should be drawn to the environmental aspects of battery disposal. Use the apparatus under moderate climate.

Do not mechanically crush or split batteries.

Using the Camera

- Do not aim the camera at extremely bright light sources, including artificial light sources or natural light sources such as the sun in a cloudless sky. Failure to observe this precaution could damage the camera image sensor.
- Strong sunlight focused through the viewfinder may damage the panel of electronic viewfinder (EVF). Do not aim the electronic viewfinder at the sun.

Take Test Shots

Before taking photographs on important occasions (such as at weddings or before taking the camera on a trip), take a test shot and view the results to ensure that the camera is functioning normally. FUJIFILM Corporation cannot accept liability for damages or lost profits incurred as a result of product malfunction.

Notes on Copyright

Unless intended solely for personal use, images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner. Note that some restrictions apply to the photographing of stage performances, entertainments, and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

Handling

To ensure that images are recorded correctly, do not subject the camera to impact or physical shocks while images are being recorded.

Liquid Crystal

In the event that the display is damaged, care should be taken to avoid contact with liquid crystal. Take the urgent action indicated should any of the following situations arise:

- **If liquid crystal comes in contact with your skin**, clean the area with a cloth and then wash thoroughly with soap and running water.
- **If liquid crystal enters your eyes**, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- **If liquid crystal is swallowed**, rinse your mouth thoroughly with water. Drink large quantities of water and induce vomiting, then seek medical assistance.

Although the display is manufactured using extremely high-precision technology, it may contain pixels that are always lit or that do not light. This is not a malfunction, and images recorded with the product are unaffected.

Trademark Information

Digital Split Image is a trademark or registered trademark of FUJIFILM Corporation. Digital Micro Prism is a trademark or registered trademark of FUJIFILM Corporation. The typefaces included herein are solely developed by DynaComware Taiwan Inc. Apple, iPhone, iPad, Mac, Mac OS X, OS X, macOS, Lightning and Apple ProRes are registered trademarks of Apple Inc. in the U.S.A. and other countries. Windows is a registered trademark of Microsoft Corporation in the U.S.A. and other countries. Android is a trademark or registered trademark of Google LLC. Adobe, the Adobe logo, Camera to Cloud, Frame.io, Lightroom and Photoshop are either registered trademarks or trademarks of Adobe in the United States and/or other countries. Wi-Fi®, the Wi-Fi CERTIFIED logo, and Wi-Fi Protected Setup® are registered trademarks of the Wi-Fi Alliance®. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc., and any use of such marks by Fujifilm is under license. The SDHC and SDXC logos are trademarks of SD-3C, LLC. CFexpress is a trademark of the CFA (CompactFlash Association). The HDMI logo is a trademark or registered trademark of HDMI Licensing LLC. QR Code is a registered trademark of DENSO WAVE INCORPORATED. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum. AirGlu™ is a trademark or registered trademark of Atomos. All other trade names mentioned in this manual are the trademarks or registered trademarks of their respective owners.

Electrical Interference

This camera may interfere with hospital or aviation equipment. Consult with hospital or airline staff before using the camera in a hospital or on an aircraft.

Color Television Systems

NTSC (National Television System Committee) is a color television telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (Phase Alternation by Line) is a color television system adopted mainly in European countries and China.

Exif Print (Exif Version 2.32)

Exif Print is a newly revised digital camera file format in which information stored with photographs is used for optimal color reproduction during printing.

IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited.

Lenses and Other Accessories

- Use a screw 4.5 mm or shorter when attaching a tripod.
- Fujifilm will not be held liable for performance issues or damage caused by the use of third-party accessories.

NOTICES

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

Please read the "Safety Notes" and make sure you understand them before using the camera.

Perchlorate Material—special handling may apply. See: http://www.dtsc.ca.gov/hazardouswaste/perchlorate

For Customers in the U. S. A.

Tested To Comply With FCC Standards
FOR HOME OR OFFICE USE

Contains IC : 10293A-WMCW26
Contains FCC ID : COF-WMCW26

FCC Statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement: This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

Notes on the Grant: To comply with Part 15 of the FCC Rules, this product must be used with a Fujifilm-specified ferrite-core A/V cable, USB cable, and DC supply cord.

A lithium ion battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY for information on how to recycle this battery.

California Code of Regulations, Title 20, Division 2, Chapter 4, Article 4, Appliance Efficiency Regulations, Sections 1601 through 1609

For Customers in Canada

CAN ICES (B)/NMB (B)

CAUTION: This Class B digital apparatus complies with Canadian ICES-003.

Industry Canada statement: This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter, except tested built-in radios. The County Code Selection feature is disabled for products marketed in the US/ Canada.

Radiation Exposure Statement: The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power Wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research. X-T30 III has been tested and found to comply with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules.

Disposal of Electrical and Electronic Equipment in Private Households

In the European Union, Norway, Iceland and Liechtenstein: This symbol on the product, or in the manual and in the warranty, and/or on its packaging indicates that this product shall not be treated as household waste. Instead it should be taken to an applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

This symbol on the batteries or accumulators indicates that those batteries shall not be treated as household waste.

If your equipment contains easy removable batteries or accumulators please dispose these separately according to your local requirements.

The recycling of materials will help to conserve natural resources. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

In Countries Outside the European Union, Norway, Iceland and Liechtenstein: If you wish to discard this product, including the batteries or accumulators, please contact your local authorities and ask for the correct way of disposal.

In Japan: This symbol on the batteries indicates that they are to be disposed of separately.

Caring for the Camera

To ensure continued enjoyment of the product, observe the following precautions.

Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- exposed to rain, steam, or smoke
- very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- extremely cold
- subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- next to rubber or vinyl products

Wireless Network and Bluetooth Devices: Cautions

This product complies with the following EU Directives:

- RoHS Directive 2011/65/EU
- RE Directive 2014/53/EU

Hereby, FUJIFILM Corporation declares that the radio equipment type FF250003 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
https://dl.fujifilm-x.com/doc/x-t30-iii_doc-alg.pdf

The full text of the UK declaration of conformity is available at the following internet address:
https://dl.fujifilm-x.com/doc/x-t30-iii_doc-alg_uk.pdf

This compliance is indicated by the following conformity marking placed on the product:

CE

This marking is valid for non-Telecom products and EU harmonized Telecom products (e.g. Bluetooth®).

- **Maximum radio-frequency power (EIRP)**:
  WLAN 2.4 GHz: 6.86 dBm
  Bluetooth: -2.98 dBm

IMPORTANT: *Read the following notices before using the camera's built-in wireless transmitter.*

① This product, which contains encryption function developed in the United States, is controlled by the United States Export Administration Regulations and may not be exported or re-exported to any country to which the United States embargoes goods.

- ***Use only a wireless network or Bluetooth device.*** Fujifilm does not accept liability for damages resulting from unauthorized use. Do not use in applications requiring a high degree of reliability, for example in medical devices or other systems that may directly or indirectly impact human life. When using the device in computer and other systems that demand a greater degree of reliability than offered by wireless network or Bluetooth devices, be sure to take all necessary precautions to ensure safety and prevent malfunction.
- ***Use only in the country in which the device was purchased.*** This device conforms to regulations governing wireless network and Bluetooth devices in the country in which it was purchased. Observe all location regulations when using the device. Fujifilm does not accept liability for problems arising from use in other jurisdictions.
- ***Do not use the device in locations subject to magnetic fields, static electricity, or radio interference.*** Do not use the transmitter in the vicinity of microwave ovens or in other locations subject to magnetic fields, static electricity, or radio interference that may prevent reception of wireless signals. Mutual interference may occur when the transmitter is used in the vicinity of other wireless devices operating in the 2.4 GHz band.
- ***The wireless transmitter operates in the 2.4 GHz band using DSSS, OFDM and GFSK modulation.***
- **Security**: Wireless network and Bluetooth devices transmit data via radio and consequently their use requires greater attention to security than applies in the case of wired networks.
  - Do not connect to unknown networks or networks to which you do not have access rights, even if they are displayed on your device, as such access may be considered unauthorized. Connect only to networks to which you have access rights.
  - Be aware that wireless transmissions may be vulnerable to interception by third parties.
  - Do not connect this device directly to telecommunications networks (including public wireless LANs) operated by providers or mobile, landline, Internet, or other telecommunications services.
- ***The following may be punishable by law:***
  - Disassembly or modification of this device
  - Removal of device certification labels
- ***This device operates on the same frequency as commercial, educational, and medical devices and wireless transmitters.*** It also operates on the same frequency as licensed transmitters and special unlicensed low-voltage transmitters used in RFID tracking systems for assembly lines and in other similar applications.
- ***To prevent interference with the above devices, observe the following precautions.*** Confirm that the RFID transmitter is not in operation before using this device. Should you observe that the device causes interference in licensed transmitters used for RFID tracking, immediately stop using the affected frequency or move the device to another location. If you notice that this device causes interference in low-voltage RFID tracing systems, contact a Fujifilm representative.

- ***Do not use this device on board an aircraft.*** When on an aircraft, follow the instructions of airline personnel. Note that this product may emit radio-frequency radiation even when off. This can be prevented by selecting **ON** for **AIRPLANE MODE** in the network/USB setting menu before boarding.

Specific Absorption Rate (SAR) Information

SAR is measured with the device at 0 mm to the body, while transmitting at the highest certified output power level in all frequency bands of the device. The maximum SAR value is 0.029 W/kg (head/body) averaged over 10 gram of tissue.

Charging specifications for this device

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 7.5 Watts in order to achieve the maximum charging speed.

■ Cautions for AC charging



① This product does not include an AC adapter or USB cable.
② Use a USB-IF certified AC adapter or USB-C to USB-C cable when charging with the camera. An AC adapter of 7.5 W or more is recommended.
③ Be sure to read the manual for this product when charging with the camera.
④ Note that we do not guarantee that all commercially available AC adapters and USB cables can be used for charging.
⑤ If any issues arise when using a commercially available AC adapter, remove the plug from the power outlet and the cable from the camera, respectively, to disconnect the power supply.

U.K. Importer:

FUJIFILM UK Ltd.

Fujifilm House, Whitbread Way, Bedford, Bedfordshire, MK42 0ZE, United Kingdom

EU Importer:

FUJIFILM Germany GmbH(FFDE)

Balcke-Dürr-Allee 6, 40882 Ratingen, Germany

Be sure to read these notes before using the lens

Safety Notes

- Make sure that you use the lens correctly. Read these safety notes and the camera *Basic Manual* carefully before use.
- After reading these safety notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.

WARNING	This icon indicates that death or serious injury can result if the information is ignored.
CAUTION	This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the instructions which are to be observed.

	Triangular icons tell you that this information requires attention ("Important").
	Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").
	Filled circles with an exclamation mark indicate an action that must be performed ("Required").

⚠ WARNING

Do not immerse	***Do not immerse in or expose to water.*** Failure to observe this precaution can cause a fire or electric shock.
Do not disassemble	***Do not disassemble (do not open the case).*** Failure to observe this precaution can cause fire, electric shock, or injury due to product malfunction.
Do not touch internal parts	***Should the case break open as the result of a fall or other accident, do not touch the exposed parts.*** Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.
	Do not place on unstable surfaces. The product may fall, causing injury.
	Do not view the sun through the lens or camera viewfinders. Failure to observe this precaution can cause permanent visual impairment.

⚠ CAUTION

	Do not use or store in locations that are exposed to steam, or smoke or are very humid or extremely dusty. Failure to observe this precaution can cause fire or electric shock.
	Do not leave in direct sunlight or in locations subject to very high temperatures, such as in a closed vehide on a sunny day. Failure to observe this precaution can cause fire.
	Keep out of the reach of small children. This product could cause injury in the hands of a child.
	Do not handle with wet hands. Failure to observe this precaution can cause electric shock.
	Keep the sun out of the frame when shooting backlit subjects. Sunlight focused into the camera when the sun is in or close to the frame can cause fire or burns.
	When the product is not in use, replace the lens caps and store out of direct sunlight. Sunlight focused by the lens can cause fire or burns.
	Do not carry the camera or lens while they are attached to a tripod. The product can fall or strike other objects, causing injury.

⚠ WARNING

- **INGESTION HAZARD**: This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH** of **CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

■ Notes on the Built-in Battery

- This product contains a non-replaceable battery.
- The compatible battery type: MS621R
- The nominal battery voltage: 3V
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children.
  Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Do not force discharge, disassemble, heat above 60 °C or incinerate.
  Doing so may result in injury due to vending, leakage or explosion resulting in chemical burns.

Statement of Compliance

Manufacturer:	FUJIFILM Corporation
Address:	7-3, Akasaka 9-Chome Minato-Ku, Tokyo 107-0052, JAPAN
UK Authorized Representative:	FUJIFILM UK Ltd.
Address:	Fujifilm House, Whitbread Way, Bedford, Bedfordshire, MK42 0ZE, United Kingdom
Trade Mark:	FUJIFILM
Product Name:	DIGITAL CAMERA
Product Model Number:	FF250003
Model Number:	X-T30 III
Support period:	Seven years after the end of production For details, refer to the website shown below. *https://repairs.fujifilm.eu/en/repairable-products/*

We, Fujifilm Corporation, herewith declare under our sole responsibility that the product(s) identified in this declaration conforms to the applicable security requirements in Schedule 1 of the following Regulations and Standards.

Regulations:	The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023
Standards:	ETSI EN 303 645 V2.1.1 (2020-06) (provision 5.1-1, 5.1-2, 5.2-1, 5.3-13)
Place: JAPAN	Akihiro Kobayashi (Signature)
Date: July 11, 2025	(Name, Function) Akihiro Kobayashi General Manager of Quality Assurance Group, Imaging Solutions Division FUJIFILM Corporation

Product Care

To ensure continued enjoyment of the product, observe the following precautions.

Camera body: Use a soft, dry cloth to clean the camera body after each use. Do not use alcohol, thinner, or other volatile chemicals, which could discolor or deform the leather on the camera body. Any liquid on the camera should be removed immediately with a soft, dry cloth. Use a blower to remove dust from the monitor, taking care to avoid scratches, and then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of Fujifilm lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. To prevent dust entering the camera, replace the body cap when no lens is in place.

Image sensor: Multiple photographs marred by spots or blotches in identical locations may indicate the presence of dust on the image sensor. Clean the sensor using **USER SETTING** > **SENSOR CLEANING**.

Cleaning the Image Sensor

Dust that cannot be removed using **USER SETTING** > **SENSOR CLEANING** can be removed manually as described below.

Note that there will be a charge to repair or replace the image sensor if it is damaged during cleaning.

1 Use a blower (not a brush) to remove dust from the sensor.



2 Check whether the dust has been successfully removed.

3 Replace the body cap or lens.

- Do not use a brush or blower brush. Failure to observe this precaution could damage the sensor.
- If dust cannot be removed, we recommend asking your Fujifilm dealer to perform a cleaning.

Firmware Updates

When the firmware has been updated, and features have been added and/or changed, update the firmware.

After updating to the latest firmware, the features of the camera may differ somewhat from what is listed in this manual.

Downloading Firmware

First download the latest firmware and save it to a memory card. For the method to download the firmware, refer to the following website.

https://fujifilm-x.com/support/download/firmware/cameras/

Updating Firmware

Firmware can be updated in the following ways.

Updating the Firmware When Starting the Camera

Insert a memory card containing the new firmware into the camera. While pressing the **DISP/BACK** button, turn on the camera. The firmware can be updated. After the update is finished, turn the camera off once.

Updating the Firmware From the Setup Menus

Insert a memory card containing the new firmware into the camera. Select **USER SETTING** > **FIRMWARE UPDATE** to update the firmware.

Updating the Firmware Using a Smartphone App (manual update)

If you are using a smartphone app, you can update the firmware from the app. For details, refer to the following website.

https://fujifilm-dsc.com/

Updating the Firmware Using a Smartphone App (automatic update)

If FUJIFILM XApp Ver. 2.0.0 or later is used, the latest firmware will be automatically downloaded to the camera from your smartphone.

---

1 When using the camera, a confirmation screen will be displayed if the update is ready.
Select **START**.



If **CANCEL** is selected, the confirmation screen will be displayed again when the camera is turned on on the next day or later.

2 When the selection screen is displayed, select UPDATE NOW.



- Select **SCHEDULE DATE AND TIME** to automatically turn the camera on on the specified date and time and update.
- Select **REMIND ME LATER** to display the confirmation screen 3 days later.
- Select **TURN OFF NOTIFICATION** to display no confirmation screen.

3 Select OK.

4 Follow the instructions on the screen to update the firmware.

5 When the update completion screen is displayed, turn the camera off.

- Use a battery with a sufficient charge to update the firmware. Do not turn off or operate the camera during an update. If the camera is turned off during a firmware update, the camera may no longer operate normally.
- Nothing will be displayed on the EVF during a firmware update. Use the LCD monitor.
- The time required for a firmware update depends on the size of the firmware. At most, it may take about 10 minutes.
- It is not possible to return to a previous version after the firmware has been updated.
- If an error message appears while the firmware is being updated, refer to the following website.
  https://fujifilm-dsc.com/en-int/manual/error_message_recovery/

Checking the Firmware Version

Select **USER SETTING** > **FIRMWARE UPDATE** to check the version information.

To view the firmware version or update firmware for optional accessories such as interchangeable lenses, shoe-mounted flash units, and mount adapters, mount the accessories on the camera.

Troubleshooting

Consult the table below should you encounter problems using your camera. If you don't find the solution here, contact your local Fujifilm distributor.

Power and Battery

Power and Battery

Problem	Solution
The camera does not turn on.	• The battery is not charged at shipment. Charge the battery before first use. • Charge the battery or insert a fully-charged spare battery (📖 42). • Reinsert in the correct orientation (📖 39). • Latch the battery-chamber cover.
The battery runs down quickly.	• When using the battery in a low-temperature environment, keep it warm in your pocket or elsewhere and install it just before shooting. • Set **AF/MF SETTING** > **PRE-AF** to **OFF**. • Adjust the brightness of the display using **SCREEN SET-UP** > **EVF BRIGHTNESS** or **LCD BRIGHTNESS**. • Change the **POWER MANAGEMENT** setting.

Problem	Solution
The camera turns off suddenly.	• Check whether the battery is running out of power (📖 47). • When the time is set in **POWER MANAGEMENT** > **AUTO POWER OFF**, the camera will automatically turn off after that time has elapsed. • When the camera temperature becomes high, it will automatically turn off (📖 325). • If the interval shooting is long during interval-timer photography, the display on the screen will disappear. The display on the screen will return to normal a few seconds before shooting or when the shutter-release button is pressed.
The camera does not turn off.	Check the indicator lamp (📖 12).

Charging

Problem	Solution
Charging does not start (USB).	• Charging will not start when the camera is turned on. Turn off the power. • Charging will not start when the battery is fully charged. • Check the connection status of your computer, USB cables, and the camera. • When charging from a computer, make sure that the computer is turned on. • When the battery temperature is low or high, charging will not start for safety reasons. Wait for the battery temperature to return to normal temperature before charging again.

Problem	Solution
Charging is slow.	• When the battery temperature is low or high, charging may be slow for safety reasons. Wait for the battery temperature to return to normal temperature before charging again. • Use a USB PD compatible power supply with an output of 30 W or more to shorten the charging time.
The indicator lamp blinks, but the battery does not charge.	Clean the terminals with a soft, dry cloth (📖 39).

Power Supply

Problem	Solution
The power supply icon is not displayed.	Confirm that **POWER SUPPLY ON/COMM OFF** is selected for **USB POWER SUPPLY/COMM SETTING**.

Menus and Displays

Problem	Solution
Display is not in English.	Select **ENGLISH** for **USER SETTING** > **言語/LANG.** (📖 50, 293).

Shooting

Basic Photography

Problem	Solution
No picture is taken when the shutter button is pressed.	• Check whether the storage media is set correctly. • Check whether the write-protect switch on the memory card is not set to the lock position. • Check the free space on the storage media. • Select **ON** for **BUTTON/DIAL SETTING** > **SHOOT WITHOUT CARD** when shooting without a memory card. • If **FOCUS** is selected for **AF/MF SETTING** > **RELEASE/FOCUS PRIORITY**, you may not be able to shoot when the camera is not in focus. • If you are using a lens made by another manufacturer and the like, you may be able to take pictures by selecting **ON** for **BUTTON/DIAL SETTING** > **SHOOT WITHOUT LENS**.

Movie Recording

Problem	Solution
Video recording ended unexpectedly.	Recording may stop if the writing speed of the storage media is slow. A list of supported storage media is available on the Fujifilm website. For details, refer to "COMPATIBILITY (Cameras)". *https://fujifilm-x.com/support/compatibility/cameras/*

Continuous Shooting (Burst Mode)

Problem	Solution
The burst shooting speed is slowed down.	The burst shooting speed may be slower depending on conditions such as lens type, writing speed of the storage media, flash use, exposure conditions, camera settings, remaining battery level, and temperature of the environment in which the camera is used.

Panoramas

Problem	Solution
No panorama is recorded when the shutter button is pressed.	Wait until the indicator lamps turns off (📖 12).

Face Detection

Problem	Solution
No face is detected.	• Remove the obstructions. • Change the composition so that the subject's face occupies a larger area of the frame. • Ask the subject to face the camera. • Select **FACE DETECTION ON** for **AF/MF SETTING** > **FACE/EYE DETECTION SETTING**. • Keep the camera level. • Shoot in better light.

Subject Detection

Problem	Solution
No subject is detected.	• Choose a vantage point where you can see as much of the subject as possible. • Get closer to your subject so it occupies more of the frame. • Select **SUBJECT DETECTION ON** for **AF/MF SETTING** > **SUBJECT DETECTION SETTING**. • Shoot in better light.

Flash

Problem	Solution
The flash does not fire.	• Check **SHOOTING SETTING** > **SHUTTER TYPE**, **FLASH SETTING** > **FLASH FUNCTION SETTING**, and drive modes. • When using an external flash, check its instructions.
The flash does not fully light the subject.	• Position the subject in range of the flash. • Hold the camera correctly. • If the shutter speed is faster than the sync speed, the image may look darker even when the flash fires. Choose a shutter speed at the sync speed or slower than that (📖 73, 78, 415).

Abnormalities in Pictures Taken

Problem	Solution
The picture is out of focus. **The picture is blurry.**	• Set the focus mode to a mode other than manual focus. • Use a tripod when taking pictures. Also, it is recommended to use the remote release and the self-timer shooting function. • When shooting handheld, hold the camera steady and gently press the shutter-release button to avoid camera shake. • Turn on the camera's image stabilization function (📖 183). • When using a lens with image stabilization, turn on the image stabilization function. • The shutter speed may be slower in dark places. Use a faster shutter speed, increase the ISO sensitivity, or use a flash. • Shoot with focus and exposure locked. • Increase the size of the focus area by a couple of steps.

Problem	Solution
The camera records images of things that do not exist, or the subject is recorded distorted.	• Certain phenomena that are not visible to the naked eyes may be recorded in images due to the reflection of light and other circumstances. • The Q&A section of our website provides examples of such phenomena that may occur depending on the characteristics of the camera system and the light beams. It may be possible to control the occurrence of the phenomenon by using different shooting methods, so refer to our website.
Pictures are mottled.	This is normal and does not indicate a malfunction.* Select **IQ IMAGE QUALITY SETTING** > **PIXEL MAPPING**. * X-rays, cosmic rays, and other forms of radiation interacting with the image sensor may cause bright spots of various colors such as white, red, and blue. Pixel mapping helps reduce the occurrence of such bright spots.
Noise is recorded in the picture.	Turn off the power for a while before using (📖 46, 410).

Playback

Full-Frame Playback

Problem	Solution
Pictures are grainy.	The pictures were taken with a different make or model of camera.
Playback zoom is unavailable.	The pictures were created using **RESIZE** or with a different make or model of camera.

Movie Playback

Problem	Solution
No sound in movie playback.	• Adjust playback volume (📖 299). • Do not block the microphone during movie recording. • Do not block the speaker during playback.

Deletion

Problem	Solution
Selected pictures are not deleted.	Some of the pictures selected for deletion are protected. Remove protection using the device with which it was originally applied (📖 240).
Pictures remain after ERASE > ALL FRAMES is selected.	

Frame Number

Problem	Solution
File numbering is unexpectedly reset.	The battery-chamber cover was opened while the camera was on. Turn the camera off before opening the battery-chamber cover (📖 326).

During Connection

Connecting to TV

Problem	Solution
The monitor is blank.	When the camera is connected to a TV, nothing will be displayed on the camera screen in playback mode.
Both the TV and camera monitor are blank.	• Put your eye to the viewfinder. • Change the EVF/LCD display settings (📖 18).
No picture or sound on TV.	• Connect the camera properly. • Set input to "HDMI" (📖 55). • Use the controls on the television to adjust the volume. • Check the supported resolution and frame rate on the TV side.

Connecting to Computers

Problem	Solution
The computer does not recognize the camera.	• Check the USB cable and reconnect it correctly (📖 261). • Set the connection mode according to your intended use in advance before connecting the camera. • Set the camera connection mode compatible with the application used on the computer. Also, check the settings of the application on the computer.

Connecting to Smartphones

Problem	Solution
Cannot connect to iPhones or iPads.	**POWER SUPPLY ON/COMM OFF** is selected for **USB POWER SUPPLY/COMM SETTING**. Select **POWER SUPPLY OFF/COMM ON** when the camera is connected via a Lightning connection to a device that do not supply power.
Cannot connect to smartphone.	The procedure for connecting the camera varies with the type of connector with which the smartphone is equipped (📖 260).

Wireless Transfer

For additional information on troubleshooting wireless connections, visit:
https://digitalcamera-support-en.fujifilm.com/

Problem	Solution
Cannot connect to smartphone. **The camera is slow to connect or upload pictures to the smartphone.** **Upload fails or is interrupted.**	• Move the devices closer (📖 256). • Use the camera away from devices that emit radio waves.
Cannot upload images.	• The smartphone and camera can connect to only one device at a time. End the connection and try again (📖 256). • Try connecting again. The presence of multiple smartphones can make connection difficult. • The camera may not be able to upload images created on other devices. • Uploading movies takes some time. In addition, smartphones may not accept upload of movies in formats they do not support.

Miscellaneous

Camera Operation

Problem	Solution
The camera is unresponsive.	• Remove and reinsert the battery (📖 39). • Charge the battery or insert a fully-charged spare battery (📖 42). • Check the USB or LAN connection mode. • Press and hold the **MENU/OK** button to unlock the controls (📖 15, 17). • Check the lighting status of the indicator lamp. If the problem persists, reinsert the battery and check whether the camera operates. • Select **BUTTON/DIAL SETTING** > **LOCK** to check whether the buttons are locked.
The camera does not function as expected.	Remove and reinsert the battery (📖 39). If the problem persists, contact your Fujifilm dealer.

Sound

Problem	Solution
No sound.	Adjust the volume (📖 296).

Q (The Quick Menu)

Problem	Solution
Pressing the Q button does not display the quick menu.	End TTL-LOCK (📖 185).

Warning Messages and Displays

The following warnings appear in the display.

Warning	Description
(red)	Low battery. Charge the battery or insert a fully-charged spare battery.
(blinks red)	Battery exhausted. Charge the battery or insert a fully-charged spare battery.
! AF (displayed in red with red focus frame)	The camera cannot focus. Use focus lock to focus on another subject at the same distance, then recompose the picture.
Aperture or shutter speed displayed in red	The subject is too bright or too dark and the picture will be over- or under-exposed. Use the flash for additional lighting when taking photographs of poorly-lit subject.
FOCUS ERROR **LENS CONTROL ERROR** **TURN OFF THE CAMERA AND TURN ON AGAIN**	Camera malfunction. Turn the camera off, remove the lens, and check for foreign matter between the lens and the camera body, then replace the lens and turn the camera on. If the problem persists, contact a Fujifilm dealer.
CARD NOT INITIALIZED	• **The memory card is not formatted or the memory card has been formatted in a computer or other device**: Format the memory card using **USER SETTING** > **FORMAT**. • **The memory card contacts require cleaning**: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card. • **Camera malfunction**: Contact a Fujifilm dealer.

Warning	Description
LENS ERROR	Turn the camera off, remove the lens, and check for foreign matter between the lens and the camera body, then replace the lens and turn the camera on. If the problem persists, contact a Fujifilm dealer.
CARD ERROR	• **The memory card is not formatted for use in the camera**: Format the card. • **The memory card contacts require cleaning or the memory card is damaged**: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card. • **Incompatible memory card**: Use a compatible card. • **Camera malfunction**: Contact a Fujifilm dealer.
PROTECTED CARD	The memory card is locked. Unlock the card.
BUSY	The memory card is incorrectly formatted. Use the camera to format the card.
SD MEMORY FULL	The memory card is full and pictures cannot be recorded. Delete pictures or insert a memory card with more free space.

Warning	Description
WRITE ERROR	• **Memory card error or connection error**: Reinsert the card or turn the camera off and then on again. If the message persists, contact a Fujifilm dealer. • **Not enough memory remaining to record additional pictures**: Delete pictures or insert a memory card with more free space. • **The memory card is not formatted**: Format the memory card. • **The memory card was removed while data were being recorded**: Do not remove the memory card during recording. • **The memory card write speed is slow**: When recording movies, be sure the memory card write speed is fast enough.
FRAME NO. FULL	The camera has run out of frame numbers (current frame number is 999-9999). Insert a formatted memory card and select **RENEW** for **SAVE DATA SET-UP** > **FRAME NO.**. Take a picture to reset frame numbering to 100-0001, then select **CONTINUOUS** for **FRAME NO.**.

Warning	Description
READ ERROR	• **The file is corrupt or was not created with the camera**: The file cannot be viewed. • **The memory card contacts require cleaning**: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card. • **Camera malfunction**: Contact a Fujifilm dealer.
PROTECTED FRAME	An attempt was made to delete or rotate a protected picture. Remove protection and try again.
CAN NOT CROP	The picture is damaged or was not created with the camera.
DPOF FILE ERROR	Print orders can contain no more than 999 pictures. Copy any additional pictures you wish to print to another memory card and create a second print order.
CAN NOT SET DPOF	The picture cannot be printed using DPOF.
CAN NOT SET DPOF	Movies cannot be printed using DPOF.
CAN NOT ROTATE	The selected picture cannot be rotated.
CAN NOT ROTATE	Movies cannot be rotated.

Warning	Description
CANNOT EXECUTE	**The selected operation is not supported**: Check whether the picture was recorded with a different model of camera.
CANNOT EXECUTE	
! (yellow) **CAMERA IS APPROACHING STANDARD TEMPERATURE LIMIT**	The camera is approaching the maximum temperature allowed when **STANDARD** is selected for **AUTO POWER OFF TEMP.** and will shortly turn off automatically. Turn the camera off and wait for it to cool.
! (yellow) **CAMERA IS APPROACHING HIGH TEMPERATURE LIMIT.DO NOT HOLD CAMERA FOR LONG PERIODS OF TIME**	The camera is approaching the maximum temperature allowed when **HIGH** is selected for **AUTO POWER OFF TEMP.** and will shortly turn off automatically. Remaining in contact with the camera could result in low-temperature burns; mount the camera on a tripod or take other steps to avoid prolonged contact with the camera. The camera will shortly turn off automatically. Turn the camera off and wait for it to cool. Mottling may increase in pictures taken when this warning is displayed.
! (red) **HIGH TEMPERATURE LIMIT REACHED SHUTTING DOWN**	The camera temperature has reached the cutoff point and the camera is about to turn off automatically. Turn the camera off and wait for it to cool. Mottling may increase in pictures taken when this warning is displayed.

Memory Card Capacity

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

	Capacity	SD memory cards 64 GB	
		FINE	NORMAL
Photos	L 3:2	4050	6000
	RAW (UNCOMPRESSED)	1000	
	RAW (LOSSLESS COMPRESSED)	1990	
	RAW (COMPRESSED)	2750	
Movies*	4K 2160	160 minutes	
	FHD 1080	160 minutes	

* Assumes default bit rate.

- The types of memory cards suitable for movie recording vary with the settings selected (📖 63).
- Depending on the bit rate, shots saved to memory cards with a capacity of 32 GB or less may be recorded across multiple files without interruption. The same is true of shots over an hour in length, independent of the bit rate and memory card capacity.

Specifications

System	
Model	FUJIFILM X-T30 III
Product Number	FF250003
Effective pixels	Approx. 26.1 million
Image sensor	23.5 mm × 15.6 mm (APS-C), X-Trans CMOS 4 sensor with primary color filter
Storage media	Fujifilm-recommended SD/SDHC/SDXC memory cards
Memory card slots	SD memory card slot (UHS-I compliant)
File system	• **Still pictures:** Compliant with DCF 2.0 • **Compressed:** Exif 2.32 JPEG-baseline compliant; DPOF compliant; HEIF compliant (4 : 2 : 2, 10-bit) • **Uncompressed or compressed using a reversible or non-reversible algorithm:** RAW (original RAF format; special-purpose software required); RAW+JPEG available; TIFF (RGB) • **Movies:** Compliant with HEVC/H.265, and H.264 • **Audio (including voice memos):** – LPCM (two channels: 24-bit, 48 kHz sampling) – AAC (MP4 recordings only)

System		
Image size	**L** **3:2** (6240 × 4160) **L** **16:9** (6240 × 3512)	**L** **1:1** (4160 × 4160)
	M **3:2** (4416 × 2944) **M** **16:9** (4416 × 2488)	**M** **1:1** (2944 × 2944)
	S **3:2** (3120 × 2080) **S** **16:9** (3120 × 1760)	**S** **1:1** (2080 × 2080)
	instax mini (1568 × 2080) **instax SQUARE** (2080 × 2080)	**instax WIDE** (3120 × 1984)
	RAW (6240 × 4160)	**TIFF** (6240 × 4160)
	L **panorama**: vertical (2160 × 9600)/horizontal (9600 × 1440) **M** **panorama**: vertical (2160 × 6400)/horizontal (6400 × 1440)	
Lens mount	FUJIFILM X mount	
Sensitivity	• **Still pictures**: Standard output sensitivity equivalent to ISO 160–12800 in increments of ⅓ EV; AUTO 1–3; extended output sensitivity equivalent to ISO 80, 100, 125, 25600, or 51200 • **Movies**: Standard output sensitivity equivalent to ISO 160–12800 in increments of ⅓ EV; AUTO; extended output sensitivity equivalent to ISO 25600	
Metering	256-segment through-the-lens (TTL) metering; MULTI, SPOT, AVERAGE, CENTER WEIGHTED	
Exposure control	Programmed AE (with program shift); shutter-priority AE; aperture-priority AE; manual exposure	
Exposure compensation	• **Still pictures**: −5 EV–+5 EV in increments of ⅓ EV • **Movies**: −2 EV–+2 EV in increments of ⅓ EV	

System

Shutter speed

- **MECHANICAL SHUTTER, E-FRONT CURTAIN SHUTTER, E-FRONT + MECHANICAL**
  - **Modes P and A**: 30 s to 1/4000 s
  - **Modes S and M**: 15 min. to 1/4000 s
  - **Bulb**: Max. 60 min.
- **ELECTRONIC SHUTTER**
  - **Modes P and A**: 30 s to 1/32000 s
  - **Modes S and M**: 15 min. to 1/32000 s
  - **Bulb**: Fixed at 1 s
- **MECHANICAL + ELECTRONIC, E-FRONT + MECHANICAL + ELECTRONIC**
  - **Modes P and A**: 30 s to 1/32000 s
  - **Modes S and M**: 15 min. to 1/32000 s
  - **Bulb**: Max. 60 min.

The shutter speed ranges for continuous mode may differ from those listed here.

Continuous

CONTINUOUS MODE	Available frame advance rates (JPEG)
30fps(1.25X CROP)*	30
20fps(1.25X CROP)*	20
10fps(1.25X CROP)*	10
20fps*	20
10fps*	10
8.0fps	8.0
5.0fps	5.0
4.0fps	4.0
3.0fps	3.0

* Available with electronic shutter only.

The frame rate and number of frames per burst varies with shooting conditions and type of memory card used.

System	
Focus	• **Mode**: Single or continuous AF; manual focus with focus ring • **Autofocus system**: Intelligent hybrid AF (TTL contrast-detect/phase-detection AF) • **Focus-area selection**: SINGLE POINT, ZONE, WIDE/TRACKING, ALL
White balance	Auto (WHITE PRIORITY, AUTO, AMBIENCE PRIORITY), Custom 1, Custom 2, Custom 3, color temperature selection, direct sunlight, shade, daylight fluorescent, warm white fluorescent, cool white fluorescent, incandescent, underwater
Self-timer	• **Still pictures**: Off, 2 sec., 10 sec. • **Movies**: Off, 3 sec., 5 sec., 10 sec.
Flash	• **Type**: Manual pop-up flash unit • **Guide number**: Approx. 5/16.4 (ISO 100, m/ft.)
Flash mode	• **MODE**: TTL MODE (FLASH AUTO, STANDARD, SLOW SYNC.), MANUAL, COMMANDER, OFF • **SYNC. MODE**: 1ST CURTAIN, 2ND CURTAIN, AUTO FP (high-speed sync) • **RED EYE REMOVAL**: FLASH, OFF
Hot shoe	Provided (supports TTL flash control); supports sync speeds as fast as 1/180 s
Sync contact	X contact; supports sync speeds as fast as 1/180 s
Sync terminal	–
Electronic viewfinder (EVF)	0.39-in., 2360k-dot OLED viewfinder; magnification 0.62× with 50 mm lens (35 mm format equivalent) at infinity and diopter set to −1.0 m^{-1}; diagonal angle of view approximately 31° (horizontal angle of view approximately 26°) • **Diopter adjustment**: −4 to +2 m^{-1} • **Eyepoint**: Approximately 17.5 mm
LCD monitor	3.0-in/7.6 cm, 1620k-dot color touchscreen LCD monitor, tilting

System	
Movies (with stereo sound)	• **Movie size**: 6.2K 3:2, 4K 16:9, DCI 4K 17:9, FHD 16:9, FHD 9:16, FHD 17:9 • **Frame rate**: 59.94P, 50P, 29.97P, 25P, 24P, 23.98P • **Recording/output format**: – H.265 (10-bit MOV 4:2:2/4:2:0; 360, 200, 100, or 50 Mbps) – H.264 (8-bit MOV/MP4 4:2:0; 360, 200, 100, or 50Mbps) – HDMI output supported (RAW output supported with Atomos and Blackmagic Design external recorders; 8-bit 4:2:2/10-bit 4:2:2)
High-speed movies	• **Movie size**: FHD 16:9, FHD 17:9 • **Frame advance rate**: 240P, 200P, 120P, 100P

Input/output terminals	
Microphone connector	⌀2.5 mm mini-stereo jack
Headphone jack socket	The USB connector can be converted to a headphone jack using the supplied headphone adapter
Remote release connector	⌀2.5 mm 3-pole mini jack
Digital input/output	USB connector: USB Type-C® USB 10 Gbps
HDMI output	HDMI Micro connector (type D)

Power supply/other

Power supply

NP-W126S rechargeable battery (supplied with camera)

Battery life

- **Battery type**: NP-W126S
- **Lens**: XF35mmF1.4 R
- **External flash units**: Disabled
- **Shooting mode**: Mode **P**

Number of shots		
PERFORMANCE	**LCD**	**EVF**
BOOST[1]	Approx. 310	Approx. 260
NORMAL	Approx. 315	Approx. 315
ECONOMY	Approx. 425	Approx. 380

Total length of footage that can be recorded on a single charge		
Mode	**Actual battery life of movie capture**	**Continuance battery life of movie capture**
6.2K[2]	Approx. 45 minutes	Approx. 65 minutes
4K[3]	Approx. 40 minutes	Approx. 60 minutes
FHD[3]	Approx. 45 minutes	Approx. 80 minutes
High-speed movies[4]	Approx. 50 minutes	–

1 **EVF FRAME RATE PRIORITY (100P)** selected **EVF/LCD BOOST SETTING**.
2 At a frame rate of 29.97 fps.
3 At a frame rate of 59.94 fps.
4 At a frame rate of 120 fps.

CIPA standard. Measured using battery supplied with camera and SD memory card.

Note: Battery endurance varies with battery charge level and the figures given above are not guaranteed. Battery endurance will decline at low temperatures.

Power supply/other	
Camera size (W × H × D)	118.4 mm × 82.8 mm × 46.8 mm (31.9 mm excluding projections, measured at thinnest part)/4.67 in. × 3.26 in. × 1.85 in. (1.26 in.)
Camera weight	Approx. 329 g/11.6 oz., excluding battery, accessories, and memory card
Shooting weight	Approx. 378 g/13.3 oz., including battery and memory card
Operating conditions	• **Temperature**: 0 °C to +40 °C/+32 °F to +104 °F (+5 °C to +40 °C/+41 °F to +104 °F when battery is charging) • **Humidity**: 10% to 80% (no condensation)

Wireless transmitter	
Wireless LAN	
Standards	IEEE 802.11b/g/n (standard wireless protocol)
Operating frequency (center frequency)	2,412 MHz–2,462 MHz (11 channels)
Access protocols	Infrastructure
Bluetooth®	
Standards	Bluetooth version 5.2 (Bluetooth Low Energy)
Operating frequency (center frequency)	2,402 MHz–2,480 MHz

NP-W126S rechargeable battery	
Nominal voltage	7.2 V
Nominal capacity	1260 mAh
Operating temperature	0 °C to +40 °C/+32 °F to +104 °F
Dimensions (W × H × D)	36.4 mm × 47.1 mm × 15.7 mm/1.4 in. × 1.9 in. × 0.6 in.
Weight	Approx. 47 g/1.7 oz.

Specifications and performance are subject to change without notice. Fujifilm will not be held liable for any errors this manual may contain. The appearance of the product may differ from that described in this manual.

FUJIFILM

FUJIFILM Corporation
7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN
https://fujifilm-x.com